

MSI-6360

Trans-Weigh Crane Scales

Technical Manual



© Rice Lake Weighing Systems. All rights reserved.

Rice Lake Weighing Systems® is a registered trademark of
Rice Lake Weighing Systems.

All other brand or product names within this publication are trademarks or
registered trademarks of their respective companies.

All information contained within this publication is, to the best of our knowledge, complete and
accurate at the time of publication. Rice Lake Weighing Systems reserves the right to make
changes to the technology, features, specifications and design of the equipment without notice.

The most current version of this publication, software, firmware and all other product
updates can be found on our website:

www.ricelake.com

Revision History

This section tracks and describes manual revisions for awareness of major updates.

Revision	Date	Description
A	June 13, 2023	Initial manual release with product launch

Table i. Revision Letter History



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at www.ricelake.com/training or obtained by calling 715-234-9171 and asking for the training department.

Contents

1.0 Introduction	7
1.1 FCC Compliance	8
1.2 Overview	8
1.3 Display	9
2.0 Installation	10
2.1 Unpacking	10
2.2 Battery Pack	10
2.2.1 Battery Life	10
2.2.2 Battery Charger	11
2.2.3 Battery Replacement	12
2.3 Communications Port	13
2.3.1 Communications Port Cables	13
2.4 RF Connection	13
2.5 Servicing	14
2.5.1 Remove Front Casting	14
2.5.2 Reinstall Front Casting	14
2.6 Replacement Parts	15
2.6.1 MSI-6360 Front Casting Assembly	15
2.6.2 MSI-6360 Bulkhead Assembly	17
2.6.3 MSI-6360 Mid-Section Assembly	18
2.6.4 MSI-6360 Back Assembly	24
3.0 ScaleCore Connect Installation	25
3.1 Install Program	25
4.0 Configuration/Setup	26
4.1 Connect a Device	26
4.2 Connected Devices	26
4.3 Device Profiles	26
4.4 Configuration	27
4.4.1 Auto Connect	27
4.4.2 Product Info	27
4.4.3 RF Configuration	28
4.5 Load Cells	29
4.5.1 General	29
4.5.2 Zero, Standard	30
4.5.3 Total	31
4.5.4 Math	32
4.5.5 Maintenance	32
4.5.6 Calibration Records	33
4.6 Inputs / Outputs	34
4.6.1 Setpoints	34
4.6.2 Stream Print String	35
4.7 Monitors	39
4.8 File Menu	40
4.8.1 Open Profile	40
4.8.2 Exit	40



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit www.ricelake.com/webinars

4.9 Administration Menu 40

4.10 Communications Menu 41

 4.10.1 Select Stream Port 41

 4.10.2 Configure Stream Port 41

4.11 Program Menu 42

 4.11.1 Program App Code 42

 4.11.2 Acquire Profile from Device 43

 4.11.3 Clone Profile to Device..... 43

5.0 Calibration 44

 5.1 Calibration Switch Access 44

 5.2 Calibration 44

 5.2.1 Full Calibration 45

 5.2.2 Re-Calibration 45

 5.2.3 Full Constant Calibration 46

 5.2.4 Constant Re-Calibration..... 46

6.0 Troubleshooting and Maintenance 47

 6.1 Troubleshooting 47

 6.2 Radio Compliance..... 48

 6.2.1 802.15.4 (XBee 3 and XBee 3-PRO) 48

 6.2.2 802.15.4 (XBee 2SC) 49

 6.2.3 Wi-Fi..... 49

 6.2.4 FHSS (Frequency Hopper Spread Spectrum) 49

 6.3 MSI-6360 Trans-Weigh Dimensions 50

7.0 Specifications 51



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at www.ricelake.com/training or obtained by calling 715-234-9171 and asking for the training department.



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit www.ricelake.com/webinars

1.0 Introduction

This manual is intended for use by service technicians responsible for installing and servicing the MSI-6360 Trans-Weigh crane scale.

Configurations and calibrations of the scale can be accomplished using ScaleCore Connect software or RF remote displays. See [Section 4.0 on page 26](#) and [Section 5.0 on page 44](#) for information about setup and configuration of the MSI-6360.



Manuals and additional resources are available from Rice Lake Weighing Systems at www.ricelake.com/manuals

Warranty information can be found at www.ricelake.com/warranties

Safety Definitions:



DANGER: Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. Includes hazards that are exposed when guards are removed.



WARNING: Indicates a potentially hazardous situation that, if not avoided, could result in serious injury or death. Includes hazards that are exposed when guards are removed.



CAUTION: Indicates a potentially hazardous situation that, if not avoided, could result in minor or moderate injury.



IMPORTANT: Indicates information about procedures that, if not observed, could result in damage to equipment or corruption to and loss of data.

General Safety



Do not operate or work on this equipment unless this manual has been read and all instructions are understood. Failure to follow the instructions or heed the warnings could result in injury or death. Contact any Rice Lake Weighing Systems dealer for replacement manuals.



WARNING

Failure to heed could result in serious injury or death.

Do not allow minors (children) or inexperienced persons to operate this unit.

Do not stand near the load being lifted as it is a potential falling hazard. Keep a safe distance.

Do not use for purposes other than weight taking or dynamic load monitoring.

Do not use any load bearing component that is worn beyond 5% of the original dimension.

Do not use the scale if any of the components of the load train are cracked, deformed or show signs of fatigue.

Do not exceed the rated load limit of the scale, rigging elements or the lifting structure.

Do not allow multi-point contact with the hook, shackle or lifting eye of the scale.

Do not allow high torque on the scale unless it is specifically designed for high torque.

Do not make alterations or modifications to the scale or associated load bearing devices.

Do not use improperly rated or sized shackles. Use only Rice Lake Weighing Systems recommended shackles.

Do not remove or obscure warning labels.

Do not submerge to clean.

For guidelines on the safe rigging and loading of overhead scales and dynameters, read the MSI Crane Scale Safety and Periodic Maintenance Manual (available at www.ricelake.com).

Keep hands, feet and loose clothing away from moving parts.

There are no user serviceable parts within the MSI-6360. Any repairs are to be performed by qualified service personnel only.

The MSI-6360 Trans-Weigh scale has a safe mechanical overload of 200% and an ultimate overload of 500%. Overloads greater than 500% could result in structural failure and dropped loads. Dropped loads could cause serious personal injury or death.

1.1 FCC Compliance

United States

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Canada

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la Class A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

1.2 Overview

A single MSI-6360 Trans-Weigh can be used to communicate with a ScaleCore-based remote display. A paired transmitter and receiver can be used to wirelessly send weight data to any ScaleCore compatible remote display.



Figure 1-1. MSI Trans-Weigh 6360 Series

1.3 Display




Figure 1-2. MSI-6360 Front Panel

Item No.	Description
1	Status LED – Indicates state of unit power Steady short green blinks – RF connected, good battery (or AC power) Two short red blinks then a pause – RF connected, low battery Four short red blinks then a pause – RF connected, very low battery Steady long red blinks – RF disconnected and good battery (or AC power) Long red blink, short red blink then a pause – RF disconnected and low battery Long red blink, three short red blinks – RF disconnected and very low battery Steady red – Load cell fault (overload/underload/uncal/error/etc.) Five green blinks per second – Calibration mode Steady Green – Standby mode
2	Power Switch Press & release – Turns unit on/off

Table 1-1. Key Functions

2.0 Installation

This section details unpacking and installation of the MSI-6360 Trans-Weigh crane scale.



WARNING: Refer to the Crane Scale Safety and Periodic Maintenance Manual (PN 153105) for safe loading and rigging guidelines when installing the model MSI-6360.

Regular maintenance inspections of the lifting system should be performed to ensure safety. Pay particular attention for signs of stress on any element in the load train.

Use the appropriate interface hardware for the capacity of the scale.

- If the interface hardware does not fit properly, Rice Lake Weighing Systems can supply the MSI-6360 with oversize lifting eyes or shackle interfaces.
- If the crane hook is too large to fit in the lifting eye with single point interface, then install the scale using adaptive rigging.
- If multiple attachments are needed, use a shackle or ring to attach the multiple lines to keep a single point attachment to the scale.



IMPORTANT: Using an oversize shackle or hook to interface with the MSI-6360 can cause off center loading and stress points that will reduce the life of the lifting eye or hook.

Single point attachments are necessary to ensure the safety and accuracy of the scale system.

2.1 Unpacking

When unpacking the MSI-6360, ensure that all assembly parts are accounted for. Check the MSI-6360 for any visible damage. If any parts were damaged in shipment, notify Rice Lake Weighing Systems and the shipper immediately. If the MSI-6360 must be returned, it must be properly packed with sufficient packing materials. Whenever possible, use the original carton when shipping the unit back.

2.2 Battery Pack

The MSI-6360 is powered by a 12V Sealed Lead Acid (SLA) rechargeable battery. This battery will operate for up to 85 hours before requiring recharging. Charging time for a completely discharged battery is up to eight hours. A spare battery pack is recommended to keep the MSI-6360 in continuous operation.



IMPORTANT: To obtain maximum service life from batteries, store between -4°F and 122°F (-20°C and $+50^{\circ}\text{C}$).

Stored batteries should be recharged every three months. The battery is fully charged when the status indicator on the battery charger is flashing.

2.2.1 Battery Life

The battery life of the MSI-6360 depends on a number of factors:

- The age of the battery
- The condition of the SLA battery
- Ambient temperature

The MSI-6360 automatically turns off when the SLA battery drops to approximately 10.5V. Recharge the battery when this happens, SLA batteries benefit from frequent recharging and can be recharged when it still has available life.

Due to the maintenance discharge imposed on the battery by the MSI-6360 electronics, do not store the MSI-6360 with the battery inside. Remove the battery if it will not be used for more than two weeks.



IMPORTANT: Leaving a discharged battery in the scale, which has a maintenance battery drain, can result in a deep discharged battery which will shorten its service life.



NOTE: If the scale is in continuous use, a fully charged spare battery is recommended. Replace the drained battery as close as possible to the low battery warning.

SLA batteries that have not been deep discharged should withstand 500 to 1500 charging cycles.

Low battery warning annunciator indicates about two to four hours of additional use before MSI-6360 powers off.

If MSI-6360 is not going to be used again soon, remove SLA battery to prevent deep discharge while unit is in storage.

Recycle the battery at an authorized recycling center when the average life drops to 20 hours or less.

2.2.2 Battery Charger

The MSI-6360 is shipped with a battery charger designed to charge and maintain the battery. Exact charging time will depend on the degree of discharge of the battery. A battery removed when the low battery warning first appears should take about four hours to fully charge.

⚠ DANGER: *Charger is for indoor use only and should not be used in wet locations.*

📄 NOTE: *When the battery is new, it might take significantly longer for the initial charge. It is recommended to charge a new battery for 24 hours. It might take several charge/discharge cycles before full capacity is reached. Deep discharged batteries will also take significantly longer to charge.*



Figure 2-1. Battery Charger Connected to Battery

The battery charger illuminates annunciators as the battery charges. To charge the battery:

1. Remove the battery from the MSI-6360 (Figure 2-2 on page 12).
2. Connect the charger assembly to the AC power supply (86-260 VAC). The power annunciator displays red.

📄 NOTE: *If the power status light fails to illuminate, check the AC power connection to ensure the jack is fully seated. AC power cords suitable for any world location are available from Rice Lake Weighing Systems.*

3. Plug the polarized connector into the jacks on the battery. Charging annunciators illuminate to represent charge percentage.
4. Charge until all of the status annunciators fully illuminate.

When the charge cycle is complete, the battery can be left on the charger until it is needed. The charger keeps a maintenance float charge on the battery to ensure the best possible operation times.

⚠ IMPORTANT: *For maximum service life from batteries, the manufacturer suggests recharging after each 20 hours of use. Continuous deep discharging reduces maximum battery life cycle estimated at 2000 cycles.*

Extended use at temperatures below 14°F (-10°C) and above 104°F (40°C) may reduce battery life.

2.2.3 Battery Replacement

1. Turn the MSI-6360 off.
2. Secure the battery cover.
3. Release the latches holding the battery cover.
4. Slowly lower the cover while holding the battery in place.
5. Remove the battery by pulling straight back.
6. Install a fully charged battery by plugging it in to the exposed battery jacks.
7. Close the battery cover.
8. Reset the latches. Make sure the latches are completely latched and the cover is firmly in place.




Figure 2-2. Remove Battery



IMPORTANT: Periodically, inspect the battery latches for fit. Adjust the screw latch by rotating the catch on its threads to maintain a tight seat on the battery O-ring.



CAUTION: The 12V Sealed Lead Acid battery can be a dangerous falling hazard. When opening the battery hatch, be sure to hold the battery to prevent it from falling. These batteries contain lead and should be recycled when it has reached its end of life.

2.3 Communications Port

The MSI-6360 has a single communications port allowing access to the embedded ScaleCore through the terminal access mode or ScaleCore Connect. The terminal access mode is used for updating scale firmware while ScaleCore Connect can be used for calibration and configuration, backup and adjusting scale settings. This communications port is not intended for output use.

2.3.1 Communications Port Cables

The MSI-6360 comes standard with one communications port cable wired for RS-232 following the AT standard for 9-pin serial cables (DCE). An un-terminated cable is also available for wiring the serial cable for RS-232.

Table 2-1 shows the wiring color code.

Signal	Wire Color
TxD (transmitted data)	Brown
RxD (received data)	Black
CTS (clear to send)	Grey
RTS (request to send)	White
GND	Blue
PG (protective ground)	Drain Wire

Table 2-1. RS-232 Wiring Code




Figure 2-3. Comm Port Cable Assignments Examples

2.4 RF Connection

The RF modem in the MSI-6360 must be configured to accept communication from a remote device. For information about RF connections, see [Section 4.4.3 on page 28](#).

2.5 Servicing

Rice Lake's dealer network provides both on-site and depot servicing of MSI-6360 crane scales. Please contact a local dealer or Rice Lake Weighing Systems to obtain a return material authorization (RMA). Due to the weight and size of many of the product, it is not always necessary to return the whole scale. Lower swivel hook assemblies and upper lifting shackles on 50k capacity models and above do not need to be returned for service or recalibration. There are no user serviceable parts inside the MSI-6360. Depot repair is performed with module and harness swaps. If the electronics are at fault, often the front casting section is all that needs to be returned.




Figure 2-4. Remove Front Casting

2.5.1 Remove Front Casting

See the following procedure to remove the front casting:

1. Remove the cap screws (x4).
2. Unplug connectors.
3. Package the front casting well for safe shipping.

2.5.2 Reinstall Front Casting

See the following procedure to reinstall the front casting:

1. Clean the front casting and bulkhead o-ring grooves with isopropyl alcohol.
2. Reconnect the load cell cables and power cables then tighten the cables.
3. While securing the o-ring, ensure the o-ring is flush with the o-ring grooves.



WARNING: Replace damaged o-rings when necessary. Damaged o-rings may break the unit seal, causing water penetration.

4. Insert the bolts (x4) into the front casting then torque the bolts to 20-25 ft-lbs.



NOTE: Apply anti-seize compound as necessary.

2.6 Replacement Parts

2.6.1 MSI-6360 Front Casting Assembly




Figure 2-5. MSI-6360 Front Casting Assembly

Item	Part No.	Description
1	144773	Radio module Xbee-pro
2	212607	PCA 6360 no display
3	71408	Battery, lithium CR2032
4	146606	Screw pan head 8-32 x 1/4 stainless steel
5	215863	Bracket angle steel #8
6	146629	Nut, hex 8-32 nyloc stainless steel
7	146531	Washer flat #8 stainless steel
8	215842	Cable assembly, toggle switch
9	142591	Screw seal dr hh 8-32
10	139449	Cable assembly, comm serial
11	143352	Conn closure cap IP68
12	215973	LED/capacity label 6360
13	215948	Label descriptive 6360
14	201823	Antenna assembly 2.4 GHz patch
15	215840	Front casting machined
16	215912	Cable assembly, red/green LED
17	146608	Screw pan head 8-32 x 7/16 Phillips
18	143075	Cable clamp .375 diameter
19	215938	Standoff 3/16 hex x 0.875
20	215935	Standoff 3/16 hex x 2.00
21	146593	Screw pan head 4-40 x 3/16 Phillips
22	144929	Spacer miniature dual
23	153429	PCA ScaleCore3 1-channel

Table 2-2. MSI-6360 Front Casting Assembly Components

2.6.2 MSI-6360 Bulkhead Assembly




Figure 2-6. MSI-6360 Bulkhead Assembly

Item	Part No.	Description
1	215839	Front bulkhead
2	139471	Cable assembly, bulkhead load
3	139472	Cable assembly, bulkhead

Table 2-3. MSI-6360 Front Casting Assembly Components

2.6.3 MSI-6360 Mid-Section Assembly




Figure 2-7. MSI-6360 Mid-Section Assembly 500 lb to 10,000 lb

Item	Part No.	Description
1	145990	Screw socket head 1/4-20 x 5/8 stainless steel
2	149710	Seal link lower (500lb - 2K)
2	149165	Seal link lower (5 - 10k)
3	148457	Bolt clevis hex head 5/8 x 1.75 (500lb - 2K)
3	149217	Bolt clevis hex head 5/8 x 1.75 (5 - 10K)
4	138661	Load cell assembly (500 lb)
4	138662	Load cell assembly (1 - 2K)
4	138663	Load cell assembly (5K)
4	138664	Load cell assembly (10K)
5	72031	Screw
6	148271	Upper link (500 lb -2K)
6	149126	Upper link (5 - 10K)
7	128799	Screw, set 1/4-20 x 3/8
8	139795	Eye nut #7 (500 lb - 2K)
8	148225	Eye nut #7 (5 - 10K)
9	148274	Collar top half (500 lb - 2K)
10	146322	Filter millipore
11	15238	Cotter pin
12	142832	Nut hex slotted 5/8 - 11
13	150519	Casting (500 lb - 2K)
13	149175	Casting (5 - 10K)
14	148259	Collar (500 lb - 2K)
14	149168	Collar (5 - 10K)
15	135043	Swivel hook assembly (500 lb - 2K)
15	143236	Latch, safety (500 lb - 2K)
15	134523	Swivel hook assembly (5 - 10K)
15	143233	Latch, safety (5 - 10K)

Table 2-4. MSI-6360 Mid-Section Assembly 500 lb to 10,000 lb Components




Figure 2-8. MSI-6360 Mid-Section Assembly 20,000 lb and 30,000 lb

Item	Part No.	Description
1	134938	Swivel hook assembly (20K)
1	134939	Swivel hook assembly (30K)
1	110661	Latch assembly (20K)
1	143235	Latch assembly (30K)
2	81280	Washer, lock no 6 type A
3	146601	Screw pan head 6-32 x 1/4 Phillips
4	148458	Bolt clevis hex head 1.125 - 7
5	139843	Ground strap cable
6	146101	Screw pan head 6-32 x 3/16 type
7	149957	Boot lower (20-70K)
8	137763	Load cell assembly (20/30K)
9	146631	Nut hex 1/4-20 nyloc stainless steel
10	149976	Gasket upper (20/30K)
11	146081	Screw set 3/8-24 x 3/4
12	148110	Eye nut (20/30K) galvanized
13	81405	Screw, socket head 1/4-20
14	146322	Filter millipore
15	142186	Cotter pin 3/16 x 2 stainless steel
16	142833	Nut hex slotted 1.125 - 7
17	150523	Mid-section machined
18	149958	Collar bottom (20 - 50K)
19	145990	Screw socket head 1/4-20 x 5/8 stainless steel

Table 2-5. MSI-6360 Mid-Section Assembly 20,000 lb and 30,000 lb Components




Figure 2-9. MSI-6360 Mid-Section Assembly 50,000 and 70,000 lb

Item	Part No.	Description
1	81280	Washer, lock no 6 type A
2	146601	Screw pan head 6-32 x 1/4 Phillips
3	139843	Ground strap cable
4	146101	Screw pan head 6-32 x 3/16 type
5	14642	Nut, 1/4-20NC hex stainless steel
6	15148	Washer, lock 1/4 regular
7	137764	Load cell assembly 50/70K
8	117599	Screw, cap 1/4-20NC x 1-1/2
9	145982	Screw button head 1/4-20 x 1 stainless steel
10	148213	Collar top 50/100K
11	146322	Filter millipore
12	150525	Mid-section machined
13	149958	Collar bottom 20-50K
14	145990	Screw slotted head 1/4-20 x 5/8 stainless steel
15	149957	Boot lower 20-70K
	135035	50K hook, swivel
	142179	50K latch
	135036	70K hook
	142180	70K latch
	151356	50K shackle 25 ton
	146335	70K shackle 40 ton

Table 2-6. MSI-6360 Mid-Section Assembly 50,000 and 70,000 lb Components

2.6.4 MSI-6360 Back Assembly




Figure 2-10. MSI-6360 Back Assembly

Item	Part No.	Description	Qty.
1	193557	Casting, rear cover, 12V, machined	1
2	149719	Fastener battery door	2
3	149718	Plate aluminum battery	4
4	213050	Screw, button head 8-32 × 5/16 stainless steel (T15) torx drive	16
5	147825	Plug banana jack	2
6	81280	Washer, lock no 6 type A	2
7	146603	Screw, pan head 6-32 × 3/8 Phillips stainless steel	2
8	146627	Nut, hex 6-32 nyloc stainless steel	1
9	214737	Cable assembly power 12 in	1
10	204844	Casting rear 12V SLA machined	1
11	145934	Latch camloc	2
12	149723	O-ring assembly batter well casting	1
13	146661	Nut, hex 5/16-18 jam stainless stell	1
14	169440	Connector block 12V battery casting intrinsically safe	1
15	55124	Washer, flat #6 cres	1
16	127036	Screw, 6-32 × 3/4 Phillips pan head 18-8 stainless steel	1
17	146640	Pad poron 2.0 × 1.0	1

Table 2-7. MSI-6360 Back Assembly Components

3.0 ScaleCore Connect Installation

ScaleCore Connect is used to program and configure the MSI-6360 Trans-Weigh using ScaleCore software. It allows complete backup, copy and restore of a scale configuration including calibration. Install the ScaleCore Connect Software onto a computer for setting up multiple products.

System Requirements

Windows® Operating System

Display: 800 x 600 or greater

Built-in serial port or USB to serial port adapter

FTDI chip set required (Tripp-Lite USB/Serial Adapter [PN 153603] recommended)

JAVA JRE 1.7 or Newer

To download and install JAVA JRE: <https://java.com/en/download/manual.jsp>

3.1 Install Program

To install:

1. Open the Rice Lake website and navigate to the [ScaleCore Connect](#) product page and scroll to the Software tab under Resources/Downloads.
2. Download the ScaleCore Connect software to the computer.
3. Extract the zip file to generate the ScaleCore Connect folder.
4. Open the folder and double click on **ScaleCoreConnect_XX-XX.exe**.



NOTE: Folder structure must be kept intact. Application will not work without the companion folder.

5. A security warning may display, press **Run** to continue.
6. ScaleCore Connect will automatically connect to any connected ScaleCore device. If a device was not connected to the PC before launching the application, connect device and press **Auto Connect** to establish the connection for configuration/setup of the device.



NOTE: Make sure USB/serial drivers are installed and up-to-date if the scale does not appear.





Figure 3-1. ScaleCore Connect Main Display

4.0 Configuration/Setup

This section is a guide for setting up the MSI-6360 by the ScaleCore Connect program.

Prior to making changes to a product profile it is recommended to save a backup. See [Section 4.11.2 on page 43](#).

At anytime during set up, press  to return to previous page without saving.

4.1 Connect a Device



ScaleCore Connect supports interfacing to the MSI-6360 from RS-232 connection. See [Section 2.3.1 on page 13](#) for RS-232 connection information.

4.2 Connected Devices

Displays currently connected devices. Devices must be connected and powered on to be visible.



Figure 4-1. Connected Devices

1. Press . Connected devices display.
2. Select the device to configure and press .

4.3 Device Profiles

A device profile contains all settings of a device, such as load cell calibration, communication settings, setpoints, relay, print string, etc. See [Section 4.11.2 on page 43](#) and [Section 4.11.3 on page 43](#) for more information on device profiles.




Figure 4-2. Device Profiles

4.4 Configuration

The configuration menu displays parameters related to the configuration of scale power and communication.

4.4.1 Auto Connect

Auto Connect triggers a new search for available devices.




Figure 4-3. Configuration Display

4.4.2 Product Info

Product info displays device identification information.



NOTE: Do not change these settings without consulting Rice Lake Weighing Systems or a local dealer.





Figure 4-4. Product Info Settings

1. Select **Configuration**, then **Product Info**.
2. Make any necessary changes in the following parameters:

Parameter	Description	
Device ID	Number given to the current product (selections: 1–255)	
User Defined Model	ATP 3 C Cells 6 D Cells 6V Battery 12V Battery 110V AC CHI 107 CHI 234 AC Power DC Power	Power source of current product
User Model Name	Enter a name for the product	
PCB Serial Number	Serial number for the PCB board, read only	
Product Serial Number	Serial number of displayed product, read only	
Software Version	Displays the version of software currently installed, read only	

Table 4-1. Product Info Settings Parameters

3. Press  to save. New settings will not take affect until power is cycled on the product.

4.4.3 RF Configuration

Radio Frequency (RF) configuration displays RF setup information.

Figure 4-5. RF Configuration

1. Select **Configuration**, then **RF**.
2. Make any necessary changes in the following parameters:

Parameter	Description
Status	Select Enabled (default) or Disabled
Channel	Select a channel from 12–23
Network ID	Enter a number from 0–65534 for an ID
Device Type	Select XBee or Other (for all other cards installed)
Power Level	Select a level from 0–4
Always On	Select Enabled (default) or Disabled

Table 4-2. RF Configuration Parameters



NOTE: Only set **Always On** to **Enabled** when using **Rugged Remote**. Having this parameter set to **Enabled** will drain the battery even when the scale is off. Disconnect the battery when not in use.

3. Press **Commit** to save. New settings will not take effect until power is cycled on the product.



NOTE: **Channel**, **Network ID**, and **Power Level** are only used with the **802.15.4** radio option. If the device does not have a secondary **802.15.4** radio option installed, these settings will have no effect on the scale.

Ensure a relatively clear transmission path exists between the devices to be connected. Radio signals travel primarily by line of sight (LOS), obstructions between stations may degrade the system performance.

The optional second xBee radio can only be configured at the factory. It can not be configured through the front panel or ScaleCore Connect



IMPORTANT: Changing the RF status will result in loss of connection to scale. Connection will need to be reconfigured using the front panel or the serial port.

4.5 Load Cells

The Load Cells menu displays parameters related to the load cell configuration.

4.5.1 General

The General menu displays parameters for each load cell associated with the connected device.




Figure 4-6. Load Cell General Settings

1. Select **Load Cells**, then **General**.
2. Make any necessary changes in the following parameters:

Parameter	Description
Load Cell Number	Select a load cell number 1–5
Load Cell Enabled	Select Enabled (default) or Disabled
Filter	Set filtering to Off, Low, Medium or High
Load Cell Name	Enter a name to identify the load cell
Motion Enabled	Select Enabled or Disabled (default)
Motion Detect Period in 50 mSec Tick	Select a number from 1-255
Motion Band in D, 0=0.5D, 1=1D etc.	Select a number from 1-255
Pending Time in 50 mSec Tick	Select a number from 1-255
Viewing Capacity	Enter Capacity
Viewing Country	Select 0.0001-5000
Under Load Threshold	Select a number from -100 to 90

Table 4-3. Load Cell General Settings Parameters

3. Press  to save.

4.5.2 Zero, Standard

The Zero, Standard display defines the regulatory standard of a device. Additionally, all of the parameters for zeroing the scale can be adjusted in this display. Parameters vary by selected standard mode.

The screenshot shows the 'Load Cell Zero Settings' screen for an MSI6360 scale. The interface includes a navigation menu on the left with options like 'Connected Devices', 'Device Profiles', 'Configuration', 'Load Cells', 'General', 'Zero, Standard', 'Total', 'Math', 'Maintenance', 'Cal Records', 'Calibration', 'Inputs / Outputs', and 'Monitors'. The main area contains several dropdown menus for configuration: 'Standard Mode' (set to 'Industry'), 'AZM' (set to 'Enabled'), 'Motion Detection' (set to 'Disabled'), 'Zero On Power Up' (set to 'Disabled'), 'Load Cell Number' (set to '1'), 'AZM Range in D' (set to '1'), 'AZM Period in 50 milli Sec' (set to '40'), 'Zero High Band' (set to '100'), 'Zero Low Band' (set to '20'), 'Power Up Zero Hi Band' (set to '20'), and 'Power Up Zero Low Band' (set to '20'). A red 'Commit' button is located at the bottom center. A note states: 'The following are in Percentage of Capacity. For Example, 20, means 20% of Capacity.'

Figure 4-7. Load Cell Zero Settings

1. Select **Load Cells**, then **Zero, Standard**.
2. Enter the following parameters for the current product::

Parameter	Description
Standard Mode	Select Industry, NTEP, OIML or One Unit
AZM	Select Disabled or Enabled
Motion Detection	Select Disabled or Enabled
Zero On Power Up	Select Disabled or Enabled
Load Cell Number	Select the load cell number from 1-4
AZM Range in D	Select a number from the AZM range (0-255)
AZM Period in 50 milli Sec	Select a number from the AZM period (20-255)
Zero High Band	Select the zero high band number from 1-100 (in percentage of capacity)
Zero Low Band	Select the zero low band number from 1-20 (in percentage of capacity)
Power Up Zero Hi Band	Select the power up zero hi band number from 1-25 (in percentage of capacity)
Power Up Zero Low Band	Select the power up zero low band number from 1-20 (in percentage of capacity)

Table 4-4. Load Cell General Settings Parameters

3. Press **Commit** to save.

4.5.3 Total

The Total display defines Total mode of a load cell. Total mode allows for consecutive weighments to be summed in a combined total. All of the parameters that control the timing and thresholds of the chosen Total mode can be adjusted in this display.




Figure 4-8. Load Cell Total Settings

1. Select **Load Cells**, then **Total**.
2. Make any necessary changes in the following parameters:

Parameter	Description									
Load Cell Number	Select the load cell number from 1–5									
Total Mode	<table border="1"> <tr> <td>Disabled</td> <td rowspan="6">Select the type of total mode for the connected product</td> </tr> <tr> <td>Auto Load</td> </tr> <tr> <td>Auto Normal</td> </tr> <tr> <td>Auto Peak</td> </tr> <tr> <td>Load Drop</td> </tr> <tr> <td>On Accept</td> </tr> <tr> <td>On Command</td> <td></td> </tr> </table>	Disabled	Select the type of total mode for the connected product	Auto Load	Auto Normal	Auto Peak	Load Drop	On Accept	On Command	
Disabled	Select the type of total mode for the connected product									
Auto Load										
Auto Normal										
Auto Peak										
Load Drop										
On Accept										
On Command										
Minimum Stable Time	Select the minimum stable time from 0–255 (in 50 ms)									
Lower Bound Weight Accept	Enter the lower bound weight									
Upper Bound Weight Accept	Enter the upper bound weight									
Drop Threshold	Select the drop threshold number from 0–100 (in percentage of capacity)									
Rise Threshold	Select the rise threshold number from 0–100 (in percentage of capacity)									

Table 4-5. Load Cell Total Settings Parameters

3. Press **Commit** to save. New settings will not take affect until power is cycled on the product.

4.5.4 Math

The Math Channel Settings display configures multiple load cell sensors to combine into one output measurement. Math Channel settings transfer to the connected device. Once the device is disconnected from ScaleCore Connect, the device's math channel will use the Math Expression configuration to sum up to 3 sensors as the output measurement. This is useful if a load is being lifted from more than one point.




Figure 4-9. Math Channel Settings

1. Select **Load Cells**, then **Math**.
2. Make any necessary changes in the following parameters:

Parameter	Description
Enabled	Select Enabled or Disabled
Math Expression	Enter math expression

Table 4-6. Math Channel Settings Parameters

3. Press **Commit** to save.

4.5.5 Maintenance

See [Section 6.1 on page 47](#) for the advanced setup of the maintenance settings.



NOTE: Do not change these settings without consulting Rice Lake Weighing Systems or a local dealer.




Figure 4-10. Maintenance Settings

1. Select **Load Cells**, then **Maintenance**.

- Make any necessary changes in the following parameters:

Parameter	Description
Load Cell Number	Load cell number (read only)
Lift Count	Number of times the load cell has exceeded the Lift Threshold (read only)
Overload Count	Number of times the load cell has exceeded capacity (read only)
Load Cell Numbers	Select the sensor ID from 1-4
Lift Threshold	Select the lift threshold number from 0–100 (in percentage of capacity, 0=0.5%, 1=1%, 100=100%)
Drop Threshold	Select the drop threshold number from 0–100 (in percentage of capacity, 0=0.5%, 1=1%, 100=100%)

Table 4-7. Maintenance Settings Parameters

- Press **Commit** to save.

4.5.6 Calibration Records

The Calibration Records display maintains a record of the calibration of each load cell for maintenance and regulatory purposes.

- Select **Load Cells**, then **Cal Records**.
- Select **Load Cell Number** and the recorded calibration settings for selected load cell displays.




Figure 4-11. Calibration Records Settings

4.6 Inputs / Outputs

The Inputs / Outputs menu displays parameters related to input and output function of the scale.

4.6.1 Setpoints

Setpoints provide a trip point for load values.




Figure 4-12. Setpoint Configuration

1. Select **Inputs / Outputs**, then **Setpoints**.
2. Make any necessary changes in the following parameters:

Parameter	Description	
Setpoint Number	Select the setpoint number from 1–3	
Status	Select Disabled or Enabled	
Source Sensor ID	Select the source sensor ID number from 1–5	
Relay Output Mode	Select Coil or Latch	
Comparison Logic	Select Undefined, Greater Than or Less Than	
Comparison Value	Enter the comparison value	
Value Type	Net Gross Gross Total Total Count Lift Count	Select the value type parameter
Hysteresis in D	Select the hysteresis in D number from 0–99	

Table 4-8. Setpoints Configuration Parameters

3. Press **Commit** to save.

4.6.2 Stream Print String

Listeners

The Listeners feature controls the machine to machine communications interfaces.




Figure 4-13. Listener Settings

1. Select **Inputs / Outputs**, then **Stream Print String**.
2. Select the **Listeners** tab.
3. Make any necessary changes in the following parameters:

Parameter	Description
Listener Number	Select stream listener number from 0–2
Destination ID	Select the ID assigned to the stream listener from 0–255; 255 indicates broadcast ID, it is for every device that attached
Sensor ID	Select the sensor the listener will observe from 1–5
Stream Type	Select the type of this stream listener
Interval (50 ms)	Select interval value from 0–255 Example: 20 means 20x50 ms = 1 second.
Control Output Mode	Select the mode for the listener

Table 4-9. Listener Parameters

4. Press  to save.

Print String

The edit print string, allows the mode, interval and composite for a listener to be configured. The mode can be configured to print on command, on stable load, continuous, or it can be disabled. The print composite allows the combination of the configured print formatters to produce a great deal of information in a single print.




Figure 4-14. Print String Settings

1. Select **Inputs / Outputs**, then **Stream Print String**.
2. Select the **Print String** tab.
3. Make any necessary changes in the following parameters:

Parameter	Description
Listener Number	Select stream listener number from 0–2
Control Output Mode	Select the output mode for the print string; Disabled, Command, Stable Load, Continuous
Interval in Seconds	Select the interval period on continuous output from 0–255, 0 (fastest) up to 255 seconds
Composite Formatters	Add formatters from list; preview as needed; Clear to reset selected formatters

Table 4-10. Print String Parameters

4. Press  to save.

Format Editor

The format editor function allows customization of the formatted print information that a ScaleCore device can produce. Custom print formatters can be generated with the help of the custom interface within the format editor.




Figure 4-15. Format Editor

Use the buttons to create the string or type it into the formatter box. The maximum length for this print string is 18 characters.

NOTE: All characters are case sensitive.

Character	Definition	Explanation
R##	Right justify length of next field	R5 means next item maximum width is 5 characters with padding leading spaces if needed; R0 means variable width without justify; It is only valid for one next field; ## maximum value is 12.
L##	Left justify length of next field	L5 means next item maximum width is 5 characters with padding trailing spaces if needed; L0 means variable width without justify. It is only valid for one next field. ## maximum value is 12.
S##	Defines sensor for fields V, I, M, N and U	S05 means that fields V, I, M, N and U will output values from sensor 05; Once S## is specified, following V, I, M, N and U fields are referred to current S## until new S## is specified; ## maximum value is 15. NOTE: If sensor is not specified, default sensor is Sensor#0
T#	Defines data type	# represents the type of data that trailing characters will output: 0==GROSS, 1==NET, 2==TOTAL, 3==TARE, 4==ZERO, 5==PEAK, 6==ADC COUNT, 7==CURRENT MODE. 8 == Total count Example, T1 means following value field is for NET weight value; NOTE: If data type is not specified, default type is GROSS
V	Outputs real value	Output value is based on leading print string data type T# from sensor ID field S##;
I	Outputs integer value	Output precision is based on configured count-by d;
A	Outputs absolute value	See Table 4-11 on page 37
M	5-character string of specified data type	Output character field representing data type T#; character field is fixed at five characters with trailing padding spaces if needed; Example, T1 is NET mode; M field will print NET with two trailing blank characters T6 is ADC COUNT; M field will print ADC C with no trailing blank characters
m	First character of specified data type	Output character field representing data type T#; character field is fixed at one character; Example, T1 is NET mode; m field will print N T6 is ADC COUNT; m field will print A
N	Name of sensor	Output name of sensor S##; Name is defined by NOTE: Field can be controlled by R## and L##

Table 4-11. Parameter Print Characters

Character	Definition	Explanation
U	2-character string of current unit of specified sensor	Unit output is always two characters; kg=kilogram, lb=Pound, T =Metric Ton, TN=English Ton
u	First character of current unit of specified sensor	Unit output is always one character
P	Polarity of specified sensor	Output '-' if negative; Output blank space if positive
t	Status of specified sensor	Output M= in-motion, Z=COZ, O=overload or underload; Blank space outputs if none

Table 4-11. Parameter Print Characters (Continued)

Character	Formatting
_	Space character
r	Carriage return
n	New line feed
^	String quote (^ABC D^ outputs "ABC D")
s	Start of text (STX)

Table 4-12. Formatting Print Characters

Examples:

String: R7S0T0V_U_Mrn

*R7 - Right justify next output with 7 characters width**S0 - All values extracted from Sensor 0**T0 - All data extracted as GROSS mode**V - Output data value precision based on count-by**_ - Space**U - Output 2-character string unit**_ - Space**M - Output 5-character data type string**r - carriage return**n - line feed*Output: **12345 lb GROSS** <cr LF>

String: S0T0MR7V_Urn

Output: **GROSS 12345 lb** <cr LF>

String: S0R4NT0R7V_U_Mrn

*Sensor name is "WestSide." Print string only outputs "West" because R4 limits the N output to 4 characters.*Output: **West 12345 lb GROSS** <cr LF>

String: ^Crane:1 ^S0T0R7V_U_Mrn

*1st field is a string "Crane:1".*Output: **"Crane:1" 12345 lb GROSS** <cr LF>

Standard Rice Lake Serial Scale String: sPR7S0T7Aumtrn

4.7 Monitors

Monitor mode displays a terminal monitor view or a meter monitor view.



Figure 4-16. Monitors Menu

Terminal

Terminal monitor view displays a blank screen that returns print string data that is useful when modifying the Stream Print String settings.



NOTE: Terminal monitor should only be used for troubleshooting by qualified Rice Lake Weighing Systems technicians.

Meter

Meter monitor view displays a virtual indicator weigh mode for the connected scale.




Figure 4-17. Meter Monitor View

4.8 File Menu

The **File Menu** is used to open an existing profile or exit the program.





Figure 4-18. File Menu Selections

4.8.1 Open Profile

Profiles can be exported and saved, then imported into a different product. To open a previously saved profile:

1. Select **File**, then **Open Profile**.
2. Navigate to where the profile is stored.
3. Select the file and press . A valid profile file then displays on the left panel, under Device Profile ([Section 4.3 on page 26](#)).
4. Select the intended profile from the left panel. Application displays all information as if it was that device.



NOTE: The profiles that show up grayed out are read only.

To clone the open profile see [Clone Profile to Device on page 43](#).

4.8.2 Exit

To close ScaleCore Connect application.

4.9 Administration Menu

Administration allows the setup of User Privileges. Selections are Normal User Mode and Administrator Mode. The current password must be available to complete this setup.




Figure 4-19. Administration Menu Selection

1. Select **Administration**, then **User Privileges**. User Privileges window displays.





Figure 4-20. User Privileges

2. Select either Normal User Mode or Administrator Mode.
3. Enter the password and press .

4.10 Communications Menu

Communications allows the selection and configuration of the stream ports.




Figure 4-21. Communications Menu Selections

4.10.1 Select Stream Port

To select the stream port:

1. Select **Communications**, then **Select Stream Port**.
2. Select the port to be used from the drop down.




Figure 4-22. Select Stream Port

3. Press **OK** to save and return to main page.

4.10.2 Configure Stream Port

To configure communications stream ports:

1. Select **Communications**, then **Configure**.
2. Select the port to be configured and press **Configure Stream**.




Figure 4-23. Communication Setup

3. Set the option:
 - **Baud Rate** – Rate at which information is transferred through the port
Selections: 9600 (default), 19200, 38200, 57600, 115200
 - **Hand Shake** – Signals transmitted back and forth over a communications network in order to establish a valid connection between two stations.
Example: A hardware handshake uses dedicated wires like request-to-send (RTS) and clear-to-send (CTS) lines in an RS-232 serial transmission
Selections: None, RTS/CTS, XON/XOFF (default)

- **Parity** – error detection technique that tests the integrity of digital data in the computer
Selections: None (default), ODD, EVEN
 - **Data Bits** – number of bits used to represent one character of data
Selections: 7 data bits, 8 data bits (default)
 - **Stop Bits** – indicates end of a character or of the whole transmission
Selections: 1 stop bit (default), 2 stop bits
4. Press to save and return to Communication Setup.
 5. Press to return to main page.

4.11 Program Menu

Program is used to program the application code, acquire a profile from a connected device or clone a profile from another connected product.




Figure 4-24. Program Menu

4.11.1 Program App Code

Program App Code is used to update the ScaleCore firmware on a connected device.



IMPORTANT: Program App Code should only be accessed by a trained dealer or under the direction of the Rice Lake Weighing Systems Customer Service.




Figure 4-25. Program App Code

1. Select **Program App Code** from the **Program** drop down menu.
2. Press , application switches to the terminal mode screen and displays the bootloader menu.
 - * If the terminal mode screen displays strange characters, change the baud rate to 38400. See [Configure Stream Port on page 41](#) to change the baud rate. Once the baud rate has been changed, make sure cursor is in the terminal screen and press the “R” key to refresh the terminal screen. The bootloader menu will display.
 - * If the unit shuts off after pressing the Go To Bootloader button, press the power key to restart the unit and the bootloader menu will display on the terminal screen.
3. Press , a file dialog box pops-up.
4. Select an app code file from the file dialog box, press , app code file is sent to the target device.

4.11.2 Acquire Profile from Device

Acquire profile from devices enables the user to save a configuration profile to the PC so that it can be cloned to other devices.



IMPORTANT: *Acquire Profile from Device should only be performed by a trained dealer or under the direction of the Rice Lake Weighing Systems Customer Service. This action could potentially remove all configuration, calibration and functionality if performed incorrectly*



NOTE: *Acquire Profile from Device is not 100% reliable if ScaleCore Connect is displaying the Meter Monitor. Ensure that ScaleCore Connect displays any configuration screen other than the Meter Monitor. (See [Section 4.7 on page 39](#))*




Figure 4-26. Acquire Profile

1. Select **Acquire Profile from Device** from the **Program** drop down menu.
2. When prompted save the file to desired location.

4.11.3 Clone Profile to Device

Clone profile to device enables the user to duplicate a saved configuration to multiple devices so that all of the devices share the same configuration without the need to set each parameter individually.



IMPORTANT: *Clone Profile to Device should only be performed by a trained dealer or under the direction of the Rice Lake Weighing Systems Customer Service. This action could potentially remove all configuration, calibration and functionality if performed incorrectly*



NOTE: *Clone Profile to Device is not 100% reliable if ScaleCore Connect is in the Meter Monitor display. Ensure that ScaleCore Connect displays Terminal Monitor or another configuration screen. (See [Section 4.7 on page 39](#))*





Figure 4-27. Clone Profile

1. Select **Clone Profile to Device** from the **Program** drop down menu.
2. Select the Profiles to clone to the Target Devices.
3. Press .
4. Once profile is successfully cloned to the target device, the target device is configured based on the cloned profile info.

5.0 Calibration

The MSI-6360 must be calibrated remotely. Most commonly it is calibrated using a connected remote display. Reference the technical manual for the connected model for calibration instructions. The MSI-6360 can also be calibrated with ScaleCore connect. This section includes instructions for ScaleCore Connect calibration instructions.

The MSI-6360 is calibrated using standard weights. It is required that the weight used is at least 10% of full capacity in order to achieve rated accuracy. For example, use at least a 500 kg test weight to calibrate a 5000 kg capacity scale. Although a single span point is usually adequate for rated accuracy, the MSI-6360 supports Multi-Point calibration with up to four span points plus zero.

When adequate test weights are not available, the MSI-6360 can be calibrated using a calculated constant calibration which is referred to as C-Cal. To use C-Cal, a previously generated C-Cal number must be known.

There are three kinds of calibration:

- **Standard Calibration** – Used for maintenance and routine calibration.
- **Initial Calibration** – Used to set up both the capacity and resolution (d) of the scale. It differs from Standard Calibration only in the initial steps. The initial calibration is performed after a calibration reset which completely erases the calibration and setup memory.
- **C-Cal** – Last calculated C-Cal values is known, the MSI-6360 can be calibrated without weights.

5.1 Calibration Switch Access

Use the following steps to access the calibration switch on the MSI-6360 if calibrating the unit using either the standard calibration or the C-Cal calibration.

1. Remove the hex seal screw from the MSI-6360.




Figure 5-1. Calibration Switch Seal Screw

2. Using a small screwdriver, press the Cal switch located behind the hex seal screw. $\square RL$ displays.

5.2 Calibration

The available methods of calibration are:

- **Full Cal Load Cell** – enter scale unit, capacity and country
- **Re-Cal Load Cell** – uses current scale unit, capacity and country
- **Full C-Cal Load Cell** – enter scale unit, capacity and country; allows a calibration using a Constant Calibration (C-Cal) number without the requirement of test weights
- **Re-C-Cal Load Cell** – use current scale unit, capacity and country; allows a calibration using a C-Cal number without the requirement of test weights
- **Multi Load Cell** – use when calibrating multiple load cells, perform a Full Calibration on each load cell to be calibrated



NOTE: Refer to the connected remote display Technical Manual for remote display calibration instructions.

5.2.1 Full Calibration

1. Select **Calibration**, then **Full Cal Load Cell**.










Figure 5-2. Select Load Cell ID





2. Select the **Load Cell ID** number from 1-4.
3. Press .
4. Set the **Unit** and **Capacity** parameters.
5. Press .



NOTE: Press  to end current calibration and restore the previous calibration.

6. Select the desired **Country** parameter, then press .
7. Ensure there is no weight on the load cell, then press .
8. Enter the test weight value, then press .
9. Press . The constant cal number is displayed, document the number for use later if needed.
10. Repeat steps above for each load cell to be calibrated.

5.2.2 Re-Calibration

1. Select **Calibration**, then **Re-Cal Load Cell**.
2. Select the Load Cell ID number from 1-4.
3. Press .
4. Ensure there is no weight on the load cell, then press .
5. Enter the test weight value, then press .
6. Press . The constant calibration number is displayed, document the number for use later if needed.
7. Repeat steps above for each load cell to be re-calibrated.

5.2.3 Full Constant Calibration

1. Select **Calibration**, then **Full C-Cal Load Cell**.
2. Press **Set Load Cell ID**.
3. Set the **Unit** and **Capacity** parameters.
4. Press **Set Unit And Capacity**.
5. Select the desired **Country** parameter, then press **Set Selected Country**.
6. Ensure there is no weight on the load cell, then press **Unload Test Weight**.
7. Enter the constant calibration number, then press **Set Constant Cal #**.

5.2.4 Constant Re-Calibration

1. Select **Calibration**, then **Re-C-Cal Load Cell**.
2. Press **Set Load Cell ID**.
3. Ensure there is no weight on the load cell, then press **Unload Test Weight**.
4. Enter the constant calibration number, then press **Set Constant Cal #**.

6.0 Troubleshooting and Maintenance

6.1 Troubleshooting

Problem	Possible Cause	Solution
The status LED does not light when the POWER button is toggled	Discharged battery	Recharge the battery; Allow at least four hours charge
	Defective battery	Replace the battery
	Corroded battery or battery contacts	Clean the battery contacts
	Defective switch or circuit board	Requires authorized service
The Status LED does not function properly, the front panel button does not function normally or the scale will not turn off	Improperly updated software	Reinstall the software
	Faulty circuit board	Requires authorized service
	Loose connectors	Requires authorized service
The scale does not respond to weight changes	Out of calibration	Calibrate the unit
	Faulty load cell	Replace the load cell
	Load cell connector	Check the connector and wires
The remote display over ranges below 100% capacity	Tared weight is added to load to determine overload point	Return to gross weight mode
	Zero requires adjustment	Rezero the scale
	Too much weight has been zeroed	Rezero the scale
The remote display drifts	AZM (Auto0) is turned off	Turn AZM on
	Rapid temperature changes such as moving the scale from indoors to outdoors	Wait until the scale temperature has stabilized
The displayed weight shows a large error	Scale not zeroed before load is lifted	Zero the scale with no load attached
	lb/kg units causing confusion	Select the proper units
	Requires recalibration	Recalibrate the unit
The remote display reading is not stable	Excessive vibration in crane system	Increase filtering or increase 'd' in Cal
	Excessive side loading	Improve load train symmetry
	Load cell faulty	Check the load cell connections
The remote display toggles between "Error" and "Load"	Weight exceeds capacity	Reduce weight immediately
	Faulty load cell or wiring	Check load cell and load cell wiring
The remote display toggles between "Error" and "UnLd"	Weight in below the zero range	If the scale is in compression, remove the source
	Calibration faulty	Recalibrate
	Faulty load cell or wiring	Check the load cell connections
The remote display toggles between "Error" and "A2DLo"	A/D is saturated negative	Check the load cell and load cell wiring
The remote display toggles between "Error" and "buttn"	A key is stuck or is being held down	Check switches for damage
		Ensure that a remote is not transmitting continuously
Remote display shows "NO RF"	Scale is not in range, incorrect radio configuration	Move remote display closer to scale
	Interference or blocked signal	Ensure line-of-sight between remote display and scale
	Incorrect radio configuration	Check radio configuration; See Section 4.4.3 on page 28
RF Remote does not work	Units are not paired	See Section 4.4.3 on page 28
Some RF remote keys do not work but the ACK light blinks	The keys were not enabled during the setup process	Enable the keys by running the transmitter and receiver address procedures
Status LED is blinking	The battery is low	Recharge the battery

Table 6-1. Troubleshooting

Problem	Possible Cause	Solution
Unit turns on, then immediately turns off	The battery is low	Recharge the battery
Weight will not zero	The system not stable	The stable annunciator must turn on for Zero to function; Increase the filtering for more stability
	Zero is out of range	Increase the filtering for more stability Legal-for-Trade units have limited zero range; Reduce the weight or use Tare instead
The weight will not Zero, Tare or Total	The system is not stable	Wait for Stable annunciator to turn on, or if in a mechanically noisy crane, increase the filtering or increase the size of the scale increment "d". It is also possible to increase the motion window; Contact MSI if you have a problem getting the MSI-6360 to zero, tare, or total due to stability issues
Remote display setpoint lights blink	Setpoint is enabled and the trigger point has been reached	Disable set points if they are not needed
Manual total does not work	A Function key is not set to "Total"	Set up Func1 or Func2 for "Total"
	The weight must be stable	Increase filtering for more stability
Auto Total does not work	The weight must be stable	Wait for the stable annunciator to turn on, or Increase filtering for more stability
	Weight thresholds not reached	Must exceed 1% of capacity for autototal to work; Must drop below 0.5% of capacity for additional weighments to register

Table 6-1. Troubleshooting (Continued)

6.2 Radio Compliance

All radio options meet FCC and international radio compliance per the certification information listed in this section.

These modules may have additional international certifications that are not listed in this section.

Please contact Rice Lake Weighing Systems if you require operation in a jurisdiction that is not listed.

6.2.1 802.15.4 (XBee 3 and XBee 3-PRO)

FCC Statement

Contains FCC ID: MCQ-XBEE3

International Certifications

Canada: Radio Certificate Number: IC 1846A-XBEE3

Australia: RCM

Brazil: ANATEL 06329-18-01209

EU (XBee 3 only): Yes, when used with CE approved products

Japan (XBee 3 only): R210-119309

Mexico: IFETEL (IFT) RCPDIXB19-1820

South Korea (XBee 3 only): R-C DIG-XBEE3

6.2.2 802.15.4 (XBee 2SC)

FCC Statement

Contains FCC ID: MCQ-S2CTH

International Certifications

Canada: Radio Certificate Number: IC 1846A-S2CTH

Australia: RCM

Brazil: ANATEL 0616-15-1209

EU: Yes, when used with CE approved products

Japan: R210-105563

Mexico: IFETEL (IFT) RCPDIS219-1821-A1

South Korea: MSIP-CRM-DIG-XBee-S2C-TH

6.2.3 Wi-Fi

FCC Statement

Contains FCC ID: T9J-RN171

International Certifications

Canada: Radio Certificate Number: IC 6514A-RN171

Korea: Radio Certificate Number: KCC-CRI-029-RN-171

Europe: The product is compliant with the following standards and/or other normative documents:

- EN 300 328 : V1.8.1 (2012)

This product is compliant with the following standards and/or other normative documents:

Safety (article 3.1A) EN 60950-1:2006+A11:2009+A1:2010+A12:2011

EMC (article 3.1b) EN 301 489-1 : V1.9.2 (2011) In accordance with the specific requirements of ETSI EN 301 489-17: V2.2.1 (2012)

6.2.4 FHSS (Frequency Hopper Spread Spectrum)

FCC Statement


Contains FCC ID: HSW-DNT24

International Certifications

Canada: Radio Certificate Number: IC 4492A-DNT24

ETSI Certified

6.3 MSI-6360 Trans-Weigh Dimensions



Capacity	Resolution**	A*	B*	C*	D*	E*	F	Hook	Eye Nut or Shackle	Safety Factor	Shipping Wt
500 lb	0.2 lb	18.2 in	2.25 in	3.06 in	1.44 in	1.41 in	-	5 ton alloy swivel	CR # 7 eyenut	>5	51 lb
250 kg	0.1 kg	463 mm	57.1 mm	77.7 mm	37.0 mm	36.0 mm	-	5 ton alloy swivel	CR # 7 eyenut	>5	22 kg
2,000 lb	1 lb	18.2 in	2.25 in	3.06 in	1.44 in	1.41 in	-	5 ton alloy swivel	CR # 7 eyenut	>5	51 lb
1,000 kg	0.5 kg	463 mm	57.1 mm	77.7 mm	37.0 mm	36.0 mm	-	5 ton alloy swivel	CR # 7 eyenut	>5	22 kg
5,000 lb	1 lb	20.4 in	2.50 in	3.50 in	1.81 in	1.69 in	-	7 ton alloy swivel	CR # 8 eyenut	>5	60 lb
2,500 kg	0.5 kg	519 mm	64.0 mm	89.0 mm	46.0 mm	42.9 mm	-	7 ton alloy swivel	CR # 8 eyenut	>5	26 kg
10,000 lb	2 lb	20.4 in	2.50 in	3.50 in	1.81 in	1.69 in	-	7 ton alloy swivel	CR # 8 eyenut	>5	60 lb
5,000 kg	1 kg	519 mm	64.0 mm	89.0 mm	46.0 mm	42.9 mm	-	7 ton alloy swivel	CR # 8 eyenut	>5	26 kg
20,000 lb	5 lb	28.4 in	4.00 in	6.25 in	2.62 in	2.41 in	-	15 ton alloy swivel	CR # 11 eyenut	>7	103lb
10,000 kg	2 kg	722 mm	101.6 mm	159 mm	66.5 mm	61.2 mm	-	15 ton alloy swivel	CR # 11 eyenut	>6.5	45 kg
30,000 lb	10 lb	29.9 in	4.00 in	6.25 in	3.00 in	3.19 in	-	22 ton alloy swivel	CR # 11 eyenut	>5	123lb
15,000 kg	5 kg	760 mm	101.6 mm	159 mm	76.2 mm	81.0 mm	-	22 ton alloy swivel	CR # 11 eyenut	>5	53 kg
50,000 lb	10 lb	40.9 in	5.00 in	6.00 in	3.62 in	3.63 in	15.0 in	30 ton alloy swivel	CR 25ton shackle# 2130	>5	233lb
25,000 kg	5 kg	1039 mm	127 mm	152 mm	92.0 mm	92.0 mm	381 mm	30 ton alloy swivel	CR 25ton shackle# 2130	4.9	105kg
70,000 lb	20 lb	43.1 in	5.00 in	6.00 in	4.56 in	3.75 in	15.0 in	37 ton alloy swivel	CR 40ton alloy shackle # 2140	4.75	268lb
35,000 kg	10 kg	1095 mm	127	152 mm	116 mm	95.0 mm	381 mm	37 ton alloy swivel	CR 40ton alloy shackle # 2140	4.3	120kg
100,000 lb	20 lb	52.0 in	5.75 in	6.65 in	5.06 in	4.25 in	16.25 in	45 ton alloy swivel	CR 55ton alloy shackle # 2140	4.5	418lb
50,000 kg	10 kg	1322 mm	146 mm	169 mm	129 mm	108 mm	413 mm	45 ton alloy swivel	CR 55ton alloy shackle # 2140	4	188kg
								60 ton alloy swivel	CR 55ton alloy shackle # 2140	5	508lb
								Alternate Hooks for 100,000 lb	CR 55ton alloy shackle # 2140	4.5	230kg
								75 ton alloy swivel	CR 55ton alloy shackle # 2140	5	628lb
									CR 55ton alloy shackle # 2140	4.5	285kg

CR = Crosby or equivalent.

* These dimensions also apply to 50/70/100000 lb. units with hook and shackle.

** Resolution subject to change for NIST and OIML approved units.

Figure 6-1. MSI-6360 Product Dimensions

7.0 Specifications

Accuracy

± (0.1% +1 d) of applied load

Resolution

3,000 to 5,000 d standard (up to 10,000 d available)

Enclosure

NEMA Type 4, IP66 marine grade 356 alloy cast aluminum

Lifting Eye, Shackle and Hook

Crosby® or equal with 360° thrust-bearing swivel hook

Design Overload

200% Safe / 500% Ultimate (except where noted)

Functions

On/Off

Displayable Units

Pounds or kilograms selectable

Power

12 volt rechargeable battery, 115/230 VAC battery charger included

Operating Time

Up to 85 hours between charging with typical use

Operating Temperature

Legal-For-Trade: 14°F to 104°F (-10°C to 40°C)

Industrial: -40°F to 176°F (-40°C to 80°C)

Calibration

Digital via MSI ScaleCore remote display

Radio Link Effective Range

Typically 100 to 300 ft line of sight

Radio Link

802.15.4 at 2.4 GHz

Warranty

One-year limited warranty

Approvals



CoC Number: 19-122

500 lb to 70,000 lb



© Rice Lake Weighing Systems Content subject to change without notice.

230 W. Coleman St. • Rice Lake, WI 54868 • USA USA: 800-472-6703 • International: +1-715-234-9171