


SURVIVOR[®] RL1700 HE

Weigh Module Kit

Installation Manual



May 8, 2020

RICE LAKE[®]
WEIGHING SYSTEMS

PN 33318 Rev C

An ISO 9001 registered company
© Rice Lake Weighing Systems. All rights reserved.

Rice Lake Weighing Systems® is a registered trademark of
Rice Lake Weighing Systems.

All other brand or product names within this publication are trademarks or registered
trademarks of their respective companies.

All information contained within this publication is, to the best of our knowledge, complete and
accurate at the time of publication. Rice Lake Weighing Systems reserves the right to make
changes to the technology, features, specifications and design of the equipment without notice.

The most current version of this publication, software, firmware and all other product updates
can be found on our website:

www.ricelake.com

Contents

1.0	Introduction	1
1.1	Safety.....	2
2.0	Mechanical Installation	3
2.1	Compression Weighing Assembly Installation Guidelines	3
2.2	Installing the RL1700 HE Module	4
3.0	Load Cell Wiring.....	7
4.0	Junction Box Connections, Adjustments & Calibration.....	8
5.0	Troubleshooting.....	9
6.0	Maintenance and Replacement Parts.....	10




Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at www.ricelake.com/training or obtained by calling 715-234-9171 and asking for the training department.




Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit www.ricelake.com/webinars.

1.0 Introduction

The SURVIVOR® RL1700 HE Weigh Module Kit is ideally suited for light to medium capacity micro-ingredient batching and mixing in a variety of hostile environments, especially where moisture is present. The load cell is stainless steel and hermetically sealed with an IP rating of IP68 to provide superior corrosion, moisture ingress, and mechanical protection. The RL9018SS and RLHTO load cells are each waterproof guaranteed and OIML C3 certified (20kg-5,000kg) to offer the ultimate in durability and accuracy in any environment.




An important feature of the RL1700 HE is that the load may be checked in one of two directions. This allows positioning in one of two orientations for proper checking.



Integral jacking/shipping bolts offer a means to remove the load from the load cell for quick removal and replacement of a load cell and worry-free transport. The load introduction mechanism also isolates the load cell from side loads, overloads, and underloads. For reliability and accuracy, the RL1700 HE is the perfect mounting assembly for light capacity weighing.

The RL1700 HE modules are available from 5-250kg (11-550lb) capacities using RL9018SS cantilever beam load cells. In capacities from 500-5,000kg (1,100-11,000lb), the units use RLHTO single-ended shear-beam load cells.

The installation should be planned by a qualified structural engineer. Each installation is unique, and this manual is meant to serve only as a general guideline for installation.



Manuals and additional resources are available on the Rice Lake Weighing Systems website at www.ricelake.com

Warranty information can be found on the website at www.ricelake.com/warranties

1.1 Safety

Safety Signal Definitions:

**DANGER**

Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. Includes hazards that are exposed when guards are removed.

**WARNING**

Indicates a potentially hazardous situation that, if not avoided could result in serious injury or death. Includes hazards that are exposed when guards are removed.

**CAUTION**

Indicates a potentially hazardous situation that, if not avoided, could result in minor or moderate injury.

**IMPORTANT**

Indicates information about procedures that, if not observed, could result in damage to equipment or corruption to and loss of data.

General Safety



Do not operate or work on this equipment unless this manual has been read and all instructions are understood. Contact any Rice Lake Weighing Systems dealer for replacement manuals.

**WARNING**

Failure to heed may result in serious injury or death.

The installation should be planned by a qualified structural engineer. Each installation is unique, and this manual is meant to serve only as a general guideline for installation.

DO NOT use for purposes other than weight measurement.

DO NOT use any load-bearing component that is worn beyond 5% of the original dimension.

DO NOT use this product if any of the components are cracked.

DO NOT exceed the rated load limit of the unit.


DO NOT make alterations or modifications to the unit.

Contact Rice Lake Weighing Systems for replacement manuals. Proper care is your responsibility.

2.0 Mechanical Installation

2.1 Compression Weighing Assembly Installation Guidelines

1. The mounting surface for the base plate and top plate must be level. After installation, the top and bottom plates must be level within $\pm 0.5^\circ$. If the mounting surfaces are not level, then shims and/or grout may be used to level the mount.
If possible, check that the mount is level when the vessel is fully loaded because excessive deflections in legs and supporting structures may cause additional side forces that affect accuracy. Deflection of the mounts top or base plate due to loading should not exceed $\pm 0.5^\circ$. Reinforcement of legs or support structure may be necessary. Vessels with long legs should have cross bracing applied between adjacent legs to keep them from spreading under loads.
2. Compression mounting systems use 3, 4, or more mounts. More than eight mount systems should be avoided as even weight distribution becomes extremely difficult to achieve. The load on each mount assembly should vary by no more than 20%. During installation, add shims where necessary to achieve correct load distribution.
3. If the actual load cells are used during installation of the weighing assembly, extreme care must be taken to prevent overload damage. A tank or hopper weighing several tons can exert huge forces when dropped only a fraction of an inch. The RL1700 HE series weigh modules incorporate a unique jacking bolt assembly that should be used to remove the load from the cells during installation.
4. It is crucial that all piping or conduit be horizontal and flexible. If flexible piping is not used, make sure the distance from the vessel to the first pipe support is 20-30 times the pipe diameter. For details, see our Weigh Modules & Vessel Weighing Systems manual, PN 43918. In smaller, lower capacity tanks and hoppers, isolating the resultant forces becomes extremely critical.
5. Load cells should not be installed in the mounts until all welding is completed. The heat generated by welding current passing through a load cell can damage the adhesive holding the strain gauge to the body. If possible, remove the load cell when welding using the jacking/shipping bolts to maintain final height. If welding is unavoidable after load cell installation, connect the ground in such a way that the current does not flow through the load cell. For example, if welding on the mount top plate, the ground must be connected to the vessel, not to the mount base or support structure. Also, protect the load cell and cable from weld splatter.





Note *The arrow on the load cell should point in the direction of the load.*

6. All support points should be equally stiff so that they deflect by the same amount as the vessel is loaded.


2.2 Installing the RL1700 HE Module

0-250 kg



Front View

500-5000 kg



The type of installation, vessel support structure, and the surface upon which the mount is to be placed determines the method of locating, attaching, and assembling the RL1700 HE weigh module. Carefully consider three areas that commonly cause accuracy problems:

- Are the supporting legs adequately braced so they will not spread when the system is fully loaded?
- Does the supporting structure have the necessary strength to prevent excessive deflection when the system is fully loaded?
- Is there attached equipment such as skirting, venting, or piping which is likely to cause binding or lack of flexibility?

After considering any areas that may cause accuracy problems, follow these installation steps.

1. Determine where to position the mount and in which direction it should be oriented. The preferred mounting orientation for single ended beams is with the longitudinal axis of the load cell pointing toward the center of the vessel in circular mounting configurations as illustrated in A and B in [Figure 2-1 on page 5](#).




Figure 2-1. Load Cell Orientation

Mounting configurations for square and rectangular vessels are shown in D and C in Figure 2-1. For rectangular vessels, the load cell's longitudinal axis should be aligned along the vessel's longest dimension as shown in Figure 4. In any application where a recurring side force is present in one direction, such as in a conveyor belt or roller platform, the longitudinal axis of the load cell should align with that force.




Note

The load may be checked in one of two directions. Make sure the top plate moves in the proper direction (see step 2).

2. To assemble each module, remove the load cell bolts, position the load cell, and pass the load cell bolts through the load cell and the load cell spacer, and thread them into the base plate. Lift the top plate (do not loosen the retaining bolts) and place the load button into the load hole of the load cell. Rest the top plate on the load button. Verify that the retaining bolts do not protrude above the plane of the top plate. Adjust if necessary.

During installation or transport, the jacking nuts may be used to isolate the top plate from the load cell to avoid any damage to the load cell.

The load may be checked in one of two directions. To use the alternate checking feature, lift the top plate clear of the load button, turn the load button 90°, and restore the top plate to its original position.



3. Lift and block the vessel to the same height as the assembled mounts.
4. Use the jacking nuts to fully raise the top plate, automatically ensuring correct alignment of the top plate and base plate during installation.
5. Remove the block from one support point and slide a mount into position.
6. If the mount is being fitted under the leg of a vessel, verify that the leg's center line passes through the center of the load button.
7. Attach the top plate by bolting. Do not fully tighten as shimming may be necessary to level.




Note

The threads in the top plate of the 5-250kg modules are 1/2"-20 N.F. threads. The threads in the top plate of the 500-5000kg modules are 3/4"-10 N.C. threads.

8. Repeat steps 4, 5, and 6 for the remaining mounts. The vessel should now be supported on the mounts alone.
9. If necessary, move the vessel to its final position. Verify that there is no initial misalignment between the base plate and top plate. Verify that the load button is centered in the top plate to allow equal travel on either side.
10. If the jacking nuts were used to isolate the load cell from the load, lower them to the jacking spacers to lower the vessel to rest on the load cells.
11. Attach the base plates to the foundation using anchors for concrete or by bolting or welding to a steel structure. Verify that the base plates are no more than $\pm 5^\circ$ out of level. Shim as necessary.
12. Check that the top plates are no more than $\pm 5^\circ$ out of level. Shim if necessary and fully tighten the bolts.
13. The load distribution can be checked by lifting the vessel slightly at each support point in turn or, more accurately, by exciting each load cell in turn and measuring the output with a voltmeter. The variation in load among the cells should be no more than 20%. Shim if necessary.
14. Check that the two screws securing the load cell to the base plate are tight.

3.0 Load Cell Wiring

1. Route the load cell cables so they will not be damaged or cut. Cable should not be routed near heat sources greater than 150° F. **Do not shorten any load cell cable.** The load cell is temperature compensated with the supplied length of cable. Cutting the cable will affect temperature compensation. Coil excess cable and protect it so it will not be mechanically damaged or be sitting in water.
2. Provide a drip loop in all cables so that water or other liquids will not run directly down the cables onto either the load cells or the junction box. Attach load cell cable to the dead structure, not the vessel.
3. If conduit protection is necessary against mechanical or rodent damage to the load cell cables, use flexible conduit and conduit adapters at the load cells.
4. Connect cables for RL9018SS, RLHTO, TEDEA 355, and TEDEA 3510 load cells to the summing board in the junction box according to the guide shown below and the labels on the terminal strips of the junction box. To verify the wiring scheme, see the certification shipped with the load cell.
5. For better performance, use positive and negative remote sense lines if the wiring run from the junction box to the indicator is longer than 25 feet.



RL9018SS, 355		RLHTO, 3510	
Load Cell Wire Color	Function	Load Cell Wire Color	Function
Blue	+EXC	Blue	+EXC
Black	-EXC	Black	-EXC
White	+SIG	White	+SIG
Red	-SIG	Red	-SIG
Bare	SHIELD	Bare	SHIELD
Green	+Sen	Green	+Sen
Yellow	-Sen	Gray	-Sen

Table 3-1. Load Cell Wiring

4.0 Junction Box Connections, Adjustments & Calibration

1. Refer to Junction Box manual for trimming details.
2. Refer to indicator manual or “Technical Information” section in Rice Lake Weighing Systems’ Load Cell Product Selection Guide (PN 22054) for system calibration details.

5.0 Troubleshooting

If the system powers up and gives some type of stable digital readout that varies with the load on the system, any system problems are probably caused by factors other than the load cells. The load cells are often blamed for a malfunctioning system, but 90% of the time, the problem lies elsewhere. Look for mechanical causes for your problem first.

If the system can be calibrated but doesn't return to zero, loses calibration, or demonstrates non-linearity or non-repeatability, see the following chart for possible causes and do the following checks.

1. Check load cell mount for debris restricting load cell movement or debris between scale and structure.
2. Check that tank/vessel and mounts are plumb, level, and square at critical areas.
3. Check all piping and conduit for connections which restrict vessel movement.

Symptom	Possible Cause
No return to zero	Mechanical binding or debris in seals or under load cells May have lost system calibration
Non-linearity	Thermal expansion or deflection under load causing binding or side load.
Non-repeatability	Loose load cell mount Drifting caused by moisture Load cell overload or shack damage Mechanical binding
Lost calibration	Out of level or plumb Moisture problem Mechanical binding
Drifting readout	Moisture in junction box, cables or load cells Mechanical binding

Table 5-1. Troubleshooting Chart


4. If check rods are used, loosen all connections to finger tight only for testing.
5. Check load cell cables for physical or water damage.
6. Check all electrical connections, especially in the junction box.

If the problem still is not found:

7. Check possible indicator malfunction by using a load cell simulator to input a known good signal into the indicator.
8. Disconnect each load cell's signal leads at the junction box and check individual load cell outputs with a multimeter. Then check input/output impedances for comparison with load cell manufacturer's specifications.

If after all these checks the problem still cannot be isolated, reconnect all but one load cell. Replace load cell with a load cell simulator. Alternate so that each load cell is individually disconnected and replaced with a simulator. If there is a problem with a particular load cell, the symptom should disappear when that load cell is disconnected and replaced with simulator.

6.0 Maintenance and Replacement Parts



Item No.	Part No.	Description
Rated Capacity: 5 - 250 kg		
1	33036	Top Plate, Stainless Steel
2	125661	Coupling Nut, Stainless Steel
3	33035	Base Plate, Stainless Steel
4	33037	Load Cell Spacer, Stainless Steel
5	188691	Load Cell, RL9018SS-5 kg, OIML C3
	188692	Load Cell, RL9018SS-10 kg, OIML C3
	188693	Load Cell, RL9018SS-20 kg, OIML C3
	188702	Load Cell, RL9018SS-50 kg, OIML C3
	188696	Load Cell, RL9018SS-100 kg, OIML C3
	188697	Load Cell, RL9018SS-200 kg, OIML C3
	188698	Load Cell, RL9018SS-250 kg, OIML C3
6	33038	Cable Guard Plate, Stainless Steel
7	33040	Load Cell Bolt, Stainless Steel
8	33039	Ground Strap
9	42364	Cap Screw, 10-24 Stainless Steel
10	15141	Washer, Plain
Rated Capacity: 500 - 2,000 kg		
1	159182	Top plate, stainless steel
2	125661	Coupling Nut, Stainless Steel
3	159181	Base Plate, Stainless Steel
4	159186	Load Cell Spacer, Stainless Steel

Table 6-1. Repair Parts List

Item No.	Part No.	Description
5	31253	Load Cell, RLHTO-500 kg, OIML C3
	31250	Load Cell, RLHTO-1000 kg, OIML C3
	31251	Load Cell, RLHTO-2000 kg, OIML C3
6	159187	Cable Guard Plate, Stainless Steel
7	33054	Load Cell Bolt, Stainless Steel
8	159183	Ground Strap
9		Machine Screw, 1/4-28 NF
10		Washer, Plain, 1/4
Rated Capacity: 5000 kg		
1	33043	Top plate, stainless steel
2	33048	Checking/jacking assembly, stainless steel
3	33042	Base plate, stainless steel
4	33044	Load cell spacer, stainless steel
5	31252	Load cell, RLHTO-5000 kg, OIML C3
6	33045	Cable guard plate, stainless steel
7	33047	Load cell bolt set, stainless steel
8	33046	Ground strap (includes fasteners)

Table 6-1. Repair Parts List (Continued)



© Rice Lake Weighing Systems Specifications subject to change without notice.
Rice Lake Weighing Systems is an ISO 9001 registered company.

230 W. Coleman St. • Rice Lake, WI 54868 • USA

U.S. 800-472-6703 • Canada/Mexico 800-321-6703 • International 715-234-9171 • Europe +31 (0)26 472 1319

May 8, 2020

www.ricelake.com

PN 33318 Rev C