

WM-4000 AUTOMATIC WRAPPER


Error Codes and Solutions

100 – 399




March 2015

0101




[Error content]	The system has become unstable.
[Detail]	malloc area was not secured.
[Solution]	Restore power.
[Remarks]	
[Cause]	Does not occur during normal operation.
[Response]	Contact S/C if this error occurs.

0102




[Error content]	A commodity is out of sequence.
[Detail]	The peripheral devices are controlled by assigning each cycle a sequence number. This error occurs when these are not consistent.
[Solution]	[Return] button
[Remarks]	When this error occurs, communication log with the peripheral devices is cut.
[Cause]	The peripheral devices are controlled by assigning each cycle a sequence number. These are inconsistent.
[Response]	Does not occur during normal operation. Contact S/C if this error occurs.

0103




[Error content]	Attempting to send a message to a non-existent printer.
[Detail]	
[Solution]	Resolve the error with the return button
[Remarks]	Possible to locate where a sub-error has become an error.
[Cause]	Does not occur during normal operation.
[Response]	Contact S/C if this error occurs.

0104




[Error content]	Network settings have been lost.
[Detail]	
[Solution]	Restarts automatically
[Remarks]	Reset network settings.
[Cause]	Performing network setting.
[Response]	The device will automatically restart. Please wait a moment.

0105




[Error content]	Memory has not been initialized.
[Detail]	
[Solution]	[OK] button, Numeric keys
[Remarks]	Memory needs to be cleared in test mode memory initialization. Can you enter from test mode.
[Cause]	Initialization of P-910 memory has not been performed.
[Response]	Initialize P-910 memory in test mode.

0106




[Error content]	P-910 battery switch is OFF or the battery is exhausted.
[Detail]	
[Solution]	[OK] button, Numeric keys
[Remarks]	Can only enter test and system modes.
[Cause]	P-910 battery switch is OFF or burnt out.
[Response]	<ol style="list-style-type: none"> 1. Confirm switch is in the ON position, switch ON. 2. If the battery is ON, the battery is exhausted. Replace P-910 main board.

0107




[Error content]	Touch panel adjustment is incomplete.
[Detail]	
[Solution]	[OK] button, Numeric keys
[Remarks]	Can only enter test mode and system mode.
[Cause]	Touch panel adjustment is incomplete.
[Response]	Perform touch panel adjustment on adjustment screen.

0108




[Error content]	Time setting is incomplete.
[Detail]	
[Solution]	[OK] button, Numeric keys
[Remarks]	
[Cause]	Time setting is incomplete.
[Response]	Set clock.

0109




[Error content]	Printer initialization is incomplete.
[Detail]	Sub-error is the printer number.
[Solution]	[OK] button, Numeric keys
[Remarks]	Can you enter from test mode or system modes.
[Cause]	Printer initialization is incomplete.
[Response]	In test mode, initialize printer unit memory in printer adjustment screen 1/2.

0110




[Error content]	Model setting is incomplete.
[Detail]	
[Solution]	[OK] button, Numeric keys
[Remarks]	Can you enter from test mode or system modes.
[Cause]	Model setting is incomplete.
[Response]	Set model settings in test mode.

0202




[Error content]	Product master is not registered.
[Detail]	Does not exist in internal master.
[Solution]	Numeric keys, [OK] button
[Remarks]	Product number is displayed.
	Product master is not registered.
[Cause]	Product master is not registered.
[Response]	Register product master.

0203




[Error content]	POP master is not registered.
[Detail]	Does not exist in internal master.
[Solution]	[EXECUTE] button: Delete Product Master POP No. [CANCEL] button: Cancel error.
[Remarks]	In the case of no automatic POP No. update, it is not deleted even after pressing [EXECUTE]. Error display can be changed in link master error settings.
[Cause]	POP master is not registered.
[Response]	Register POP master.

0204




[Error content]	Origin master is not registered.
[Detail]	Does not exist in internal master.
[Solution]	[EXECUTE] button: Delete product origin master no. [CANCEL] button: Cancel error.
[Remarks]	In the case of no automatic origin update, it is not deleted even after pressing the [EXECUTE] button. Error display can be changed in link master error settings.
[Cause]	Origin master is not registered.
[Response]	Register origin master.

0205




[Error content]	Extra message 1 master is not registered.
[Detail]	Does not exist in internal master.
[Solution]	[EXECUTE] button: Delete extra message 1 master. [CANCEL] button: Cancel error.
[Remarks]	In the case of no automatic extra message 1 master update, it is not deleted even after pressing [EXECUTE]. Error display can be changed in link master error settings.
[Cause]	Extra message 1 master is not registered.
[Response]	Register extra message 1 master.

0206




[Error content]	Storage method master is not registered.
[Detail]	Does not exist in internal master.
[Solution]	[EXECUTE] button: Delete product master storage method no. [CANCEL] button: Cancel error.
[Remarks]	In the case of no storage method automatic update, it is not deleted even after pressing the [EXECUTE] button. Error display can be changed in link master error settings.
[Cause]	Storage method master is not registered.
[Response]	Register storage method master.

0207




[Error content]	Storage Temperature master is not registered.
[Detail]	Does not exist in internal master.
[Solution]	[EXECUTE] button: Delete product master storage temperature no. [CANCEL] button: Cancel error.
[Remarks]	In the case of no automatic storage temperature update, it will not be deleted even after pressing [EXECUTE]. Error display can be changed in link master error settings.
[Cause]	Storage temperature master is not registered.
[Response]	Register storage temperature master.

0208




[Error content]	Image no. 1 master is not registered.
[Detail]	
[Solution]	[EXECUTE] button: Delete item master image No. 1 [CANCEL] button: Cancel error.
[Remarks]	In the case of no automatic image No. 1 update, it is not deleted even after pressing [EXECUTE].
[Cause]	Image no. 1 master is not registered.
[Response]	Register image no. 1 master.

0209




[Error content]	Image no. 2 master is not registered.
[Detail]	
[Solution]	[EXECUTE] button: Delete item master image no. 2 [CANCEL] button: Cancel error.
[Remarks]	In the case of no automatic image no. 2 update, it is not deleted even after pressing [EXECUTE].
[Cause]	Image no. 2 master is not registered.
[Response]	Register image no. 2 master.

0210




[Error content]	Tray master is not registered.
[Detail]	
[Solution]	[OK] button
[Remarks]	In the case of no automatic tray update, it is not deleted even after pressing [EXECUTE].
[Cause]	Tray master is not registered.
[Response]	Register tray master.

0212




[Error content]	Free 1 master is not registered.
[Detail]	
[Solution]	[EXECUTE] button: Delete product master free no. 1. [CANCEL] button: Cancel error.
[Remarks]	In the case of no free 1 automatic update, it is not deleted even after pressing [EXECUTE]. It is possible to change the name of free 1 in "Free master name settings" in system mode. Error display can be changed in link master error settings.
[Cause]	Free 1 master is not registered.
[Response]	Register free 1 master.

0213




[Error content]	Free 2 master is not registered.
[Detail]	
[Solution]	[EXECUTE] button: Delete product master free no. 2. [CANCEL] button: Cancel error.
[Remarks]	In the case of no automatic free 2 update, it is not deleted even after pressing [EXECUTE]. It is possible to change the name of Free 2 in "Free master name settings" in system mode. Error display can be changed in link master error settings.
[Cause]	Free 2 master is not registered.
[Response]	Register free 2 master.

0214




[Error content]	Free 3 master is not registered.
[Detail]	
[Solution]	[EXECUTE] button: Delete product master free no. 3. [CANCEL] button: Cancel error.
[Remarks]	In the case of no automatic free 3 update, it is not deleted even after pressing [EXECUTE]. It is possible to change the name of free 3 in "Free master name settings" in system mode.
[Cause]	Free 3 master is not registered.
[Response]	Register free 3 master.

0215



[Error content]	Free 4 master is not registered.
[Detail]	
[Solution]	[EXECUTE] button: Delete product master free no. 4. [CANCEL] button: Cancel error.
[Remarks]	In the case of no automatic free 4 update, it is not deleted even after pressing the [EXECUTE] button. It is possible to change the name of free 4 in "Free master name settings" in system mode. Error display can be changed in link master error settings.
[Cause]	Free 4 master is not registered.
[Response]	Register free 4 master.

0216



[Error content]	Free 5 master is not registered.
[Detail]	
[Solution]	[EXECUTE] button: Delete product master free no. 5. [CANCEL] button: Cancel error.
[Remarks]	In the case of no automatic free 5 update, it is not deleted even after pressing [EXECUTE]. It is possible to change the name of free 5 in "Free master name settings" in system mode. Error display can be changed in link master error settings.
[Cause]	Free 5 master is not registered.
[Response]	Register free 5 master.

0219




[Error content]	Store Master is not registered.
[Detail]	Does not exist in internal master.
[Solution]	Numeric keys, [OK] button
[Remarks]	
[Cause]	Store Master is not registered.
[Response]	Register Store Master.

0220



[Error content]	PLU link master is not registered.
[Detail]	This error occurs when alphabetical search is attempted in normal mode and there is no PLU link master.
[Solution]	[OK] button
[Remarks]	
[Cause]	PLU link master by word is not registered.
[Response]	Register the PLU link master by word.

0221




[Error content]	Tare is greater than 999g.
[Detail]	
[Solution]	Numeric keys, [OK] button
[Remarks]	Tare is cleared after the error is cleared.
[Cause]	Tare is greater than 999g.
[Response]	Check tare.

0222



[Error content]	Tare weight is set at 0.
[Detail]	
[Solution]	Numeric keys, [OK] button
[Remarks]	Tare weight is set at 0 error does not occur when "Do not display" is selected.
[Cause]	Tare weight is set at 0.
[Response]	Enter the tare weight.

0223




[Error content]	Comment master is not registered.
[Detail]	Does not exist in the internal master.
[Solution]	[EXECUTE] button: Delete product master comment no. [CANCEL] button: Cancel error.
[Remarks]	In the case of no automatic comment update, it is not deleted even after pressing [EXECUTE]. Error display can be changed in link master error settings.
[Cause]	Comment master is not registered.
[Response]	Register comment master.

0224




[Error content]	Label master no. unregistered error.
[Detail]	Occurs when trying to create a new label master no. in System Mode>Label Issue Pattern Settings>Label Details.
[Solution]	[EXECUTE] button: New registration by call number [CANCEL] button: Cancel.
[Remarks]	
[Cause]	Label master no. unregistered error.
[Response]	Register label master.

0225




[Error content]	The label format no. attempted to configure is not registered.
[Detail]	
[Solution]	[OK] button
[Remarks]	
[Cause]	The label format no. attempted to configure is not registered.
[Response]	Register format.

0226




[Error content]	Internal memory full error.
[Detail]	Insufficient internal master area free space.
[Solution]	[OK] button
[Remarks]	The data to be saved will be lost. Delete unnecessary data.
[Cause]	Internal memory full error.
[Response]	Delete unnecessary data.

0227




[Error content]	Internal total memory full error.
[Detail]	Insufficient total memory.
[Solution]	[OK] button
[Remarks]	The data to be added will be lost. Delete total data
[Cause]	Internal total memory full error.
[Response]	Delete total data.

0228




[Error content]	No memory card is inserted.
[Detail]	This error occurs when save results are set to CF-2, SRAM 1, SRAM 2 in system mode option settings and the card is not inserted when normal mode is entered.
[Solution]	[OK] button
[Remarks]	
[Cause]	No memory card is inserted.
[Response]	Insert memory card.

0229




[Error content]	Occurs when there is an internal file is abnormal.
[Detail]	Sub-error enters internal error details. (FMGR, H)
[Solution]	[OK] button
[Remarks]	Re-setup.
[Cause]	<ul style="list-style-type: none"> · No file · Unformatted
[Response]	<ol style="list-style-type: none"> 1. Remove the battery and let stand for ten minutes. Replace battery and reformat the RAM disk. 2. If it isn't fixed after reformatting, replace the P-910 board.

0230




[Error content]	Occurs when tray and packaging image is not in CF.
[Detail]	Occurs when multiple value functions have been set and the image for that number is not in CF.
[Solution]	[OK] button
[Remarks]	Re-setup
[Cause]	Occurs when tray and packaging image is not in CF
[Response]	Register tray and packaging image in CF.

0231




[Error content]	Occurs when there is insufficient memory to write data on the CF card.
[Detail]	Occurs when there is insufficient CF card memory.
[Resolution]	[OK] button
[Remarks]	
[Cause]	Occurs when there is insufficient memory to write data on the CF card.
[Response]	Ensure space for writing data on the CF card.

0250



[Error content]	Download file sum error.
[Detail]	Occurs during execution of program download in test mode. Occurs when the SUM value is out of sync in the download file (*.MOI).
[Solution]	[OK] button
[Remarks]	
[Cause]	1. There is an abnormality in the ***.MOI file on the CF. 2. CF is defective
[Response]	1. Replace all software on the CF. (There is the possibility of a writing error to CF) 2. Change CF .

0251




[Error content]	Download file size error.
[Detail]	Occurs during execution of program download in test mode. Occurs when the download file (*.MOT) is larger than its download location.
[Solution]	[OK] button
[Remarks]	
[Cause]	Download file size error.
[Response]	This error does not normally occur. Reception-side space is already ensured when sending from the P-910 CF to the writing board. When this error occurs, re-write the program information on the CF board.

0301

PACKING CONTROL PART

THE EMERGENCY STOP SWITCH IS PRESSED

*Release EMERGENCY STOP switch.



OK

0301-0000


[Error content]	Emergency stop switch is pressed.
[Detail]	The emergency stop switch is pressed before operation. The emergency stop switch is blinking red on the wrapping unit display.
[Solution]	Release emergency stop switch, [OK] button
[Remarks]	
[Cause]	Emergency stop switch is pressed.
[Response]	Release emergency stop switch.

0302

PACKING CONTROL PART

THE EMERGENCY STOP SWITCH IS NOT PRESSED

*Press EMERGENCY STOP switch.



0302-0000


[Error content]	Emergency stop switch is not pressed.
[Detail]	This occurs when the emergency stop switch is not pressed.
[Solution]	Press the emergency stop switch, [OK] button.
[Remarks]	
[Cause]	Emergency stop switch is not pressed.
[Response]	Press the emergency stop switch.

0303

PACKING CONTROL PART

THE FRONT COVER IS OPEN

*Close front cover.



0303-0000


[Error content]	The front cover is open.
[Detail]	Occurs when the front cover is open before operation.
[Solution]	Close the front cover, [OK] button
[Remarks]	
[Cause]	The front cover is open.
[Response]	Close the front cover.

0304

PACKING CONTROL PART

THE INFEED LOWER COVER IS OPEN

*Close infeed lower cover.



0304-0000


[Error content]	The infeed lower cover is open.
[Detail]	This occurs when the infeed lower unit cover is open before operation.
[Solution]	Close the infeed lower cover, [OK] button
[Remarks]	
[Cause]	The infeed lower cover is open.
[Response]	Close the infeed lower cover.

0305

PACKING CONTROL PART

THE INFEED COVER IS OPEN


*Close infeed cover.



0305-0000

[Error content]	The infeed cover is open.
[Detail]	Occurs when the infeed unit is open before operation.
[Solution]	Close the infeed cover, [OK] button
[Remarks]	
[Cause]	The infeed cover is open.
[Response]	Set the infeed unit.

0306




[Error content]	Right side film removal door is open.
[Detail]	Occurs when the right side film removal cover is open before operation.
[Solution]	Close right side film removal door, [OK] button
[Remarks]	
[Cause]	Right side film removal door is open.
[Response]	Close right side film removal door.

0307

PACKING CONTROL PART

LEFT SIDE FILM REMOVAL DOOR IS OPEN


*Close film remove door.



0307-0000


[Error content]	Left side film removal door is open.
[Detail]	Occurs when the left side film removal cover is open before operation.
[Solution]	Close left side film removal door, [OK] button
[Remarks]	
[Cause]	Left side film removal door is open.
[Response]	Close left side film removal door.

0308



[Error content]	Right film replacement door is open.
[Detail]	Occurs when the right film replacement cover is open before operation.
[Solution]	Close right film replacement door, [OK] button
[Remarks]	
[Cause]	Right film replacement door is open.
[Response]	Close right film replacement door.

0309




[Error content]	Left side film replacement door is open.
[Detail]	Occurs when the left side film replacement cover is open before operation.
[Solution]	Close left side film replacement door, [OK] button
[Remarks]	
[Cause]	Left side film replacement door is open.
[Response]	Close left side film replacement door.

0310

PACKING CONTROL PART

THE OUTFEED HAS PULLED UP

*Take down the outfeed.



OK

0310-0000

[Error content]	The outfeed unit is pushed up.
[Detail]	Occurs when the outfeed unit is pushed up before operation.
[Solution]	Lower outfeed unit, [OK] button
[Remarks]	
[Cause]	The outfeed unit is pushed up.
[Response]	Lower outfeed unit.

0312


PRINTER

EXTRA LABELS REMAIN

*Remove the following labels.

*Press numeric key to clear error.

*Press numeric key to clear error.



OK

0312-0000

[Error content]	Label remains in the printer when operation started.
[Detail]	Separated by Bit. Bit0 : Printer no. 1 Bit1 : Printer no. 2 Bit2 : Printer no. 3 Bit3 : Printer no. 4 Bit7 : Applicator Bit11 : Product in the wrapper
[Solution]	Remove label, numeric keys
[Remarks]	
[Cause]	Label remains in the printer when operation started.
[Response]	Remove the label according to the sub-error.


0313

PRINTER

THE PRINTER THERMAL HEAD IS IN UP POSITION

*The following thermal header is pulled up.


- 1)For Printer #1~2, open the front cover.
- 2)For Printer #4, Take out B-Label printer.
- 3)Set the thermal head of printer.



0313-0000


[Error content]	The printer thermal head is in the up position.
[Detail]	Separated by Bit. Bit0 : Printer no. 1 Bit1 : Printer no. 2 Bit2 : Printer no. 3 Bit3 : Printer no. 4
[Solution]	Set thermal head, [OK] button
[Remarks]	
[Cause]	The printer thermal head is in the up position.
[Response]	According to the sub-error 1. Set thermal head. 2. Check head up sensor.

0315




[Error content]	Items remain in the stock unit.
[Detail]	
[Solution]	[OK] button, remove item in stock unit
[Remarks]	This error only occurs in type J.
[Cause]	Items remain in the stock unit.
[Response]	<ol style="list-style-type: none"> 1. Confirm that product does not remain in the stock unit. 2. Check capacity detection sensor movement.

0316




[Error content]	Markdown price exceeds regular price.
[Detail]	
[Solution]	Numeric key, [OK] button
[Remarks]	
[Cause]	Markdown price exceeds regular price.
[Response]	Confirm and correct markdown price.

0317




[Error content]	Selected price exceeds regular price.
[Detail]	
[Solution]	Numeric key, [OK] button
[Remarks]	
[Cause]	Selected price exceeds regular price.
[Response]	Set selected price as a bigger difference from the regular price.

0318



[Error content]	Markdown unit price exceeds the regular unit price.
[Detail]	
[Solution]	Numeric key, [OK] button
[Remarks]	
[Cause]	Markdown unit price exceeds the regular unit price.
[Response]	Set markdown unit price less than the regular unit price.

0319




[Error content]	The order quantity has been completed.
[Detail]	
[Solution]	Numeric key, [OK] button
[Remarks]	Clears p/order quantity.
[Cause]	Attempted to turn out more than the designated quantity.
[Response]	Press [OK] and continue with the next operation.

0321




[Error content]	No price entered.
[Detail]	
[Solution]	Numeric key, [OK] button
[Remarks]	Does not occur when "do not display" is selected for 0 price error.
[Cause]	No price entered.
[Response]	Enter price.

0322



[Error content]	Starting point return processing is done.
[Detail]	
[Solution]	[RETURN] button
[Remarks]	Starting point return processing is performed by pressing the [RETURN] button. Only when the power supply is first turned ON.
[Cause]	Perform starting point return processing.
[Response]	Displayed when the power supply is turned ON and each mechanical position returns to default.

0323




[Error content]	Label issue pattern is not set.
[Detail]	
[Solution]	Numeric key, [OK] button
[Remarks]	Perform label issue pattern setting in system mode.
[Cause]	Label issue pattern is not set.
[Response]	Perform label issue pattern setting.

0324



[Error content]	Label setting master is not set.
[Detail]	
[Solution]	Numeric key, [OK] button
[Remarks]	
[Cause]	Label setting master is not set.
[Response]	Set label setting master.

0325



[Error content]	Weight is outside the set range.
[Detail]	
[Solution]	[PRINT] button: print label; error will not occur. [STOP] button: will not check weight until next unit is called. Numeric key > resolves error, but does not resolve weight check.
[Remarks]	Does not check product limits when "No" is selected for product weight measurement in system data settings.
[Cause]	Weight is outside the set range.
[Response]	Adjust weight to within the set range.

0326




[Error content]	Tray detection error.
[Detail]	The right side of the tray is protruding.
[Solution]	Fix tray placement, [OK] button
[Remarks]	
[Cause]	Tray detection error.
[Response]	<ol style="list-style-type: none"> 1. Fix tray placement. 2. If the error persists: <ul style="list-style-type: none"> ◦ Is the tray dirty? ◦ Is it exposed to direct sunlight? ◦ Have the surroundings changed since the camera was adjusted? ◦ Perform camera adjustment if the problem is not resolved by the above.

0327




[Error content]	Tray detection error.
[Detail]	The left side of the tray is protruding.
[Solution]	Fix tray placement, [OK] button
[Remarks]	
[Cause]	Tray detection error.
[Response]	<ol style="list-style-type: none"> 1. Fix tray placement. 2. If the error persists: <ul style="list-style-type: none"> ▪ Is the tray dirty? ▪ Is it exposed to direct sunlight? ▪ Have the surroundings changed since the camera was adjusted? ▪ Perform camera adjustment if the problem is not resolved by the above.

0328




[Error content]	Tray detection error.
[Detail]	Right and left sides of the tray are protruding. Sub-error 1 data anomaly
[Solution]	Fix tray placement, [OK] button
[Remarks]	
[Cause]	Tray detection error.
[Response]	<ol style="list-style-type: none"> 1. Fix tray placement. 2. If the error persists: <ul style="list-style-type: none"> ▪ Is the tray dirty? ▪ Is it exposed to direct sunlight? ▪ Have the surroundings changed since the camera was adjusted? ▪ Perform camera adjustment if the problem is not resolved by the above.

0329




[Error content]	Tray detection error.
[Detail]	Top of the tray is protruding.
[Solution]	Fix tray placement, [OK] button
[Remarks]	
[Cause]	Tray detection error.
[Response]	<ol style="list-style-type: none"> 1. Fix tray placement. 2. If the error persists: <ul style="list-style-type: none"> ▪ Is the tray dirty? ▪ Is it exposed to direct sunlight? ▪ Have the surroundings changed since the camera was adjusted? ▪ Perform camera adjustment if the problem is not resolved by the above.

0330




[Error content]	Tray detection error.
[Detail]	Bottom of the tray is protruding.
[Solution]	Fix tray placement, [OK] button
[Remarks]	
[Cause]	Tray detection error.
[Response]	<ol style="list-style-type: none"> 1. Fix tray placement. 2. If the error persists: <ul style="list-style-type: none"> ◦ Is the tray dirty? ◦ Is it exposed to direct sunlight? ◦ Have the surroundings changed since the camera was adjusted? ◦ Perform camera adjustment if the problem is not resolved by the above.

0331




[Error content]	Tray detection error.
[Detail]	Top and bottom of the tray are protruding.
[Solution]	Fix tray placement, [OK] button
[Remarks]	
[Cause]	Tray detection error.
[Response]	<ol style="list-style-type: none"> 1. Place tray as indicated. 2. If this error persists: <ul style="list-style-type: none"> ◦ Is the tray dirty? ◦ Is it exposed to direct sunlight? ◦ Have the surrounding changed since the camera was adjusted? ◦ Perform camera adjustment if the problem is not resolved by the above.

0332



[Error content]	Tray detection error.
[Detail]	Tray is located more than 5cm from the infeed bar.
[Solution]	Fix tray placement, [OK] button
[Remarks]	
[Cause]	Tray detection error.
[Response]	<ol style="list-style-type: none"> 1. Place tray as indicated. 2. If the error persists: <ul style="list-style-type: none"> ◦ Is the tray dirty? ◦ Is it exposed to direct sunlight? ◦ Have the surroundings changed since the camera was adjusted? ◦ Perform camera adjustment if the problem is not resolved by the above.

0333



[Error content]	Tray detection error.
[Detail]	Sub-error 0: No corresponding tray. Sub-error 1's column is 1: Detected length data is 0 Sub-error 10's column is 1: Detected narrow side data is 0 Sub-error 100's column is 1: Detected height data is 0
[Solution]	Fix tray placement, [OK] button
[Remarks]	
[Cause]	Tray detection error.
[Response]	<ol style="list-style-type: none"> 1. Fix tray placement. 2. If the error persists: <ul style="list-style-type: none"> ◦ Is the tray dirty? ◦ Is it exposed to direct sunlight? ◦ Have the surroundings changed since the camera was adjusted? ◦ Perform camera adjustment if the problem is not resolved by the above.

0334

PLEASE CHECK

THE CORRESPONDING TRAY IS NOT REGISTERED

*Register a tray into 5 selling-price table.
 *Choose tray near detected size & press sell-price table to register.
 *The tray is not changed by [OK] key but release is possible.

Moreover, when tray No. is displayed in red, it is tray size error.
 Enter tray No. and touch one table again.

PRICE	g	O	R	g	O	R	g	O	R
No.	0	0	0	0	0	0	0	0	0
NAME									

The tray near detected size		

OK

INPUT

0334-0000

[Error content]	Corresponding tray is not registered in the 5 selling-price table.
[Detail]	
[Solution]	Register the tray in the 5 selling-price table.
[Remarks]	
[Cause]	Corresponding tray is not registered in the 5 selling-price table.
[Response]	Register the tray in the 5 selling-price table.

0335

PLEASE CHECK

THE TRAY OF A NEAR SIZE IS REGISTERED

*Overwrite tray currently displayed in red & delete it.
 *Enter tray No. & touch one table to overwrite.
 *Enter 0 and touch one table to delete.
 *It will cancel, if tray displayed in red is lost.
 *The tray is not changed by [OK] key,

PRICE	g	O	R	g	O	R	g	O	R	g	O	R
No.	0			0			0			0		
NAME												


But release is possible.

OK

0335-0000 INPUT

[Error content]	Similar tray registered in the 5 selling-price table.
[Detail]	Tray data exists in the 5 selling-price table in system mode automatic tray recognition input limitation settings.
[Solution]	Delete similar tray.
[Remarks]	
[Cause]	Similar tray registered in the 5 selling-price table
[Response]	Confirm tray registration contents.

0336



[Error content]	The order quantity has been completed.
[Detail]	
[Solution]	Numeric keys, [OK] button
[Remarks]	Displayed when "End message" is selected in system data settings in system mode.
[Cause]	The order quantity has been completed.
[Response]	Confirm order quantity.

0337


CHECK OF RETURN OPERATION

IMMEDIATE BEFORE DATA IS DELETED

*The items inside wrapper became invalid.
 <<REMOVE THE FILM AND LABEL>>

1) Press EMERGENCY switch, REMOVE item on lift and infeed conveyor.
 2) Open the front cover and remove the label.

*Display goes back when the label is removed.
 *Label feeds by pressing flashing yellow.




The diagram shows a cross-section of the machine's internal mechanism. A central vertical shaft is visible, with a component labeled '1' at the top. To the right, there is a control panel with a monitor. Below the machine, a yellow button with the word 'RETURN' in black text is shown.

0337-0000

[Error content]	Data has been deleted.
[Detail]	
[Solution]	Perform return processing by pressing the [RETURN] button.
[Remarks]	This screen is displayed when the data value and items in the wrapper become invalid.
[Cause]	Data has been deleted.
[Resolution]	Perform return processing by pressing the [RETURN] button.

0339



[Error content]	Minimum value is lighter than the fixed weight.
[Detail]	Attempted to enter a minimum value lighter than the fixed weight in fixed weight mode.
[Solution]	[EXECUTE] button: Set fixed weight to the minimum value. [CANCEL] button: Release error.
[Remarks]	The minimum value will remain the same if the error is released.
[Cause]	Minimum value is lighter than the fixed weight.
[Response]	Set minimum value equal to or larger than the fixed weight. • Set it so the fixed weight \leq minimum value.

0340

CHECK OF RETURN OPERATION


ITEM ELIMINATION WAS PERFORMED

*The items inside wrapper became invalid.
 《REMOVE THE FILM AND LABEL》

1) Press EMERGENCY switch, REMOVE item on lift and infeed conveyor.

2) Open the front cover and remove the label.


*Display goes back when the label is removed.
 *Label feeds by pressing flashing yellow.



0340-0000


[Error content]	The item was deleted.
[Detail]	
[Solution]	Press the [RETURN] button to perform return processing.
[Remarks]	This screen is displayed when the item in the wrapper becomes invalid as a result of item deletion.
[Cause]	The item was deleted.
[Response]	Press the [RETURN] button to perform return processing.

0341




[Error content]	Items remain on the lift.
[Detail]	
[Solution]	[OK] button
[Remarks]	Press the [PLU] button and remove the item after clearing the error.
[Cause]	Items remain on the lift.
[Response]	<ol style="list-style-type: none"> 1. Confirm no items remain on the lift. 2. Check the commodity on lift detection sensor.

0342




[Error content]	POS code is not registered.
[Detail]	
[Solution]	[OK] button
[Remarks]	This error only occurs when "POS code unregistered error" is set. Labels cannot be issued.
	Shown when printing is not allowed in the event of a POS code unregistered error in setting mode 2 (error processing selection settings).
[Cause]	POS code is not registered.
[Response]	Register POS code.

0343




[Error content]	POS code is not registered.
[Detail]	
[Solution]	[OK] button
[Remarks]	This error occurs only when "POS code unregistered error" is set. Labels can be issued, but barcodes will not be printed.
	Shown when "no barcode" is set for POS code unregistered error in setting mode 2 (error processing selection settings).
[Cause]	POS code is not registered.
[Response]	Register POS code.

0344




[Error content]	Incorrect cassette is set for the printer.
[Detail]	
[Solution]	[OK] button
[Remarks]	This error is not shown for the WM-4000.

0345




[Error content]	Cassette is not inserted into the printer.
[Detail]	
[Solution]	[OK] button
[Remarks]	This error is not shown for the WM-4000.

0346




[Error content]	Preliminary feeding was performed without the cassette inserted in the printer.
[Detail]	
[Solution]	[OK] button
[Remarks]	This error is not shown for the WM-4000.

0347



[Error content]	Thermal head error
[Detail]	
[Solution]	[OK] button
[Remarks]	This only occurs when display "Thermal head error" is set.
[Cause]	The thermal head error
[Response]	<ol style="list-style-type: none"> 1. Replace thermal head. 2. If you do not have a thermal head: <ul style="list-style-type: none"> ◦ Change the error display in Settings Mode 2>Error processing selection.

0348




[Error content]	Scale plate has separated.
[Detail]	
[Solution]	Replace the scale plate, [RETURN] button
[Remarks]	
[Cause]	-500g is displayed due to the separation of the scale plate, etc.
[Response]	Check if the scale plate is separated, check weight.

0349




[Error content]	Store No. is not called.
[Detail]	Occurs when call item has been completed but call store no. hasn't been completed and is attempting to change to production during store changeover.
[Solution]	Numeric keys, [OK] button
[Remarks]	
[Cause]	Store No. is not called.
[Response]	Call the store no.

0350



[Error content]	Tray no. is not registered in PLU
[Detail]	
[Solution]	Numeric entry, [OK] button
[Remarks]	
[Cause]	Tray no. is not registered in PLU
[Response]	Set tray no.

0351




[Error content]	A label remains.
[Detail]	
[Solution]	Remove label, [OK] button
[Remarks]	
[Cause]	A label remains.
[Response]	<ol style="list-style-type: none"> 1. Remove label. 2. Check label sensor.

0353




[Error content]	Memo preset is already registered for the called item.
[Detail]	
[Solution]	[OK] button
[Remarks]	The already preset part is shown blinking after the error is canceled.
[Cause]	Memo preset is already registered for the called item.
[Response]	Operation has become redundant.

0355




[Error content]	The tray number set for the item is not registered in the tray master.
[Detail]	
[Solution]	Numeric keys, [OK] button
[Remarks]	
[Cause]	The tray number set for the item is not registered in the tray master.
[Response]	Register in the tray master.

0356




[Error content]	CF card is not inserted
[Detail]	
[Solution]	[OK] button
[Remarks]	
[Cause]	CF card is not inserted
[Response]	Insert CF card.

0357




[Error content]	Dictionary file does not exist on the CF card.
[Detail]	
[Solution]	[OK] button
[Remarks]	
[Cause]	Dictionary file does not exist on the CF card.
[Response]	Put dictionary file on the CF card.

0358



[Error content]	Journal printer connection setup is not done.
[Detail]	
[Solution]	Numeric keys, [OK] button
[Remarks]	
[Cause]	Journal printer connection setup is not done.
[Response]	Connect journal printer.

0359




[Error content]	Word file does not exist on the CF card.
[Detail]	
[Solution]	[OK] button
[Remarks]	
[Cause]	Word file does not exist on the CF card.
[Response]	Put word file on the CF card.

Ishida WM-4000 Error Codes and Solutions (100-399)

0361

[Error content]	This error records the power is applied to the error log.
[Detail]	This is never displayed on the error screen.
[Solution]	
[Remarks]	This error number records the power being applied to the error log. This is not displayed on the device.

0363



[Error content]	Tray can't be detected
[Detail]	Occurs when a centered tray can't be detected normally. Occurs when a transparent tray is set to the above conditions.
[Solution]	Unstable, [OK] button
[Remarks]	
[Cause]	Tray can't be detected
[Response]	<ul style="list-style-type: none"> · If it is a clear tray, place it without centering. · If it is a regular tray, perform camera adjustment.

0364



[Error content]	Container packing no. is not registered. (unit price/tray master both 0)
[Detail]	Occurs when "do not print" is set in error processing selection settings.
[Solution]	Numeric keys, [OK] button
[Remarks]	Displayed when "Do not issue" is set for container packing no. unregistered in setting mode 2 (error processing selection settings).
[Cause]	Container packing no. is not registered.
[Response]	Set container packing no.

0365



[Error content]	Container packing no. is not registered. (unit price/tray master both 0)
[Detail]	Occurs when no container wrapping image print is set in error processing selection settings.
[Solution]	Numeric keys, [OK] button
[Remarks]	Displayed when "no container wrapping image print" is set for container wrapping unregistered error in setting mode 2 (error processing selection setting screen).
[Cause]	Container packing no. is not registered.
[Response]	Set container packing no.

0366



[Error content]	The container no. is registered, but no container image exists on the CF card.
[Detail]	This error occurs when "Do not print" is set in error processing selection setting.
[Solution]	Numeric keys, [OK] button
[Remarks]	Displayed when "do not issue" is set for container wrapping unregistered error in setting mode 2 (error processing selection setting).
[Cause]	The container no. is registered, but no container image exists on the CF card.
[Response]	Save container image file to the CF card.

0367




[Error content]	The container no. is registered, but no container image exists on the CF card.
[Detail]	This error occurs when "No container image" is set in error processing selection setting.
[Solution]	Numeric keys, [OK] button
[Remarks]	Displayed when "no container image" is set for container wrapping unregistered error in setting mode 2 (error processing selection setting).
[Cause]	The container no. is registered, but no container image exists on the CF card.
[Response]	Save container image file to the CF card.

0368

PLEASE CHECK

ITEMS REMAIN IN THE WRAPPER

*Close front cover.
*Then, Discharge by [PLU] key.



0368-0000

[Error content]	The front cover was opened when the wrapper stopped and items remained on the lift.
[Detail]	This is an error for when the front cover was opened in the initial stages.
[Solution]	[PLU] key
[Remarks]	Item is discharged by pressing the [PLU] key. Added to the total amount.
[Cause]	The front cover was opened when the wrapper stopped and items remained on the lift.
[Response]	To close the cover, press the [PLU] key to discharge the item.


0369

PLEASE CHECK

ITEMS REMAIN IN THE WRAPPER

*Lower a camera


*Then, Discharge by [PLU] key.



0369-0000


[Error content]	The camera unit was lifted up when the wrapper was stopped and items remained on the lift.
[Detail]	This was a 351 error in the initial stage.
[Solution]	[PLU] key
[Remarks]	Press the [PLU] key to discharge the item. Added to the total amount This error only occurs in manual wrapping
[Cause]	The camera unit was lifted up when the wrapper was stopped and items remained on the lift.
[Response]	Lower the camera unit and discharge the item by pressing the [PLU] key.

0370



[Error content]	Printer #4 (B label printer) is pulled out.
[Detail]	The b-label printer was pulled out before operation. The wrapper b-label printer unit is flashing red on the screen.
[Solution]	Set bottom applicator, [OK] button
[Remarks]	This error only occurs in variations with a bottom roller.
[Cause]	Printer #4 (B label printer) is pulled out.
[Response]	<ol style="list-style-type: none"> 1. Set the B label printer. 2. Check the bottom applicator sensor operation 3. Check sensor wiring >P-922(XJ1) 4. Replace board P-922

0371



[Error content]	The bottom roller part is not set.
[Detail]	The bottom roller unit is not set before operation. The wrapper bottom roller unit is flashing red.
[Solution]	Set bottom roller, [OK] button
[Remarks]	This error only occurs in the variations with a bottom roller.
[Cause]	The bottom roller part is not set.
[Response]	<ol style="list-style-type: none"> 1. Check the bottom roller installation 2. Check the bottom roller discharge sensor operation 3. Check wiring [sensor - P-922(XJ1)] 4. Replace board P922


0372

PLEASE CHECK

CHOOSE AUTO-PASTE / DP MODE

*AUTO LABELING → Close the front cover,
Set the printer #4(B-Label).

*DP mode → Open the front cover,
Pull out the printer #4(B-Label)



OK

0372-0000

[Error content]	Choose auto-paste/DP mode
[Detail]	This only occurs for items with b-labels in the following cases of scale stability: The front cover is opened and the B-label printer is set. The front cover is closed and the B-label printer is pulled out.
[Solution]	Set bottom applicator and close the front cover. Pull out the bottom applicator and open the front cover. [OK] button
[Remarks]	This error only occurs in versions with a bottom applicator.
[Cause]	When the front cover is opened and the B-label printer is set. When the front cover is closed and the B-label printer is pulled out.
[Response]	<ol style="list-style-type: none"> 1. Bottom applicator is set: check if the front cover is closed 2. Bottom applicator is pulled out: check if the front cover is closed 3. Check the bottom label sensor operation 4. Check the wiring [sensor - P922 (XJ1)]

0373


PLEASE CHECK

SET A STOCK PART

*PLU with B-Label

It is necessary to set a stock part.

*Set it to clear error.



0373-0000

OK

[Error content]	Set a stock part
[Detail]	The following occurs for items with b-labels when the scale is stable and a stock unit part is not set.
[Solution]	Set a stock part [OK] button
[Remarks]	This error only occurs in variations with a bottom applicator
[Cause]	The following occurs for items with b-labels when the scale is stable and a stock unit part is not set.
[Response]	<ol style="list-style-type: none"> 1. Is the stock conveyor un-folded? 2. Check the folding sensor operation 3. Check the wiring [sensor - P922 (XJ15)]

0374


PLEASE CHECK

PRODUCE IN DP MODE

*The machine is set as manual labeling.

*Able to operate in DP Mode.

*Open the front cover,
Pull out the printer #4(B-Label)



0374-0000

OK

[Error content]	Produce in DP mode
[Detail]	This only occurs for items with b-label when the scale is stable and in the case of hand labeling (the applicator brings the labels).
[Solution]	[OK] button
[Remarks]	This error only occurs in variations with a bottom applicator.
[Cause]	The item master is set for manual labelling and the front cover is open
[Response]	Is the B-label printer set?


0375

PLEASE CHECK

PRODUCE IN DP MODE

*The machine can operate in DP Mode only.

*Open the front cover,
Pull out the printer #4(B-Label)



0375-0000

[Error content]	Produce in DP mode
[Detail]	There are three labels issued for each product with a bottom label. Regular + Additional label + Bottom label
[Solution]	[OK] button
[Remarks]	This error only occurs in variation with a bottom applicator
[Cause]	The machine is not in DP mode.
[Response]	<ol style="list-style-type: none"> 1. Is the front cover open? 2. Is the bottom applicator not set?