


iDimension® QubeVu®

Dimensioning Systems
Firmware: 6.X.X.XXXX

Administrator Guide



© Rice Lake Weighing Systems. All rights reserved.

Rice Lake Weighing Systems® is a registered trademark of
Rice Lake Weighing Systems.

IFM® is a registered trademark of IFM Electronic GmbH.

SICK® is a registered trademark of SICK AG.

All other brand or product names within this publication are trademarks or
registered trademarks of their respective companies.

All information contained within this publication is, to the best of our knowledge, complete and accurate at the time of publication. Rice Lake Weighing Systems reserves the right to make changes to the technology, features, specifications and design of the equipment without notice.

The most current version of this publication, software, firmware and all other product updates can be found on our website:

www.ricelake.com

Revision History

This section tracks and describes manual revisions for awareness of major updates.

Revision	Date	Description
A	October 20, 2023	Initial manual release
B	October 28, 2024	Updated menus; added new model calibration procedures
C	March 6, 2025	Updated general updates
D	August 5, 2025	Updated safety information
E	January 15, 2026	Updated Calibration, Work Area, Work Zone, Engapp, general updates

Table i. Revision Letter History



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at www.ricelake.com/training or obtained by calling 715-234-9171 and asking for the training department.

Contents

1.0 Introduction	7
1.1 Additional Resources	7
2.0 QubeVu Manager	9
2.1 Navigation	10
2.2 Edit/Cancel/Save Buttons	11
2.3 System Status	12
2.3.1 System Status Messages	12
2.3.2 Restart Device Information	13
2.4 QubeVu Inspector	14
2.4.1 Device Information Tab	14
2.4.2 Change Log Tab	15
2.4.3 Audit Trail Tab	16
3.0 Display	17
3.1 Touchscreen Display	18
3.1.1 Customer Display Icon – Out of Bounds Indications	18
3.2 Operator Display	19
3.3 Customer Display	19
3.4 Forklift Display	20
4.0 Admin Tools	22
5.0 Setup	23
5.1 General Settings	24
5.1.1 General Settings Tab	24
5.1.2 External Cameras Tab	28
5.1.3 Server Configuration Tab	29
5.2 Measurement Settings	31
5.2.1 Measurement Settings Tab	32
5.2.2 Measurement Advanced Settings (Configuration Editor)	33
5.2.3 Sensor List Tab	34
5.3 Display Settings	35
5.3.1 Operator Display	35
5.3.2 Customer Display	37
5.4 User	39
5.5 Network	40
5.5.1 Network Settings Tab	40
5.5.2 Network Security Tab	41
5.5.3 WiFi Settings Tab	42
6.0 Calibration	43
6.1 Calibration Object	43
6.2 Accessing Calibration	44
6.3 FLEX, LTL 5 Sensor, and PWD Calibration	45
6.4 LTL 8 Sensor Calibration	51
6.5 Plus Calibration	60
6.6 Set Work Area	66
6.7 Verify Calibration	70



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit www.ricelake.com/webinars

7.0 Capture Definitions	71
8.0 Firmware Upgrade	73
8.1 Firmware Upgrade Tab	73
8.1.1 USB Drive or Network Share	74
8.1.2 Local File	75
8.1.3 Updating Firmware	76
9.0 Backup and Restore	77
9.1 Backup	78
9.2 Restore	79
10.0 Diagnostics	80
10.1 Component Tests	81
10.2 System Log Tab	84
10.3 Debug Info.	85
11.0 License	86
12.0 Appendix	87
12.1 QubeVu Engineering Application	87
12.2 Configuring Axis IP Camera Using IP Utility	90
12.3 Installation Notes.	94
12.4 Status Messages.	95
12.4.1 Extended Status Messages	96
12.4.2 Error Messages	96
12.5 TCP Interface	97
12.5.1 TCP Interface	97
12.5.2 TCP Interface Configuration	97
12.6 QubeVu Protocol.	97
12.6.1 Sample Requests and Responses	97
12.6.2 Serial Interface	97



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at www.ricelake.com/training or obtained by calling 715-234-9171 and asking for the training department.



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit www.ricelake.com/webinars

1.0 Introduction

QubeVu Manager is an embedded program that configures iDimension products. This manual discusses configuring QubeVu with pallet dimensioners, and is recommended for use by technical system administrators.

 **NOTE:** When interfacing to a third party program, reference the software manufacturer's documentation for configuration as necessary.

This manual is applicable with the following iDimension products:

- iDimension Flex Series Parcel and Pallet Dimensioning System
- iDimension LTL 5 Sensor Dimensioning System
- iDimension LTL 8 Sensor Dimensioning System
- iDimension PWD Pallet Weighing and Dimensioning System
- iDimension Plus Static Dimensioning System

 **WARNING:** Electric shock hazard! Ensure the iDimension is disconnected from the power source before opening kiosks or junction box enclosures. Do not remove or obscure the high voltage stickers.




Figure 1-1. High Voltage Stickers

 **NOTE:** For information regarding iDimension Plus/Plus XL Static Dimensions Systems, see:

- *iDimension Desktop Wedge Software Manual (214650)*
- *iDimension Software Suite (201231)*

 Manuals are available from Rice Lake Weighing Systems at www.ricelake.com/manuals
Warranty information is available at www.ricelake.com/warranties

1.1 Additional Resources

For additional resources, see the following information:

iDimension Flex Series Assembly Instructions

The iDimension Flex Assembly Instructions (PN 220532) provides an overview on how to assemble iDimension products.

iDimension PWD Assembly Instructions

The iDimension PWD Assembly Instructions (PN 198812) provides an overview on how to assemble the iDimension PWD.

iDimension Plus Assembly Instruction

The iDimension Plus Assembly Instructions (PN 197164) provides an overview on how to assemble the iDimension Plus.

880 Performance™ Series Indicator/Controller Technical Manual

The 880 Performance Series Technical Manual (PN 158387) provides a detailed overview of the 880 indicator installation, configuration and operation procedures.

1280 Enterprise™ Series Indicator/Controller Technical Manual

The 1280 Enterprise Series Technical Manual (PN 167659) provides a detailed overview of the 1280 indicator installation, configuration and operation procedures.

SUMMIT® 3000 Installation Manual

The SUMMIT 3000 Installation Manual (PN 76012) provides a detailed overview of the SUMMIT 3000 installation procedure.

RoughDeck® Floor Scale Installation Manual

The RoughDeck Installation Manual (PN 66662) provides a detailed overview of the RoughDeck HP/HC installation procedure.

2.0 QubeVu Manager

This section provides an overview of QubeVu Manager. QubeVu Manager is the embedded program installed with the iDimension pallet dimensioner and provides configuration, system diagnostics and calibration not accessible from the touchscreen display.

To access QubeVu Manager, connect the iDimension pallet dimensioner via Ethernet to a computer and then open a web browser and enter the dimensioner's IP address: <http://192.168.0.2> (primary) or 169.254.1.1 (secondary).




Figure 2-1. QubeVu Manager Home Page

Parameter	Description
Displays	Display information (Section 3.0 on page 17)
Admin Tools	Admin tools information (Section 4.0 on page 22)
License	License information (Section 11.0 on page 86)

Table 2-1. QubeVu Manager Home Page Navigation

2.1 Navigation

The navigation menu is located in the upper left section of all pages. This allows users to track their current menu location and provides links to each preceding page.

For example, from the General Settings menu select Admin Tools to return to the Admin Tools menu or QubeVu Manager to return to the home page.



Figure 2-2. Menu Navigation

2.2 Edit/Cancel/Save Buttons

Throughout the menus, three active buttons commonly display:  ,  and  .



Figure 2-3. Edit, Cancel and Save Buttons

Item	Description
	Press  to enable the functionality to change settings. After changing settings, press  to continue.
	Select  to cancel changes made to the active tab, unless saved.
	Select  to save changes made during the edit process. NOTE: Upon saving, the unit may restart and return to the home screen.

Table 2-2. QubeVu Manager Home Page Navigation

2.3 System Status

The system status of the connected device is displayed in the upper right corner of all pages.




Figure 2-4. Status Display

Item No.	Description
1	User <i>Logged into the device under the Admin mode. Select  to return to the standard user mode.</i>
2	Device <i>The default setting is the serial number of the iDimension device. This can be renamed in the Host Name parameter in Network Settings (while in Admin mode).</i>
3	System Status (Section 2.3.1) <i>The current status of the unit.</i>
4	IP Address <i>10.184.1.58: The Current IP address of the unit.</i>
5	Log Out (Log In displays if not signed in)
6	Restarts or Reboots system (Section 2.3.2 on page 13)
7	QubeVu Inspector (Section 2.4 on page 14)

Table 2-3. System Status Indicators

If  is selected while in the Calibration section, the unit may change to **Configuring** status. The system will restart automatically upon saving or canceling changes and return to **Ready** mode.

2.3.1 System Status Messages

The device status messages which may be displayed are described below.

Status	Description
STARTING	The system is starting up
STARTED	The device has been power cycled or rebooted. Wait for the status to change to RUNNING before performing a dimension. If the device remains in STARTING mode, use the demo display or USB display Help button to view and clear dimensions
READY	The system is ready
ERROR	The internet browser is unable to determine the status. ERROR may display during a system reboot
DIMENSIONING	The system is processing a dimension
REMOVE	Dimensions are processed and the item may be removed
STOPPING	The system is transitioning to the STOPPED state
STOPPED	The service has stopped. STOPPED displays during a restart or reboot of the system. If the unit continues to display STOPPED, perform a restart or power cycle the unit from the AC Outlet or power switch on the kiosk
CALIBRATING	The device has been power cycled, reset or rebooted and the system is restarting services. Wait for the status to change to RUNNING before performing a dimension
CONFIGURING	While in Admin mode an Edit condition has been activated to change configuration settings. If the settings are saved, the device should return to the RUNNING mode. If a save function has not been performed and the device is in the configuring mode, perform a restart
RECOVERING	The system is attempting to reestablish connection with sensors

Table 2-4. Status Messages

2.3.2 Restart Device Information

To restart or reboot the system, select one of the following buttons:

- Select  from the system start bar. The QubeVu Manager restart/reboot prompt appears.
- Select  to restart the service currently running on the device.
- Select  to reboot the operating system. Rebooting the unit takes several minutes and power cycles the unit.
- Select  to return to the previous menu.



Figure 2-5. Restart/Reboot Prompt

2.4 QubeVu Inspector

QubeVu Inspector provides **Device Information** and **Change Log** tabs. These tabs provide information regarding the device and changes made to settings. It is not necessary to log in to view the information available on the **QubeVu Inspector** tab.

2.4.1 Device Information Tab

The **Device Information** tab lists system information such as the serial number, firmware version number and specifications.

Perform the following to access the **QubeVu Inspector**:

1. Select  to access **QubeVu Inspector**.




Figure 2-6. QubeVu Inspector

2.4.2 Change Log Tab

The **Change Log** tab provides a list of changes made to settings. This menu is used by the local weights and measures inspector and factory service personnel.

- To view changes using a date range, enter a **Start** and **End** date and then Select .




Figure 2-7. Change Log Tab (Date Range)

- To view all previous logs, select  without entering a date range.




Figure 2-8. Change Log Tab (All Data)

- Use the arrow keys on the PC keyboard to scroll through the results.
- Select  to export the log to a *.csv file.

2.4.3 Audit Trail Tab

The Audit Trail Tab displays record audits history.

- To fetch records, fill the **First record Id:** and **Nb. of records:** fields and select .




Figure 2-9. Audit Trail Tab (Record Range)

- To fetch all records, select  without entering the fields.




Figure 2-10. Audit Trail Tab (All Records)

- Use the arrow keys on the PC Keyboard to scroll through the results.
- Select Download to export records to a *.csv file.

3.0 Display

This section provides an overview of the QubeVu **Display Pages** menu. There are types of displays that can be used to relay information.

To enter the **Display Pages** menu, perform the following procedure:

- Select  **Displays** from the **QubeVu Manager** menu (Figure 2-1 on page 9) to enter the **Display Pages** menu



Figure 3-1. Displays Menu

Item	Description
Operator Display	Operator display information (Section 3.2 on page 19)
Customer Display	Customer display information (Section 3.3 on page 19)

Table 3-1. QubeVu Manager Home Page Navigation

3.1 Touchscreen Display

The touchscreen display is used to navigate QubeVu. The **Power** button for the USB display is located on the back of the unit. The USB display can be configured in QubeVu Manager.



Figure 3-2. Touchscreen Display

Function keys allow the iDimension software to be managed via the touchscreen display.

Item No.	Function	Function
1	Out of Bounds Indication	Displays when objects are out of bounds (see Section 3.1.1)
2	Dimension Display	Displays measured dimensions
3	Weight Display	Displays the weight of the item when the item's metrics when captured. Use Indicator weight display to view live weight data, including negative weight
4	Information Button	Accesses configuration menu to set up time and date, display configured IP address and firmware updates via USB flash drive
5	Scan Button	Activates the device to dimension
6	Help Key	Displays the Issue Review menu; Provides instructions to clear conditions such as started, stopped, wait or remove condition with no object in the scan area
7	Live Image	The weigh area provides a real-time view of the scanning area transmitted from the scanning head to the USB display

Table 3-2. Key Functions

3.1.1 Customer Display Icon – Out of Bounds Indications

The Out of bounds (OOB) indication provides a visual symbol if the placement of the pallet or box is outside of the work area. [Figure 3-3](#) indicates the pallet is out of bounds on the left edge, when facing the scale on a PWD:



Figure 3-3. Out of Bounds Indication

3.2 Operator Display

The **Operator Display** function simulates the USB touchscreen display. The **Operator Display** menu can be configured using the Admin Tools/Setup/Displays Settings function (Section 5.3.1 on page 35).

- Select  **Operator Display** from the **Display Pages** menu (Figure 3-1 on page 17). The Operator Display appears.



Figure 3-4. Operator Display

 **NOTE:** See [Section 3.1 on page 18](#) for function descriptions.

3.3 Customer Display

The **Customer Display** menu can be used for applications when a visible display is required for dimensioning. The **Customer Display** menu does not provide access to operator controls and is configured with Admin Tools/Setup/Displays Settings function (Section 5.3.2 on page 37).

- Select  **Customer Display** from the **Display Pages** menu (Figure 3-1 on page 17). The Customer display appears.



Figure 3-5. Customer Display

3.4 Forklift Display

The **Forklift Display** is used in freight applications to give operators clearance or error messages. Forklift Display access must be addressed by typing the IP address of the unit into the web browser followed by /forkliftdisplay.

Example: 10.2.131.197/forkliftdisplay



Figure 3-6. Ready Message




Figure 3-7. Status Message



NOTE: Displays system status messages (Section 2.3.1 on page 12) except Dimensioning, Error, Remove and Ready.




Figure 3-8. Clearance Message



Figure 3-9. Error Message

Error Message	Description
ERROR getting QubeVu status - the device is probably off or restarting	System is rebooting
No item in sight	The object on the forklift is undetected
Center the freight	The object is inside the work area but outside of the central zone
Failed to collect data from the sensors - check connections...	System cannot detect the sensors due to network failure
Failed to connect to the sensors after recovery attempt	System attempted but failed to detect sensors due to network failure
Error - Lost connection to device, check network - reconnecting...	System failed to reconnect

Table 3-3. Error Messages

4.0 Admin Tools

This section provides an overview of the **QubeVu Admin Tools** menu. **Admin Tools** configure, calibrate, upgrade, back up and run diagnostics on the system.

To enter the **Admin Tools** menu, perform the following procedure:

1. Select  Admin Tools from the **QubeVu Manager** menu (Figure 2-1 on page 9).
2. The QubeVu Manager login screen displays. Enter account credentials.
3. Admin Tools screen displays.



NOTE: The default username and password are admin and password.




Figure 4-1. Admin Tools Menu

Item	Description
Setup	General (optional and scale), measurement, user and network settings (Section 5.0 on page 23)
Calibration	Calibration settings, define work area and calibrate cameras (Section 6.0 on page 43)
Capture Definitions	Capture definitions for QubeVu (Section 7.0 on page 71)
Firmware Upgrade	Update firmware (Section 8.0 on page 73)
Backup	Backup and restore settings (Section 9.0 on page 77)
Diagnostics	Diagnostics settings (Section 10.0 on page 80)

Table 4-1. Admin Tools Navigation

5.0 Setup

This section provides an overview of the QubeVu **Setup** menu.

To enter the **Setup** menu, perform the following procedure:

1. Select  Admin Tools from the **QubeVu Manager** menu (Figure 2-1 on page 9).
2. The QubeVu Manager login screen displays. Enter account credentials.
3. Select  Setup from the **Admin Tools** menu (Figure 4.0 on page 22). The **Setup** menu displays.




Figure 5-1. Setup Menu

Parameter	Description
General Settings	Modify general settings for QubeVu (Section 5.1 on page 24)
Measurement Settings	Modify measurement settings for QubeVu (Section 5.2 on page 31)
Display Settings	Modify the display settings for QubeVu (Section 5.3 on page 35)
User	Change password for the administrator account (Section 5.4 on page 39)
Network	Modify network settings for QubeVu (Section 5.5 on page 40)

Table 5-1. Setup Navigation

5.1 General Settings

General Settings menu provides access to general device configuration, scale configuration, communication interface configuration.

To access **General Settings** menu, perform the following procedure:

- Select  **General Settings** from the **Setup** menu (Figure 5-1 on page 23). The **General Settings** menu displays.

The **General Settings** menu provides two tabs:

- General Settings (Section 5.1.1)
- External Cameras (Section 5.1.2 on page 28)

5.1.1 General Settings Tab

The **General Settings** tab allows device settings to be customized and changed (Table 5-2 on page 25):



Figure 5-2. General Settings Tab

Item No.	Parameter	Description
1	Device Date/Time	Configurable date and time
2	Self-recovery	<p>Determines the recovery option of the unit. Default: Reboot Selections:</p> <ul style="list-style-type: none"> • None – System switches to Stop mode and a manual restart is required • Restart – If the system has determined a critical error state, the unit restarts after 10 seconds. • Reboot – If an error occurs three times within 15 minutes, the unit will restart.
3	Log level	<p>Changing to error or debug increases the amount of engineering and performance information stored in the diagnostics and log files shown in "ipaddress/log" command Default: debug Selections:</p> <ul style="list-style-type: none"> • Error – Only logs error messages? • Info – Only logs info messages? • Debug – Logs all messages/
4	Scale	<p>Scale Type – Scale options: Auto, None, External, USB HID, Pennsylvania 7300, METTLER TOLEDO, MT-SICS, NCI, A&D FG, Dini, Rice Lake Indicator Communication Parameters USB/RS-232 – Enter settings of the scale selected; configured indicator example: Application setting required: 9600,N,8,1 <ul style="list-style-type: none"> • Baud rate: 9600 • Parity: None • Start bits: 8 • Stop bit: 1 </p>
5	Serial Interface	<p>Serial Interface – For use when capturing data from RS-232/Serial Converter when connected to the PC; For detailed information on using these interfaces refer to the iDimension API Guide (Section 12.5.1 on page 97 for details on configuration of TCP Interface)</p> <ul style="list-style-type: none"> • Default: Off • Selections: Off, QubeVu, Cubiscan 110/150 <p>Serial Port – Set-up a RS-232/USB converter for interface to the PC</p>
6	TCP Interface	<p>For use when using the TCP command/response format when attached to the network</p> <ul style="list-style-type: none"> • Default: Off • Selections: Off, QubeVu, Cubiscan 110/150 • TCP Port:
7	HTTP Interface	<p>For use when using the HTTP command/response format when attached to the network</p> <p>Protocol</p> <ul style="list-style-type: none"> • Default: Off • Selections: Off, Text <p>HTTP port – The port used to establish communication</p> <ul style="list-style-type: none"> • Default: blank • Selections: Off, Text <p>HTTP output format</p> <ul style="list-style-type: none"> • Default: blank • Selections: %DATETIME%, %CAPTUREID%, %LENGTH%, %WIDTH%, %HEIGHT%, %VOLUME%, %DIMUNIT%, %WEIGHT%, %WEIGHT-LB%, %WEIGHT-KG%, %WEIGHTUNIT%, %DISPLAYWEIGHT%, %BARCODES%, %STATUS, and %%%%,

Table 5-2. Measurement Settings Parameters

Configuring the Serial Interface

1. Select **QubeVu** or **Cubiscan 110/150** from the serial interface drop-down list (Item 5 in [Figure 5-2 on page 24](#)).




Figure 5-3. Adapter Select

2. Select **Change...** before plugging in the USB – Serial cable. iDimension software begins scanning for a new cable.



Figure 5-4. Cable Scan

3. Plug the cable into the iDimension USB port or the USB-hub. The cable will be detected.
4. Select **OK** to proceed.
5. Select **Save** to complete the serial emulation setup.



Figure 5-5. Cable Detected

The status of the serial port can be viewed from the **General Settings**. The status is only refreshed when the page is refreshed or after selecting the **Change...** dialog.

Configuring Date/Time

The **Date/Time** parameter sets the date and time. The date and time are used to time stamp configuration changes which affect the Legal-for-Trade certification.

1. In General Settings, select  to change the date and time settings of the unit.




Figure 5-6. Date and Time Tab

2. Select **Now** to set the date and time to match the local computer date and time or enter a new date and time.
3. Select a **Time Zone**.
4. Select **Done** to apply the settings.

5.1.2 External Cameras Tab

Adding external cameras, requires the configuration of the AXIS IP camera using the AXIS IP Utility program. Ensure the IP camera matches the PC network settings. The default static IP address of the camera is 192.168.0.90. See [Section 12.2 on page 90](#) for instructions on using the Axis IP utility program. The utility program is found on integrated PC in the Utility folder.

1. To add a new external camera, select **Add New Camera**.




Figure 5-7. External Camera Tab

2. The page refreshes with temporary text added to Name, Path, and Scale factor columns.

Name	Path	Action
QVRemoteCameralImage1	http://root:password@xx.xx.xx.xx/axis-cgi/mjpg/	OK Cancel

Figure 5-8. Temporary Camera Information

3. Enter the desired camera name.

 **NOTE:** The operator display only shows images named QVRemoteImageX (where X is the numerical order of the camera).

4. Configure the Path information (<http://username:password@xx.xx.xx.xx/mjpg/video.cgi>) as the following:
 - username:password — User name and password credentials
 - @xx.xx.xx.xx — IP address of camera (for example, 192.168.0.90)
 - Mpg/video.cgi

 **NOTE:** For firmware older than 6.1.2, use the path: <https://root:password@xx.xx.xx.xx/axis-cgi/jpg/image.cgi>

5. Select **OK**.
6. Select  to continue.

7. The QubeVu Manager restarts and returns to the Home page.
8. Return to the external cameras tab and Select **Test**.
9. Select .



Figure 5-9. External Camera

5.1.3 Server Configuration Tab

Provides server details where the device uploads measurement and image data.

 **NOTE:** Currently only one server can be configured.

Adding a server

1. Files can be selected in the following ways:
 - Drag and drop the file in the Server #1 box.
 - Select **browse for files...** to pick server configuration file (see Figure 5-10 on page 29).




Figure 5-10. Server Configuration Tab

2. Adjust server parameters.




Figure 5-11. Server Configuration Parameters

3. Select .

Item No.	Parameter	Description
1	Enabled	Must be ON for system to upload measurement and image data to the server.
2	Stop On Error	On - System will stop uploading in case of error. Off - System will ignore upload errors and continue processing. NOTE: The system does not resend failed uploads.
3	Connect Timeout	Time in seconds the system will stop attempt to connect to the server.
4	Request Timeout	Time in seconds the system will stop attempt to send data to the server.
5	Server Info	Displays name of server.

Table 5-3. Server Configuration Parameters

5.2 Measurement Settings

Displays and allows a user to modify settings in the parameters menus.

IMPORTANT: Changing measurement parameters voids CubeVu's legal for trade certification.

To enter the **Measurement Settings** menu, perform the following information:

- Select  **Measurement Settings** from the **Setup** menu (Figure 5-1 on page 23). The **Measurement Settings** menu displays.
- A prompt appears describing the affect of changing Measurement parameters. If terms are acceptable select **OK**.



Figure 5-12. Measurement Settings Prompt

- Measurement Settings appears.




Figure 5-13. Measurement Settings Tab

The Measurement Settings menu contains two tabs:

- Preset Profile (Section 5.2.1)
- Sensors List (Section 5.2.3 on page 34)

5.2.1 Measurement Settings Tab

Modify the values within **Measurement Settings**. See [Table 5-2 on page 25](#) for parameter information.




Figure 5-14. Measurement Settings Tab

Item No.	Parameter	Description
1	Preset profile	Multiple profiles configured with specific measurement settings: <ul style="list-style-type: none"> Pallet: Metric, NTEP, METRIC, US Customary Parcel: Metric 1.2m, Metric 1.5m, Metric 2.0m, US 48in, US 60in, NTEP 60in, US 80in
2	Profile description	Lists specifications of the Preset Profile
3	Advanced Settings	Opens Advanced Measurement Settings (see Section 5.2.2 on page 33)

Table 5-4. Measurement Settings Functions

5.2.2 Measurement Advanced Settings (Configuration Editor)

This menu contains various parameters that affect Measurements.

To enter the **Measurement Advanced Settings** menu, perform the following information:

- Select **Advanced settings** from the **Measurement Settings** menu (Figure 5-1 on page 23). The **Configuration Editor** menu displays.

 **IMPORTANT:** Do not modify parameters without contacting Rice Lake Weighing Systems first.




Figure 5-15. Measurement Advanced Settings

5.2.3 Sensor List Tab

The Sensor List tab provides access to the iDimension working status status and calibration status.




Figure 5-16. Sensors List Functions

Item	Parameter	Description	
1	Discover	Upon a new installation, a "Remove All" function or sensor replacement; select Discover to update the Sensor List and firmware with IFM or SICK sensors used for the iDimension system	
2	Ref	The "Ref" or reference selection configures which sensor will be used as the visual reference when configuring "Set Work Area" in the calibration menu and defines the Out-Of-Bounds indications on the USB display correctly; If a fifth overhead sensors is used, the iDimension software will automatically select this sensor as a reference sensor	
3	Serial No.	Serial number of IFM or SICK sensor	
4	Host Name	IP addresses of sensors; IP addresses are configured using the IFM vision assistant or SICK SOPAS Engineering tool and must use the same network address and subnet with unique host numbers as the iDimension software Network settings. Default IFM Sensor IP Addresses: <ul style="list-style-type: none"> • ID 1 = 192.168.0.4 • ID 2 = 192.168.0.5 • ID 3 = 192.168.0.6 • ID 4 = 192.168.0.7 • ID 5 = 192.168.0.8 (for 5 sensor installation) • ID 6 = 192.168.0.24 (for 8 sensor installation) • ID 7 = 192.168.0.25 (for 8 sensor installation) • ID 8 = 192.168.0.26 (for 8 sensor installation) Default SICK Sensor IP Addresses: <ul style="list-style-type: none"> • ID1 = 192.168.0.101 • ID2 = 192.168.0.102 • ID3 = 192.168.0.103 • ID4 = 192.168.0.104 • ID5 = 192.168.0.105 (for 5 sensor installation) • ID6 = 192.168.0.106 (for 8 sensor installation) • ID7 = 192.168.0.107 (for 8 sensor installation) • ID8 = 192.168.0.108 (for 8 sensor installation) 	

Table 5-5. Remote Sensor Discovery Settings

Item	Parameter	Description
5	Calibrated	The Calibrated parameter indicates whether or not the individual sensor has been calibrated <ul style="list-style-type: none"> True – During initial installation, the sensors have not been calibrated to the iDimension unit; Upon successful calibration, the status changes to Yes; If a sensor has been replaced in the field, a new serial No will appear and display No False – The remote sensors have been calibrated during initial installation; If the sensors, IP address has been changed in the field after installation, remove all sensors, perform a Discovery and add new sensors prior to a new calibration being performed
6	Status	The status field defines the current connection status of each sensor after initial installation, Discovery and Add All have been performed <ul style="list-style-type: none"> Removable – Sensor has been identified during initial installation Available – Sensor has been identified but not connected to network switch
7	Action	Available selections: <ul style="list-style-type: none"> Add – Individually add each sensor to embedded firmware for use with; It is recommended to use Add All; After selecting this function calibration is required Remove - Individually remove each sensor from the embedded firmware; It is recommended to use Remove All when changing sensors or IP addresses, then use Add All; After selecting this function calibration is required
8	Add All	Adds all sensors when status is Pending Add; Calibration is required after selected
9	Remove All	Removes all sensors when status shows removable; For use when changing a sensor or changing IP addresses after calibration; Calibration is required after selected

Table 5-5. Remote Sensor Discovery Settings (Continued)

5.3 Display Settings

To access Display Settings:

- Select  **Display Settings** from the **Setup** menu (Figure 5-1 on page 23) to enter the **Display Settings** menu.

5.3.1 Operator Display

The display settings configures the functionality of the USB display.




Figure 5-17. Operator Display



NOTE: See Section 3.1 on page 18 for touchscreen display information.

The scan button and live image feed are not available in the customer display.

Item No.	Parameter	Description
1	Scan button's capture definition	Select a capture definition from the available list to add a Scan button onto the Operator Display. Adding a Scan button to the Operator Display enables manual triggering the system to perform a dimension. Available selections: <ul style="list-style-type: none"> • QVDemo - The scan button performs the QVDemo scan • QVDisplay - The scan button performs the QVDisplay scan • Default - No scan button <p>NOTE: The parameters in this drop-down menu are retrieved from capture definitions (see See Section 7.0 on page 71).</p>
2	Weight panel display	Default: Automatic Available selections: <ul style="list-style-type: none"> • Automatic – USB display shows weight panel display with or without scale attached • Hidden – The weight panel display is removed from the USB display
3	QR output format	Configures a QR code that is presented on the USB display. Macros provide definitions that may be selected: <ul style="list-style-type: none"> • %DATETIME% • %CAPUREID% • %LENGTH% • %WIDTH% • %HEIGHT% • %VOLUME% • %DIMUNIT% • %WEIGHT% • %WEIGHT-LB% • %WEIGHT-KG% • %WEIGHTUNIT% • %DISPLAYWEIGHT% • %BARCODE% • %%%%
4	Page path	The address to the operator display page.
5	Preview	Displays a preview of the configuration

Table 5-6. Operator Display Settings

5.3.2 Customer Display

The display settings configures the functionality of the USB display.

- Select  **Display Settings** from the **Setup** menu (Figure 5-1 on page 23) to enter the **Display Settings** menu.
- Select the **Customer Display** tab.




Figure 5-18. Customer Display



NOTE: See [Section 3.1 on page 18](#) for touchscreen display information.

The scan button and live image feed are not available in the customer display.

Item No.	Parameter	Description
1	Weight panel display	<p>Default: Automatic Available selections:</p> <ul style="list-style-type: none"> • Automatic – USB display shows weight panel display with or without scale attached • Hidden – The weight panel display is removed from the USB display
2	Page path	The address to the operator display page.
3	Preview	Displays a preview of the configuration

Table 5-7. Customer Display Settings

Display Examples




Figure 5-19. Default Display Screen



Figure 5-20. Customer Display



NOTE: The display screen shown in Figure 5-20 is a different dimensioning unit and is only used for reference.



Figure 5-21. Example Display Screen with QR code

5.4 User

This section provides an overview of the QubeVu **User** menu. The **User** menu provides access to modify the default password. To enter the **User** menu, perform the following information:

- Select  **User** from the **Setup** menu (Figure 5-1 on page 23). The **User** menu displays.




Figure 5-22. User Tab

When entering a new password, adhere to the following criteria:

- Minimum length: 6 characters
- Maximum length: 511 characters
- All printable characters are allowed except Unicode characters
- Password may not resemble the last password



NOTE: Factory assistance is required to reset the password.

5.5 Network

Use the **Network** menu to configure network parameters. To enter the **Network** menu, perform the following:

- Select  **Network** from the **Setup** menu (Figure 5-1 on page 23). The **Network** menu displays.

5.5.1 Network Settings Tab

Network Settings tab provides parameters that set the network configuration.




Figure 5-23. Default Network Interface Settings

Enter or modify the network settings for the network.

Item No.	Parameter	Description
1	Interface	There are two Ethernet parameters, eth0 or eth. These parameters configure which port is used on the system. Default: eth0
2	DHCP	Enables or disables DHCP.
3	IP Address	If DHCP is disabled, define a unique IP address for each iDimension pallet dimensioner installed. Consult with the network administrator if unsure how to assign a new IP address. If using static IP addresses, access pallet dimensioner by the hostname or the IP address: <a href="http://<hostname>/">http://<hostname>/ ; <a href="http://<ip address>/">http://<ip address>/ Default IP address: 192.168.0.2
4	Subnet Mask	Consult the network administrator for the correct setting Default: 255.255.255.0
5	Gateway	Consult the network administrator for the correct setting Default: 192.169.0.1 NOTE: The Gateway parameter is unavailable when DHCP is enabled.
6	Hardware Address	Do not modify, each iDimension pallet dimensioner has been assigned a unique hardware MAC address.
7	Host Name	The default host name is the alphanumeric portion of the device serial number; A unique host name may be defined for each device; Up to 15 characters are allowed for the Host Name
8	DHCP Lease Expires	Displays the time when DHCP lease expires. The DHCP lease time is typically set by the internet service provider and varies in duration.

Table 5-8. Network Interface Parameters

5.5.2 Network Security Tab

Network Security tab allows enhanced security by encrypting communications with iDimension software using Hypertext Transfer Protocol Secure (HTTPS). By default, communication with iDimension software is via HTTP.

To configure **Network Security**, perform the following:

1. Select the **Network Security** tab to display the current settings.
2. Select **Enable HTTPS**.
3. Select **Choose File**.
4. Select the certification file.
 - Certifications may be self-signed or sourced by third-parties and are not exclusively provided by Rice Lake Weighing Systems
5. Enter the file name of the key file, certificate file and key pass phrase.
6. Select **Upload** to transfer the information from the PC to the iDimension software.




Figure 5-24. Network Security Tab



NOTE: With HTTPS enabled, both the HTTP and the HTTPS addresses are available.

5.5.3 WiFi Settings Tab

The **WiFi Settings** displays WiFi connection characteristics and details.

The screenshot shows the WiFi Settings tab in the QubeVu Manager. The top navigation bar includes the iDimension RICE LAKE logo, the QubeVu Network title, and user information (User: admin). The main content area shows a table of WiFi networks with the following columns: SSID, Security, Signal, and Action. The Action column contains links for Forget and Connect. The table lists several networks, including eng_test, RLWSUsers, 4Corn3\$, MisGuest, abf-wlan-5g, spectra, MISTest, RFTesting, and spectra2. The Action column for each row contains 'Forget' and 'Connect' links. To the right of the table are 'Discover', 'Cancel', and 'Save' buttons. The bottom right corner of the interface shows a 'Discover' button.

Figure 5-25. WiFi Settings Tab

Item No.	Parameter	Description
1	SSID	Name of the wireless network
2	Security	Network security type: <ul style="list-style-type: none"> open - no authentication psk - pre-shared key used for authentication 8021x - WPA Enterprise security
3	Signal	Signal strength of wireless network
4	Action	Available actions: <ul style="list-style-type: none"> Add - adds the wireless network to the list of remembered networks and connects Connect - connects to a previously added wireless network Disconnect - disconnects from a connected the wireless network Forget - removes the wireless network from the list of remembered networks

Table 5-9. WiFi Setting Parameters

6.0 Calibration

This section provides an overview of the QubeVu **Calibration** menu. Calibration is required during initial setup, adding sensors, replacing sensors or if the sensors have become out of alignment during use. This section discusses the following topics:

- Calibration Object [Section 6.1 on page 43](#)
- Accessing Calibration [Section 6.2 on page 44](#)
- FLEX, LTL 5 Sensor, and PWD Calibration [Section 6.3 on page 45](#)
- LTL 8 Sensor Calibration [Section 6.4 on page 51](#)
- Plus Calibration [Section 6.5 on page 60](#)
- Set Work Area [Section 6.6 on page 66](#)
- Verify Calibration [Section 6.7 on page 70](#)

6.1 Calibration Object

A calibration object is provided with each unit and is required for calibration. There are three types of calibration objects:

- 8 x 7 square checkerboard (1118 mm x 982 mm / 44.02 in x 38.66 in) packaged in a carton with protective foam inserts
- 7 x 6 square checkerboard (980 mm x 840 mm / 38.58 in x 33.07 in) packaged in a carton with protective foam inserts
- 7 x 6 square checkerboard (288 mm x 252 mm / 11.33 in x 9.92 in) packaged in a carton with protective foam inserts

 **NOTE:** The calibration procedure remains the same regardless which calibration object is used.

The smallest checkerboard is only used with the iDim Plus.

 **IMPORTANT:** The calibration objects must be kept free from dirt, fingerprints and damage.

To store the calibration object, carefully repack the calibration object back into the carton for future use.




Figure 6-1. Calibration Objects

6.2 Accessing Calibration

To enter the **Calibration** menu, perform the following:

1. Select  Admin Tools from the **QubeVu Manager** menu (Figure 2-1 on page 9). The **Admin Tools** menu displays (Figure 4.0 on page 22).
2. The QubeVu Manager login screen displays. Enter account credentials.



NOTE: The default username and password are admin and password.

3. Select  Calibration from the **Admin Tools** menu (Figure 4.0 on page 22). The **Calibration** menu displays.




Figure 6-2. Calibration Menu

4. Proceed to one of the following:
 - [Section 6.3 on page 45](#) for Flex, LTL 5 sensor and PWD calibration
 - [Section 6.4 on page 51](#) for LTL 8 sensor calibration

6.3 FLEX, LTL 5 Sensor, and PWD Calibration

Initial setup requires alignment of sensors towards the middle of the floor scale or calibration object using crosshairs. Calibration requires the use of the calibration object and requires a 5-point procedure. Calibration is performed by placing the calibration object at the 4 o'clock position (120°) and rotating the object clockwise 30° each step.

1. Select  **Sensor Calibration** from the **Calibration** menu (Figure 6-2 on page 44). The **Sensors Calibration** menu displays.




Figure 6-3. Sensors Calibration

2. Select  to enter configuration mode. The switching to configuration mode pop-up message briefly displays.



NOTE: Select the internet browser's refresh if the message does not close after several minutes.



Figure 6-4. Switching to Calibration Mode Message

3. Align calibration object under remote sensors using sensor crosshairs as guides to center:
 - Ensure sensor rods are securely mounted in place
 - Exact alignment is not critical
 - Alignment defines the calibration position of each sensor




Figure 6-5. Sensors Calibration

4. Select **Grab**. The grabbing frame pop-up message briefly displays.



Figure 6-6. QubeVu Frame Grabbing Message

5. The first frame is now collected. Observe the frame counter increased from 0 to 1.











Figure 6-7. Sensors Calibration

6. Rotate the calibration object clockwise for the next grab as indicated below.
 7. Repeat steps **Step 3** through **Step 6** four additional instances (a total of 5 grabs).



Grab/Rotation	Calibration Object Position with Tower	Calibration Object Position when Hanging
3/2	 <p>Tower Assembly Scale Base 12 1 2</p>	 <p>Rear 12 1 2 Scale Base Front</p>
4/3	 <p>Tower Assembly Scale Base 12 1 2</p>	 <p>Rear 12 1 2 Scale Base Front</p>
5/4	 <p>Tower Assembly Scale Base 12 1 2</p>	 <p>Rear 12 1 2 Scale Base Front</p>

- When all frame grabs are completed, QubeVu displays calibration results and sensor confidence levels.




Figure 6-8. Sensor Calibration Result

 **NOTE: For systems with 4 to 5 sensors, at least five grabs are needed to save captured images. If calibration fails, check for direct sunlight affecting the system then perform a new calibration.**

- Select . The calibrating sensors pop-up message briefly displays.



Figure 6-9. Sensors Calibrating Message

10. Select . The calibration details prompt displays.




Figure 6-10. Calibration Details Save Prompt

11. Select  to continue.

12. After calibration details are saved, the restart or reboot prompt displays.

13. Select the desired option and allow QubeVu to process the command.



Figure 6-11. Reboot or Restart Prompt

14. A message displays alerting of choice selected. In this example restart is selected.



Figure 6-12. Restart Message

15. Calibration is complete. Proceed to [Section 6.6 on page 66](#).

6.4 LTL 8 Sensor Calibration

Initial setup requires alignment of sensors towards the middle of the floor scale or calibration object using crosshairs. During calibration, frames of the calibration object are grabbed at strategic positions under S1 (4), S2 (4), and directly under the device (2). Under S1 and S2, the calibration object is positioned at the 3 o'clock position and rotated clockwise 30° each step. When directly under the device, the calibration object is positioned on the floor scale at the 3 o'clock position and rotated clockwise 30° once.

1. Select  **Sensor Calibration** from the **Calibration** menu (Figure 6-2 on page 44). The **Remote Sensors Calibration** menu displays.




Figure 6-13. Remote Sensors Calibration

2. Select  to enter configuration mode. A pop-up window briefly displays.



NOTE: Refresh the internet browser if the message does not close after several minutes.




Figure 6-14. Switching to Configuration Message

- Place the calibration object directly under the reference sensor (S1) and then align S3/S5/S7 sensors to the center of the calibration object:
 - Ensure the sensor rods are securely mounted in place
 - Exact alignment is not critical
 - Alignment defines the calibration position of each sensor




Figure 6-15. Calibration Object Under S1 and Aligned with S3/S7/S5




Figure 6-16. Calibration Object Under S1

4. Select **Grab**. The grabbing frame pop-up message briefly displays.



Figure 6-17. QubeVu Frame Grabbing Message

5. The first frame is collected and the Frame parameter increases to 1.
 6. Rotate the calibration object clockwise for the next grab as indicated below.
 7. Repeat steps [Step 4](#) through [Step 6](#) three additional instances (a total of 4 grabs for S1).

Grab/Rotation	Calibration Object Position	Grab/Rotation	Calibration Object Position
2/1	<p>Rear 12 1 2 3 4 5 6 7 8 9 10 Front</p>	4/3	<p>Rear 12 1 2 3 4 5 6 7 8 9 10 Front</p>
3/2	<p>Rear 12 1 2 3 4 5 6 7 8 9 10 Front</p>		

8. Place the calibration object directly under the reference sensor (S2) and then align S4/S6/S8 sensors to the center of the calibration object:

- Ensure the sensor rods are securely mounted in place
- Exact alignment is not critical
- Alignment defines the calibration position of each sensor




Figure 6-18. Calibration Object Under S3 and Aligned with S/S4/S6/S8




Figure 6-19. Calibration Object Centered Under S2

9. Select **Grab**. The grabbing frame pop-up message briefly displays.



Figure 6-20. QubeVu Frame Grabbing Message

10. The frame is collected and the Frame parameter increases by one.
11. Rotate the calibration object ct clockwise for the next grab as indicated below.
12. Repeat steps [Step 9](#) through [Step 11](#) three additional instances (total of 4 grabs for S2).

Grab/Rotation	Calibration Object Position	Rotation	Calibration Object Position
6/1		8/3	
7/2			

13. Center the calibration object directly under the dimensioner.




Figure 6-21. Calibration Object Under Dimensioner



Figure 6-22. Calibration Object Under Dimensioner

14. Select **Grab**. The grabbing frame pop-up message briefly displays.



Figure 6-23. QubeVu Frame Grabbing Message

15. After the message closes, rotate calibration object 30° clockwise.




Figure 6-24. Rotate to 4 o'clock

16. Select **Grab**. The grabbing frame pop-up message briefly displays.



Figure 6-25. QubeVu Frame Grabbing Message

17. Select . The calibrating sensors pop-up message briefly displays.



Figure 6-26. Sensors Calibrating Message

18. Calibration completes and QubeVu displays calibration result and sensor confidence levels.




Figure 6-27. Sensor Calibration Result



NOTE: For systems with 8 sensors, at least 10 grabs are needed to save captured images. If calibration fails, check for direct sunlight affecting the system then perform a new calibration.

19. Select . The save calibration details prompt displays.




Figure 6-28. Save Calibration Details Prompt

20. Select . The calibration saving message displays.



Figure 6-29. Calibration Saving Message

21. After the save is completed, restart message displays while QubeVu restarts.




Figure 6-30. QubeVu Restart Message

22. After QubeVu restarts, calibration is complete. Proceed to [Section 6.6 on page 66](#).

6.5 Plus Calibration

Initial setup requires alignment of sensors toward the middle of the floor scale or calibration object using crosshairs. Calibration requires the use of the calibration object with a 4-point procedure. Calibration is performed by placing the calibration object at the 6 o'clock position (180°) and rotating the object clockwise 30° each step.

 **NOTE:** Calibration should only be performed if the unit has been powered on for at least 30 min.

1. Select  **Sensor Calibration** from the **Calibration** menu (Figure 6-2 on page 44). The **Sensors Calibration** menu displays.




Figure 6-31. Sensors Calibration

2. Select  to enter configuration mode. The switching to configuration mode pop-up message briefly displays.

 **NOTE:** Select the internet browser's refresh button if the message does not close after several minutes.




Figure 6-32. Switching to Calibration Mode Message

3. Align calibration object under remote sensors using sensor crosshairs as guides to center:
 - Ensure sensor rods are securely mounted in place
 - Exact alignment is not critical
 - Alignment defines the calibration position of each sensor



Figure 6-33. Sensors Calibration

4. Select **Grab**. The grabbing frame pop-up message briefly displays.



Figure 6-34. QubeVu Frame Grabbing Message

5. The first frame is now collected. Observe the frame counter increased from 0 to 1.







Figure 6-35. Sensors Calibration

6. Rotate the calibration object clockwise for the next grab as indicated below.
 7. Repeat steps [Step 3](#) through [Step 6](#) four additional instances (a total of 5 grabs).



Grab/Rotation	Calibration Object Position
3/2	
4/3	

- When all frame grabs are completed, QubeVu displays calibration results and sensor confidence levels.



Figure 6-36. Sensor Calibration Result

 **NOTE:** At least 4 grabs are needed to save captured images. If calibration fails, check for direct sunlight affecting the system then perform a new calibration.

- Select . The calibration details prompt displays.



Figure 6-37. Calibration Details Save Prompt

- Select  to continue.

11. After calibration details are saved, the restart or reboot prompt displays.
12. Select the desired option and allow QubeVu to process the command.



Figure 6-38. Reboot or Restart Prompt

13. A message displays alerting of choice selected. In this example restart is selected.



Figure 6-39. Restart Message

14. Calibration is complete. Proceed to [Section 6.6 on page 66](#).

6.6 Set Work Area

The Set Work Area configures the area that is used for dimensioning.

1. Select  [Set Work Area](#) from the **Calibration** menu (Figure 6-2 on page 44). The **Set Work Area** menu displays.






Figure 6-40. Work Area Settings

2. Select .
3. Configure the Work Area parameter values as recommended below:

	8 Sensor IFM Systems		8 Sensor SICK Systems	
	Length (mm)	Width (mm)	Length (mm)	Width (mm)
Work Area	3900	2600	4400	2900
	5 Sensor IFM Systems			5 Sensor SICK Systems
	Length (mm)	Width (mm)	Length (mm)	Width (mm)
Work Area	2600	2600	2900	2900

Table 6-1. Work Area Recommended Values


Product	Configuration
Flex, LTL 5 sensor, PWD	<p>Last calibration:</p>  <div data-bbox="964 276 1258 783"> <p>Work Area</p> <p>Side to side: <input type="text" value="0 mm"/></p> <p>Front to back: <input type="text" value="0 mm"/></p> <p>Width: <input type="text" value="2600 mm"/></p> <p>Length: <input type="text" value="2600 mm"/></p> <p>Angle: <input type="text" value="-43 °"/></p> <p>Zone of Interest <input data-bbox="1209 699 1241 720" type="button" value="+"/></p> </div>
LTL 8 sensor	<p>Last calibration:</p>  <div data-bbox="964 804 1258 1311"> <p>Work Area</p> <p>Side to side: <input type="text" value="0 mm"/></p> <p>Front to back: <input type="text" value="0 mm"/></p> <p>Width: <input type="text" value="2600 mm"/></p> <p>Length: <input type="text" value="3900 mm"/></p> <p>Angle: <input type="text" value="-43 °"/></p> <p>Zone of Interest <input data-bbox="1209 1227 1241 1248" type="button" value="+"/></p> </div>
Plus	<p>Last calibration:</p>  <div data-bbox="964 1353 1258 1860"> <p>Work Area</p> <p>Side to side: <input type="text" value="0 mm"/></p> <p>Front to back: <input type="text" value="50 mm"/></p> <p>Width: <input type="text" value="1300 mm"/></p> <p>Length: <input type="text" value="900 mm"/></p> <p>Angle: <input type="text" value="2 °"/></p> <p>Zone of Interest <input data-bbox="1209 1776 1241 1797" type="button" value="+"/></p> </div>

4. Configure the Zone of Interest parameter values as recommended below.

	5 or 8 Sensor IFM Systems		5 or 8 Sensor SICK Systems	
	Length (mm)	Width (mm)	Length (mm)	Width (mm)
Zone of Interest	1600	1600	1800	1800

Table 6-2. Zone of Interest Recommended Values

Product	Configuration
Flex, LTL 5 sensor, PWD	
LTL 8 sensor	

Product	Configuration
Plus	<p>Last calibration:</p>  <p>Work Area</p> <p>Zone of Interest</p> <p>Side to side: 0 mm</p> <p>Front to back: 0 mm</p> <p>Width: 350 mm</p> <p>Length: 250 mm</p>

Select . The Work Area save prompt displays.




Figure 6-41. Work Area Save Prompt

5. Select . Camera calibration and Work Area save messages briefly display.




Figure 6-42. Camera Calibration and Work Save Message

6. Work Area configuration is complete.

6.7 Verify Calibration

Verify calibration with the test box in Operator Display.

1. Place the test box under the dimensioner.
2. Select  Displays from the **QubeVu Manager** menu (Figure 2-1 on page 9) to enter the **Display Pages** menu.
3. Select  Operator Display from the **Display Pages** menu (Figure 3-1 on page 17).
4. Measurement results should be the test box dimensions ± 0.5 in (iDimension FLEX, LTL 5 sensor, LTL 8 sensor, or PWD) or ± 0.2 in (iDimension Plus).



Figure 6-43. Hanging Dimensioner Calibration Verified



Figure 6-44. iDim Plus with Calibration Verified

7.0 Capture Definitions

This section provides an overview of the QubeVu **Capture Definitions** menu.

Unique capture definitions can be created with external triggering, or modify the existing capture definitions. A programmer can change the capture definition, or define a new one, when integrating with a client application. The capture definitions controls the low resolution images available through the web-service API, displays and the markings on each image.

Capture definitions are used to define the operations and output of a capture request.

To enter the **Capture Definitions** menu, perform the following procedure:

1. Select  Admin Tools from the **QubeVu Manager** menu (Figure 2-1 on page 9). The **Admin Tools** menu displays (Figure 4.0 on page 22).
2. The QubeVu Manager login screen displays. Enter account credentials.

 **NOTE:** The default username and password are admin and password.

3. Select  Capture Definitions from the **Admin Tools** menu (Figure 4.0 on page 22). The **Capture Definitions** menu displays.




Figure 7-1. Capture Definitions Menu with Definition Selected




Figure 7-2. Capture Definitions Menu with Definition Selected

Item No.	Parameter	Description
1	Select Definition	QV Demo – The scan button performs the QVDemo scan QVDisplay – The scan button performs the QVDisplay scan Default – System default capture definition
2	Low Res Camera Capture	If enabled, configures cameras and remote sensors to capture images during each scan using capture definitions. NOTE: If disabled, images are not captured and the operator display does not display image data.
3	Markings	If enabled, iDimension software marks low resolution images with the selected information (Figure 7-2 on page 71): <ul style="list-style-type: none">• Serial Number – Serial number• Date and Time – Date and time stamp of the scan• Scan ID – Unique scan ID number• Dimensions – Height, width, length dimensions• Indicators – Any indicators (Undersized, oversized, irregular and other indications)• Item Outline – 2D outline of the dimensioned item• Barcodes – Barcode number• Weight – Weight of object
4*	Stop and Go Markers Distance (mm)	The distance in mm between the two markers that were applied to the fork scale.
5*	Stop and Go Markers Locations (mm)	A 3D vector that locates the center between the two markers in the fork's heel coordinate system. In Figure 7-1 on page 71 the center of the marker is centered with the middle of the forks (0 -124 497), it is 497 mm higher than the heel, and back 124 mm from the backplane of the forks.
6*	Tare Mode	Selections: <ul style="list-style-type: none">• None – Performs scans as "Drop and Clear"• ForkTruck – Performs scans as "Stop and Go"• AutoDetectForkTruck – Attempts to automatically determine the mode by trying both parameters (none and ForkTruck).• Default: None
7*	Pallet	A non-Legal-for-Trade feature; If selected, enter the height of the pallet in mm. The system measures the object on the pallet; <TareExpectedHeight>0<TareExpectedHeight>

* = not applicable to the iDimension Plus

Table 7-1. Pre-Defined Capture Definitions

8.0 Firmware Upgrade

This section provides an overview of the QubeVu **Firmware Upgrade** menu.

Firmware upgrades are available at www.ricelake.com. Operators may be instructed to update the unit firmware to take advantage of new features or software improvements to increase the performance of the unit.

To enter the **Firmware Upgrade** menu, perform the following procedure:

1. Select  Admin Tools from the **QubeVu Manager** menu (Figure 2-1 on page 9) to enter the **Admin Tools** menu (Figure 4.0 on page 22).
2. The QubeVu Manager login screen displays, enter login credentials. The default username and password are admin and password.
3. Select  Firmware Upgrade from the **Admin Tools** menu (Figure 4.0 on page 22) to enter the **Firmware Upgrade** menu.

 **NOTE:** The Administrator defined a username and password during the initial setup process. The username and password are required to log into and access the iDimension software Admin Tools.

8.1 Firmware Upgrade Tab

The **Firmware Upgrade** tab configures how firmware is upgraded and facilitates the firmware upgrade process.




Figure 8-1. Firmware Upgrade

Item No.	Parameter	Description
1	CurrentFirmwareVersion #	Displays the current firmware version number
2	Firmware File Location	USB Drive – Connect a USB drive with the firmware for the iDimension unit to an open USB port of the unit (Section 8.1.1 on page 74) Network Share – Network path, username and password for sharing information with the local network (Section 8.1.1 on page 74) Local File – Choose a file to load firmware (Section 8.1.2 on page 75)

Table 8-1. Firmware Upgrade Definitions

8.1.1 USB Drive or Network Share

To upgrade firmware with a USB drive or network share, perform the following:

1. Perform one of the following:
 - Connect USB drive with firmware to the device.
 - Enter the Network Path, Username and Password to the network with the firmware update.
2. Select **Read**.




Figure 8-2. Firmware Upgrade USB File Read

3. Select the firmware version from the list of firmware version updates.
4. Select to compute the checksum.
5. Select **Upload** after the checksum is computed. The firmware upgrade process copies the update file to the iDimension pallet dimensioner's embedded processor.
6. Proceed to Update Firmware (see [Section 8.1.3 on page 76](#)).

NOTE: Do not interrupt the upload process. An opportunity to stop the firmware upgrade is available after the file is uploaded.

8.1.2 Local File

To upgrade firmware with a local file, perform the following:

1. Select **Choose File**.
2. Select the firmware from the directory.
3. Select **Read to Compute Checksum** and upload firmware.




Figure 8-3. Firmware Select with Local File

4. The uploaded firmware notice appears and instructs to wait for firmware upload to complete. The firmware upgrade process uploads the update file to the iDimension pallet dimensioner's embedded processor.
5. The notice closes when the firmware is uploaded to the iDimension pallet dimensioner's embedded processor.




Figure 8-4. Upload Firmware Notice

6. Proceed to Update Firmware (see [Section 8.1.3 on page 76](#)).

8.1.3 Updating Firmware

Once the firmware has been uploaded, Select **Update Firmware** and follow the pop-up window directions.

Select  to delete the firmware uploaded, in case an error has been made.

Select  to validate checksum.

The system will enter into a stopped state and return to normal operating mode within a few minutes.




Figure 8-5. Updating Firmware

9.0 Backup and Restore

This section provides an overview of the QubeVu **Backup** menu.

To enter the **Backup** menu, perform the following procedure:

1. Select  Admin Tools from the **QubeVu Manager** menu (Figure 2-1 on page 9) to enter the **Admin Tools** menu (Figure 4.0 on page 22).
2. The QubeVu Manager login screen displays. The default username and password are admin and password.
3. Select  Backup from the **Admin Tools** menu (Figure 4.0 on page 22). The **Backup** menu displays.

 **NOTE:** The Administrator defined a username and password during the initial setup process.
The username and password are required to log into and access the iDimension software Admin Tools.

The **Backup** menu is used to create a backup file of settings and to restore those settings.




Figure 9-1. Backup and Restore Menu

Parameter	Description
Backup	Back up all QubeVu settings to the local computer (see Section 9.1 on page 78)
Restore All	Restore all QubeVu settings (see Section 9.2 on page 79)

Table 9-1. Setup Navigation

9.1 Backup

The **Backup** function creates a backup file of all settings. It is recommended to create a backup after the initial setup of the iDimension pallet dimensioner. The backup file is saved to a PC folder as an XML file. Also, a backup file can be sent to the customer support to help troubleshoot the device.

1. Select  **Backup** to begin the backup process.

 *The installed internet browser and its configuration determines the behavior when downloading the backup. The internet browser may automatically download the backup, open the Save As window, or request if the file should be downloaded. In this example the Save As window appears.*

2. Navigate to the desired folder and then select **Save**.




Figure 9-2. Download Ribbon - Accept

9.2 Restore

The **Restore** function is used to restore settings to factory default or from a saved backup file.




1. Select  to begin the restore process.



Figure 9-3. Restore Menu Browse Window

2. Select  to restore all settings from the factory calibration or Select  to select a saved file from the PC.
3. If  is selected in Step 2, find and select the desired backup file. Select  to restore settings.

10.0 Diagnostics

This section provides an overview of the QubeVu **Diagnostics** menu.

To enter the **Diagnostics** menu, perform the following procedure:

1. Select  Admin Tools from the **QubeVu Manager** menu (Figure 2-1 on page 9) to enter the **Admin Tools** menu (Figure 4.0 on page 22).
2. The QubeVu Manager login screen displays. Enter account credentials.

 **NOTE:** The default username and password are admin and password.

3. Select  Diagnostics from the **Admin Tools** menu (Figure 4.0 on page 22). The **Diagnostics** menu. Displays

Diagnostics tools can be used to test hardware components and gather diagnostic information.




Figure 10-1. Diagnostics Menu

Parameter	Description
Component Tests	Tests each hardware component (see Section 10.1 on page 81)
System Log	Views system log (see Section 10.2 on page 84)
Debug Info	Downloads debug information to assist technical support in troubleshooting an issue (see Section 10.3 on page 85)

Table 10-1. Setup Navigation

10.1 Component Tests

Select  **Component Tests** from the **Diagnostics** menu (Figure 10-1 on page 80) to enter the **Component Tests** menu.

The **Component Tests** menu helps diagnose operation status of the iDimension pallet dimensioner. Tests include **Scale Test**, **Sensors Test** and **Network Test**. Contact the factory to determine if a failure has occurred.

- Select  to perform a specific test
- Select  **Test all** to test each component
- The status of each component is returned as either **Passed** or **Failed**. Select  to view additional details.
- Select  on a test with results. A new tab in internet browser tab opens with details that is print formatted.

 **NOTE:** Upon completion of a component test, restart the system to return to normal operating mode.

Scale Test

The **Scale Test** determines if the configured scale is communicating and operating correctly with the attached unit.

Network Test

The **Network Test** confirms the iDimension components are connected through the Ethernet and communicating correctly. Report component failures to the Rice Lake Weighing Systems technical support team.

 **NOTE:** Network tests are for manufacturing purposes only.




Figure 10-2. Network Test

Figure 10-3. Network Test (Continued)

DMESG Test

The **DMESG Test** performs a firmware diagnostics test.



NOTE: DMESG tests are for manufacturing purposes only.

Figure 10-4. DMESG Test

Sensor Test – determines if sensors are connected and retrieves data frames from each sensor. This test runs for approximately 1 minute. Scroll through pages to identify failures, each of the sensors has a unique IP address. This test runs through the configuration of the sensor, including firmware and application file loaded.




Figure 10-5. Depth Information Test

Top Test, PS Test, Serial Number Tests

Do not modify unless instructed by Rice Lake Weighing Systems dimensioning support.

Port Scan Test

The **Port Scan Test** provides details about devices connected to ports.




Figure 10-6. Port Scan Test

10.2 System Log Tab

Select  [System Log](#) from the **Diagnostics** menu (see [Figure 10-1 on page 80](#)). The **System Log** menu displays.

The system log log level is configured in the setup menu. The log view can be customized by type (ALL, debug, info, warning or error messages only) or by order (view latest first or earliest first).



QubeVu® Manager | System Log

2025-11-06 12:01:05.653410 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [15] Connecting to 192.168.0.24...
 2025-11-06 12:01:05.706936 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [16] Connected to camera at [192.168.0.24] - camera fw version is 1.30.4123
 2025-11-06 12:01:05.706969 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [17] Connecting to 192.168.0.8...
 2025-11-06 12:01:05.756354 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [18] Connected to camera at [192.168.0.8] - camera fw version is 1.30.4123
 2025-11-06 12:01:05.756379 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [19] Connecting to 192.168.0.7...
 2025-11-06 12:01:05.806481 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [20] Connected to camera at [192.168.0.7] - camera fw version is 1.30.4123
 2025-11-06 12:01:05.806503 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [21] Connecting to 192.168.0.6...
 2025-11-06 12:01:05.855219 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [22] Connected to camera at [192.168.0.6] - camera fw version is 1.30.4123
 2025-11-06 12:01:05.855240 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [23] Connecting to 192.168.0.4...
 2025-11-06 12:01:05.904386 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [24] Connected to camera at [192.168.0.4] - camera fw version is 1.30.4123
 2025-11-06 12:01:05.904407 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [25] Connecting to 192.168.0.5...
 2025-11-06 12:01:05.955639 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [26] Connected to camera at [192.168.0.5] - camera fw version is 1.30.4123
 2025-11-06 12:01:05.955658 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [27] Connecting to 192.168.0.25...
 2025-11-06 12:01:06.005405 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [28] Connected to camera at [192.168.0.25] - camera fw version is 1.30.4123
 2025-11-06 12:01:06.005430 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [29] Connecting to 192.168.0.26...
 2025-11-06 12:01:06.053718 qubevu.service QVTracker(148704): <debug> [0x00007a8ccdbfc640] [30] Connected to camera at [192.168.0.26] - camera fw version is 1.30.4123

©2012-2025 Rice Lake Weighing Systems. All rights reserved.

6.1.2 (5804 build)

Figure 10-7. System Log Tab

10.3 Debug Info

Select  **Debug Info** from the **Diagnostics** menu (see [Figure 10-1 on page 80](#)). The **Debug Information** menu displays. The **Debug Info** provides engineering and troubleshooting information on the operation of the unit. This file may be requested for troubleshooting purposes. Enable the **Select All** box and then Select  to save the file to the computer.




Figure 10-8. Debug Information

11.0 License

This section provides an overview of the QubeVu **License** menu.

To enter the **License** menu, perform the following procedure:

1. Select  **License** from the **QubeVu Manager** menu (see [Figure 2-1 on page 9](#)). The **License** menu displays.
2. The QubeVu Manager login screen displays. Enter account credentials.

 **NOTE:** The default username and password are admin and password.

 **NOTE:** A license file is uploaded at the time of manufacturing and includes the the installation date. A QubeVu license will not expire. A license code request is sent to idim_support@ricelake.com, with the license request code.

3. Select **Choose File** to upload the license provided.




Figure 11-1. QubeVu License

12.0 Appendix


This section provides an overview of additional iDimension software documentation.

12.1 QubeVu Engineering Application

The **QubeVu Engineering Application** downloads a record of data that can be emailed to the factory for engineering analysis.

1. Using an internet browser, type the following in the address bar:
 - IPaddress/engapp

 **NOTE:** IP addresses may vary. The IP address In this example is 192.168.0.2, therefore, 192.168.0.2/tools/engapp.php is entered in the internet browser.



The screenshot shows a web browser window for the QubeVu® Engineering Web application. The address bar indicates the URL is 192.168.0.20/engapp and the connection is not secure. The main interface has a blue header with the text "QubeVu® Engineering Web" and "STARTED; ITEMDETECTED". On the right, there are buttons for "Scan", "Download", "Home", and "Restart", with checkboxes for "Continuous" and "Auto download". Below the header, there are tabs for "Details", "Measurements", and "Depth Viewer", with "Details" selected. The "Scan Id : 5523" is displayed. A table below shows sensor data:

FrameRate:	Motion:	CalError:
1.4	0.00	0.0 +/-0.0mm

Sensor #1 temps (°C)	IlluminationTemp:	FrontEnd1Temp:	FrontEnd2Temp:	Imx6Temp:
444	32767	0	32767	
Sensor #2 temps (°C)	IlluminationTemp:	FrontEnd1Temp:	FrontEnd2Temp:	Imx6Temp:
379	32767	0	32767	
Sensor #3 temps (°C)	IlluminationTemp:	FrontEnd1Temp:	FrontEnd2Temp:	Imx6Temp:
389	32767	0	32767	
Sensor #4 temps (°C)	IlluminationTemp:	FrontEnd1Temp:	FrontEnd2Temp:	Imx6Temp:
382	32767	0	32767	
Sensor #5 temps (°C)	IlluminationTemp:	FrontEnd1Temp:	FrontEnd2Temp:	Imx6Temp:
391	32767	0	32767	
Sensor #6 temps (°C)	IlluminationTemp:	FrontEnd1Temp:	FrontEnd2Temp:	Imx6Temp:
387	32767	0	32767	
Sensor #7 temps (°C)	IlluminationTemp:	FrontEnd1Temp:	FrontEnd2Temp:	Imx6Temp:
363	32767	0	32767	

Figure 12-1. Engineering Application


2. Select **Scan**.

Figure 12-2. Application Scan

3. Select **Download**.
4. Enter the length, width and height (L, W and H) then select **Download**. The file is downloaded.
5. Navigate to the downloaded file location on the local PC.
6. Email this file to the Rice Lake Weighing Systems Dimensioning support team for analysis.



NOTE: If known, the ground truth is the exact dimensions measured with a tape measure.




Figure 12-3. Ground Truth

12.2 Configuring Axis IP Camera Using IP Utility

1. Run IPUtility.exe.
2. Select the camera, right-click and select **Assign Network Parameters**.




Figure 12-4. Assign Network Parameters

3. If prompted, login using the **username** and **password**.



NOTE: The default Axis **username** and **password** are root and password.




Figure 12-5. Login

4. Make necessary changes and select **OK**.





Figure 12-6. Assign Network Parameters

5. Select .




Figure 12-7. Network Parameter Confirmation




Figure 12-8. AXIS IP Utility

6. Type the new IP address of the IP camera (192.168.0.9 is the default IP address for the iDimension software).
 7. The login displays. Enter the **username** and **password**.



NOTE: The default Axis **username** and **password** are root and password.




Figure 12-9. AXIS Sign-in

8. Select .

9. Select **Next**.




Figure 12-10. Network Camera

10. Select **Next**.




Figure 12-11. Network Camera (Continued)

11. Adjust camera angle and zoom to application requirements.
12. Select **Done**.




Figure 12-12. Camera Feed

13. Close the window.




Figure 12-13. Camera Feed (Expanded)

12.3 Installation Notes

The following actions are required to configure an iDimension pallet dimensioner during initial installation. This process is followed after the unit has been installed using one of the mounting methods. The IP camera and Forklift Operator display should be configured prior to mounting into the ceiling.

1. Check for Customer network IP address. If connected to the customer's network:
 - Configure sensors using IFM vision assistant or SICK SOPAS Engineering tool with new network addresses
 - Configure Network Setting tab

The following tables list the remote sensor and additional hardware component addresses used by the factory:

Device	IFM IP Address	SICK IP Address	Notes
Remote Sensor #1	192.168.0.4	192.168.0.101	
Remote Sensor #2	192.168.0.5	192.168.0.102	
Remote Sensor #3	192.168.0.6	192.168.0.103	
Remote Sensor #4	192.168.0.7	192.168.0.104	
Remote Sensor #5	192.168.0.8	192.168.0.105	Center sensor, for 5 sensor systems
Remote Sensor #6	192.168.0.24	192.168.0.106	For 8 sensor installation
Remote Sensor #7	192.168.0.25	192.168.0.107	For 8 sensor installation
Remote Sensor #8	192.168.0.26	192.168.0.108	For 8 sensor installation

Table 12-1. Remote Sensor Network IPs

Device	IP Address	Notes
Gateway	192.168.0.1	For all sensors, internal PC, JLT and IP camera
Subnet Mask	255.255.255.0	For all sensors, main head, JLT and IP camera
Internal PC	192.168.0.2	After configuration default/back door, connect to this on first power up
	169.254.1.1	
Web Relay	192.168.0.3	When applicable
IP Camera 1	192.168.0.9	If applicable (optional)
IP Camera 2	192.168.0.10	If applicable (optional)
Mobile HMI PC	192.168.0.11	Ethernet connection to the iDimension pallet dimensioner
Forklift Operator Display	192.168.0.12	If applicable (optional)
Label Printer	192.168.0.14	If applicable (optional)
Scale Indicator	192.168.0.15	1280, 880, 680, etc
Barcode Reader	192.168.0.16	If applicable (optional)
RFID Reader	192.168.0.22	If applicable (optional)

Table 12-2. Hardware Component IPs

Use the QubeVu Manager Admin Tools to calibrate settings in each tab:

2. Configure Capture Definitions (QV Demo and Default) to meet application requirements. Markings to meet customer requirements and Tare mode should be none.
3. Configure Displays/Customer Display:
 - a. iDimension software – Display Screen Version 1
4. Add Remote Sensors:
 - a. Discover
 - b. Add all
5. Calibration Mode:
 - a. Align sensors centered onto calibration object
 - b. Perform calibration

12.4 Status Messages

Status and error messages are visible from the QubeVu Manager Demo Display.




Figure 12-14. Demo Display

Item No.	Description
1	Status
2	Extended Status

Table 12-3. Status

Status	Description
STARTING	The system is starting up
STARTED	The system has started but is not ready for processing a dimension; If the device is in this status for more than a couple of seconds there is most likely an object on the platform that needs to be cleared or the scale is not at zero weight; If no object is on the platform, perform a zero height
READY	The system is ready and waiting to be used
TRACKING	The system is processing a dimension
REMOVE	The dimension has been fully processed – the item can be removed when the client processing has completed transferring the data
STOPPING	The system is transitioning into STOPPED state
STOPPED	The service has stopped – there is a problem; Perform a restart or power cycle the unit from the AC Outlet
CALIBRATING	The device is in calibration mode
CONFIGURING	The device is in configuration mode; A restart can take the device out of configuration mode

Table 12-4. Status Messages

12.4.1 Extended Status Messages

Status	Description
ScaleNotStable	This is set during tracking if the scale indicates that the value returned is not stable. This is only used when a recognized scale is connected to the system. Processing will not progress to the next step until this flag is cleared by receiving a stable weight from the scale
MotionDetected	This is set during tracking and ready states and indicates that the system has detected movement. Processing will not progress to the next step while this is set
ItemDetected	This is set when the system detects an item is placed on the device platform/scale. When a scale is used this indicates that weight returned is not zero. In 'scale-less' mode this indicates that the system cannot find the target panel
ItemNotDetected	This is set when the system is in ready mode and there is no item on the platform/scale
TrackerNotConfident	This indicates that the tracker detected an item but it is not confident what the dimensions of the item are. After a timeout (configurable) the system progresses to the next step and return zero-valued dimensions
ExceptionOccured	This is set when an exception occurs
DeviceNotStable	This is set during tracking if one of the sensors indicates that the sensor value returned is not a stable. Processing will not progress to the next step until this flag is cleared by receiving a stable value from the sensor
ServiceStarting	This is set when the system is initializing
ConfigMode	This is set when the system is in configuration mode, such as during calibration or image exposure adjustment. A restart operation takes the device out of configuration mode
ResultNotStable	This is set when the item is being manipulated such as when the item is in the act of being placed on the platform or removed from it
ItemOutOfBounds	This indicates that the item protrudes outside the measurable area. Repositioning the item is necessary
WaitingToWarmUp	This is set during the warm-up period. If device is used in a certified-for-trade application the warm-up period must have been elapsed before certified measurements can be taken
PlatformNotClear	This is set when there is something on the platform

Table 12-5. Extended Status Messages

12.4.2 Error Messages

The device error messages which may be displayed are described below.

Error Code	Description
1	Hardware Initialization FAILED
2	Tracker Config Initialization FAILED
3	Missing RegistrationMarksCropped.bmp
4	Setting reference image for Targetfinder FAILED
5	Loading of Calibration files FAILED
6	Getting new Images from hardware FAILED
7	Tracking FAILED
8	Calibrating
9	TCP Server Port binding failed
10	TCP Server exception in Processing Client
11	TCP Server time out on Imaging
12	Low res camera needs to be calibrated first
13	Calibration stopped
14	Error loading / parsing Configuration
15	Unable to save Calibration to file
16	Unable to use name set in Capture/Get command; CaptureDefinition with name were not set
17	Invalid CaptureDefinition command
18	Unable to delete Calibration files
19	Unable to Zero Height
20	Failed to write or verify audit trail

Table 12-6. Error Messages

12.5 TCP Interface

To edit the TCP interface, see [Section 5.1 on page 24](#). The TCP interface operates in two modes:

- QubeVu – A request or response protocol; See the QubeVu Developer Guide for information on using this interface
- Cubiscan – 110/150 Emulates a subset of commands supported by Cubiscan 110/150

12.5.1 TCP Interface

```
Microsoft Windows [Version 6.1.7601]
Copyright (c) 2009 Microsoft Corporation. All rights reserved.

C:\Users\chrsen.RLWS>telnet 169.254.1.1 1024
```

Figure 12-15. TCP Interface Example 1

```
?
D
470 x 460 x 250 mm 1.63 kg
```

Figure 12-16. TCP Interface Example 2

12.5.2 TCP Interface Configuration

1. Select **QubeVu** or **Cubiscan 110/150** from the TCP interface drop-down list.
2. Set the TCP port.
3. Select  to complete the TCP emulation setup.

12.6 QubeVu Protocol

Command		
Description	Request	Response
Causes the QubeVu to send the dimension and weight data to the client computer	D<CR>	{length} x {width} x {height} {dimUnit} {displayWeight}<CR><LF>
Error Handling		
Unit will return following response when dimensions are not available	D<CR>	0 x 0 x 0 {dimUnit}<CR><LF>

Table 12-7. Remote Sensors Parameters

12.6.1 Sample Requests and Responses

1. Dimension Command Request: D<CR>
Response: 9.75 x 7.25 x 3.50 in<CR><LF>
2. Dimension Command Request: D<CR>
Response: 0 x 0 x 0 in<CR><LF>
3. Invalid Command Request: M<CR>
Response: ?<CR><LF>

12.6.2 Serial Interface

The serial interface operates in two modes:

- QubeVu – A simple request or response protocol; Refer to the iDimension API Guide (see [Section 12.5.1](#)) for detailed information on using this interface
- Cubiscan – 110/150 Emulates a subset of commands supported by Cubiscan 110/150



© Rice Lake Weighing Systems Content subject to change without notice.

230 W. Coleman St. • Rice Lake, WI 54868 • USA USA: 800-472-6703 • International: +1-715-234-9171