


# SCT Weight Transmitter

---

30 Series

## Installation & Operator's Manual



May 29, 2025

**RICE LAKE**<sup>®</sup>  
WEIGHING SYSTEMS

PN 159585 Rev C

© Rice Lake Weighing Systems. All rights reserved.

Rice Lake Weighing Systems® is a registered trademark of  
Rice Lake Weighing Systems.

All other brand or product names within this publication are trademarks or registered  
trademarks of their respective companies.

All information contained within this publication is, to the best of our knowledge, complete and  
accurate at the time of publication. Rice Lake Weighing Systems reserves the right to make  
changes to the technology, features, specifications and design of the equipment without notice.

The most current version of this publication, software, firmware and all other product updates  
can be found on our website:

[www.ricelake.com](http://www.ricelake.com)

# Revision History

---

This section tracks and describes manual revisions for awareness of major updates.

| Revision | Date         | Description   |
|----------|--------------|---|
| C        | May 29, 2025 | Established revision history; updated format and icons; added disposal and FCC statements |
|          |              |   |
|          |              |   |

*Table i. Revision Letter History*



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at [www.ricelake.com/training](http://www.ricelake.com/training) or obtained by calling 715-234-9171 and asking for the training department.

# Contents

|            |   |           |
|------------|---|-----------|
| <b>1.0</b> | <b>Introduction .....</b>   | <b>5</b>  |
| 1.1        | Safety .....  | 5         |
| 1.2        | FCC Compliance .....  | 6         |
| 1.3        | Disposal .....  | 6         |
| 1.4        | Correct Installation of Weighing Instruments .....                | 7         |
| 1.5        | Correct Installation of the Load Cells .....                      | 7         |
| 1.5.1      | Installing Load Cells .....                                       | 7         |
| 1.5.2      | Protection Of The Load Cell Cable .....                           | 7         |
| 1.5.3      | Mechanical Restraints (pipes, etc.) .....                         | 7         |
| 1.5.4      | Connecting Several Cells in Parallel .....                        | 7         |
| 1.5.5      | Welding .....   | 8         |
| 1.5.6      | Windy Conditions - Shocks - Vibrations .....                      | 8         |
| 1.5.7      | Grounding The Weighed Structure .....                             | 8         |
| 1.6        | Load Cell Testing .....   | 9         |
| 1.6.1      | Load Cell Resistance Measurement (Use a Digital Multimeter) ..... | 9         |
| 1.6.2      | Load Cell Voltage Measurement (Use a Digital Multimeter) .....    | 9         |
| 1.7        | Features .....  | 10        |
| 1.8        | Electrical Connections .....                                      | 11        |
| 1.9        | Analog Output Type Selection .....                                | 12        |
| 1.10       | Instrument Commissioning .....                                    | 13        |
| <b>2.0</b> | <b>Calibration.....</b>   | <b>14</b> |
| 2.1        | Real Calibration (With Sample Weights) .....                      | 14        |
| 2.2        | Theoretical Calibration .....                                     | 14        |
| 2.3        | Digital Filtering .....   | 15        |
| <b>3.0</b> | <b>RS-485 Serial Connection.....</b>                              | <b>16</b> |
| 3.1        | Continuous One Way Transmission Protocol .....                    | 16        |
| 3.2        | Modbus-RTU Protocol .....   | 16        |
| 3.3        | Alarms .....  | 18        |
| <b>4.0</b> | <b>Reserved for the Installer .....</b>                           | <b>20</b> |
| 4.1        | Restoring Factory Values .....                                    | 20        |
| 4.2        | Calibration and RS-485 Port Setting Access Limitation .....       | 20        |
| <b>5.0</b> | <b>Specifications .....</b>                                       | <b>22</b> |



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit [www.ricelake.com/webinars](http://www.ricelake.com/webinars)

# 1.0 Introduction



Manuals are available from Rice Lake Weighing Systems at [www.ricelake.com/manuals](http://www.ricelake.com/manuals)

Warranty information is available at [www.ricelake.com/warranties](http://www.ricelake.com/warranties)

## 1.1 Safety

### Safety Definitions:



**DANGER:** Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. Includes hazards that are exposed when guards are removed.



**WARNING:** Indicates a potentially hazardous situation that, if not avoided could result in serious injury or death. Includes hazards that are exposed when guards are removed.



**CAUTION:** Indicates a potentially hazardous situation that, if not avoided, could result in minor or moderate injury.



**IMPORTANT:** Indicates information about procedures that, if not observed, could result in damage to equipment or corruption to and loss of data.

### General Safety



*Do not operate or work on this equipment unless this manual has been read and all instructions are understood. Contact any Rice Lake Weighing Systems dealer for replacement manuals.*



#### WARNING

*Failure to heed may result in serious injury or death.*

*This unit has no power switch. To completely remove D/C power from the unit, disconnect the D/C power cable from the main socket.*

*DO NOT allow minors (children) or inexperienced persons to operate this unit.*

*DO NOT operate without all shields and guards in place.*

*DO NOT use for purposes other than weighing applications.*

*DO NOT place fingers into slots or possible pinch points.*

*DO NOT use this product if any of the components are cracked.*

*DO NOT make alterations or modifications to the unit.*

*DO NOT remove or obscure warning labels.*

*DO NOT use near water.*



#### IMPORTANT

*Failure to follow the installation recommendations will be considered a misuse of the equipment.*

- Keep away from heat sources and direct sunlight.
- Protect the instrument from rain.

- Do not wash, dip in water or spill liquid on the instrument.
- Do not use solvents to clean the instrument.
- Do not install in areas subject to explosion hazard.

## 1.2 FCC Compliance

### United States

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### Canada

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la Class A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

## 1.3 Disposal



### Product Disposal

The product must be brought to appropriate separate waste collection centers at the end of its life cycle.

Proper separate collection to recycle the product helps prevent possible negative effects on the environment and to health, and promotes the recycling of the materials. Users who dispose of the product illegally shall face administrative sanctions as provided by law.

## 1.4 Correct Installation of Weighing Instruments

- The terminals indicated on the instrument's wiring diagram to be connected to ground must have the same potential as the scale structure (ground). If you are unable to ensure this condition, connect a ground wire between the instrument and the scale structure.
- The load cell cable must be run separately to the instrument input and not share a conduit with other cables. A shielded connection must be continuous without a splice.
- Use "RC" filters (quench-arcs) on the instrument-driven solenoid valve and remote control switch coils.
- Avoid electrical noise in the instrument panel; if inevitable, use special filters or sheet metal partitions to isolate.
- The panel installer must provide electrical protection for the instruments (fuses, door lock switch, etc.).
- It is advisable to leave equipment always switched on to prevent the formation of condensation.
- Maximum cable lengths:
  - RS-485: 1000 meters with AWG24, shielded and twisted cables
  - Analog current output: up to 500 meters with 0.5 mm<sup>2</sup> cable
  - Analog current output: up to 300 meters with 0.5 mm<sup>2</sup> cable

## 1.5 Correct Installation of the Load Cells

### 1.5.1 Installing Load Cells

The load cells must be placed on rigid, stable structures within .5 percent of plumb and level. It is important to use mounting modules for load cells to compensate for misalignment of the support surfaces.

### 1.5.2 Protection Of The Load Cell Cable

Use waterproof sheaths and joints in order to protect the cables of the load cells.

### 1.5.3 Mechanical Restraints (pipes, etc.)

When pipes are present, we recommend the use of hoses, flexible couplings and rubber skirted joints. In case of rigid conduit and pipes, place the pipe support or anchor bracket as far as possible from the weighed structure (at a distance at least 40 times the diameter of the pipe).

### 1.5.4 Connecting Several Cells in Parallel

Connect several load cells in parallel by using, if necessary, a watertight junction box with a terminal box. The load cell connection extension cables must be shielded, placed individually into their piping or conduit, and laid as far as possible from the power cables (in case of 4-wire connections, use cables with 4 x 1 sq.mm minimum cross-section).

### 1.5.5 Welding

Avoid welding with the load cells already installed. If this cannot be avoided, place the welder ground clamp close to the required welding point to prevent sending current through the load cell body.

### 1.5.6 Windy Conditions - Shocks - Vibrations

The use of weigh modules is strongly recommended for all load cells to compensate for misalignment of the support surfaces. The system designer must ensure that the scale is protected against lateral shifting and tipping relating to shocks and vibration, windy conditions, seismic conditions and stability of the support structure.

### 1.5.7 Grounding The Weighed Structure

By means of a 10 AWG solid or braided wire or braided grounding strap, connect the load cell upper support plate with the lower support plate, then connect all the lower plates to a single earth ground. Once installed, electrostatic charges are discharged to the ground without going through or damaging the load cells. Failure to implement a proper grounding system might not affect the operation of the weighing system; this, however, does not rule out the possibility that the load cells and connected instrument may become damaged by ESD.

 **WARNING: Do not ground the system with metal parts from the weighing structure** (see Figure 1-1).




Figure 1-1. Installation Recommendations

## 1.6 Load Cell Testing

### 1.6.1 Load Cell Resistance Measurement (Use a Digital Multimeter)

- Disconnect the load cells from the instrument and check that there is no moisture in the load cell junction box caused by condensation or water infiltration. If so, drain the system or replace it if necessary.
- The value between the positive signal wire and the negative signal wire must be equal or similar to the one indicated in the load cell data sheet (output resistance).
- The value between the positive excitation wire and the negative excitation wire must be equal or similar to the one indicated in the load cell data sheet (input resistance).
- The insulation value between the shield and any other load cell wire, and between any other load cell wire and the body of the load cell, must be higher than 20 Mohm (mega ohms).


### 1.6.2 Load Cell Voltage Measurement (Use a Digital Multimeter)

- Remove weight of scale from load cell to be tested.
- Make sure that the excitation wires of the load cell connected to the instrument is 5 Vdc +/- 3 percent.
- Measure the millivolt signal between the positive and the negative signal wires by directly connecting them to the multi-meter, and make sure it reads between 0 and 0.5 mV (thousandths of a volt).
- Apply load to the load cell and make sure that there is a signal increment.



**IMPORTANT:** *If one of the above conditions is not met, please contact the technical assistance service.*


## 1.7 Features



- Analog/serial weight transmitter suitable for assembly on back panel fitted Omega/DIN rail. Dimensions: 90x93x65 mm.
- Current or voltage 16 bit analog output.
- RS-485 serial output with Modbus RTU or continuous transmission protocol.
- Zero and full scale setting.
- Simultaneous display of the load cell reading in mV and of the analog output reading.
- Operating mode selection via 3-position selector switch, DIP switches, knob control and 2 line, 8 column alphanumeric display.

## 1.8 Electrical Connections

- It is recommended that the negative side of the power supply be grounded.
- It is possible to power up to eight 350 ohm or sixteen 700 ohm load cells.
- Connect terminal "0 VDC" to the RS-485 common of the connected instruments in the event that these receive alternating current input or that they have an opto-isolated RS-485.



1: Selector switch    2: Knob control    3: DIP switch

Figure 1-2. Wiring Diagram




Figure 1-3. RS-485 Serial Connection



**NOTE:** If the RS-485 network is longer than 100 meters or baud rates higher than 9600 are used, connect two 120 ohm terminating resistors between the '+' and '-' terminal strip ends of the instruments farthest away. Should there be different instruments or converters, refer to the specific manuals to determine whether it is necessary to connect the above-mentioned resistors.

## 1.9 Analog Output Type Selection

Set the indicated DIP switch with MODE.

| DIP SWITCH |     |     | OPERATION MODE    |
|------------|-----|-----|-------------------|
| 1          | 2   | 3   |                   |
| OFF        | OFF | OFF | 0-5 V             |
| OFF        | OFF | ON  | 0-10 V            |
| OFF        | ON  | OFF | -5-5 V            |
| OFF        | ON  | ON  | -10-10 V          |
| ON         | OFF | ON  | 4-20 mA (default) |
| ON         | ON  | OFF | 0-20 mA           |

Table 1-1. Analog Output Type Selection

By default, the instrument is calibrated to convert the load cell 0-10 mV to the selected analog output value.



**NOTE:** By modifying the type of analog output, calibration will be brought back to default values.

## 1.10 Instrument Commissioning

1. Power on the transmitter and wait five minutes until all the components have reached a stable temperature.
2. Check that the display shows the mV value of the load cells and that when loading the load cells there is an increase in weight.
3. If there is not, check and verify the connections and correct positioning of the load cells.
4. Set the three-way selector switch to ZERO, the red LED will light.



**NOTE: If the display reads BLOCK, zero setting is not enabled.**

5. The display shows the load cell reading in mV and the flashing zero value of the selected analog output (0 V, 0 mA or 4 mA); adjust the analog output value by turning the control knob.
6. Hold the control knob down until the display reads **ZERO**.
7. Release the control knob and set the selector switch back to NORMAL.



**NOTE: Zero setting can also be obtained by referring to the values read by devices connected to the instrument, such as the PC or PLC.**

## 2.0 Calibration

Before carrying out the instrument real calibration, the type of analog output must be selected and the tare weight zero setting must be performed.

### 2.1 Real Calibration (With Sample Weights)

1. Load a sample weight (at least 50 percent of the full scale value) onto the weighing system.
2. Set the three-way selector switch to FS CAL. The yellow LED will light.



**NOTE:** If the display reads **BLOCK**, zero setting is not enabled.

3. The display shows the load cell reading in mV and the corresponding flashing value of the analog output. Adjust the analog output value by turning the control knob.
4. Hold the control knob down until the display reads **FS CAL**.
5. Release the knob control and set the selector switch back to **NORMAL**.



**NOTE:** Calibration can also be obtained by referring to the values read by devices connected to the instrument, such as the PC or PLC.

#### **Example:**

*The weighing system uses four 1000 kg cells, the 4-20mA analog output has been selected and you wish to have 20 mA at 2000 kg. Check that the system is not loaded; perform the tare weight zero setting and load a sample weight of 1000 kg onto the system (equal to 50 percent of the required full scale value); move the selector switch to FS CAL and set the analog output value to 12 mA by working the knob control (range:  $20 - 4 = 16$  mA;  $\frac{1}{2}$  of the range:  $16 / 2 = 8$  mA;  $\frac{1}{2}$  of full scale:  $8 + 4 = 12$  mA); hold down the knob control until the display reads FS CAL; release the knob control and set the selector switch back to NORMAL.*

With this type of calibration it is possible to set the analog output value corresponding to a given value in mV read by the cell.

### 2.2 Theoretical Calibration



**NOTE:** Theoretical calibration may be carried out with or without load cells connected to the instrument. The analog output is zero (4 mA for the 4-20 mA output case) when the value read by the cell is 0 mV.

1. Hold down the control knob and set the selector switch to **FS CAL** within four seconds. The yellow LED will light.
2. Release the control knob.
3. **5.000mV** will flash on the first line of the display. Adjust the value by turning the control knob.
4. Hold down the control knob for at least three seconds.
5. Upon releasing the control knob, line two on the display will start flashing.

6. Adjust the analog output value by turning the control knob.
7. Hold down the control knob for at least three seconds.
8. Upon releasing the control knob, the first display line begins to flash again. Confirm the settings by adjusting the selector switch to NORMAL or change the values again by repeating the above.



**NOTE:** Ensure that the weighing system is not loaded and perform the tare weight zero setting.

**Example:**

The weighing system uses four 1000 kg cells with 2 mV/V sensitivity, the 4-20mA analog output has been selected and you wish to have 20 mA at 2000 kg. Considering that the instrument provides 5 Vdc supply for the load cells, the cell full scale value is equal to  $2 \text{ mV/V} \times 5 \text{ V} = 10 \text{ mV}$ . Additionally, 2000 kg is equal to 50 percent of the system full scale ( $4 \times 1000 \text{ kg} = 4000 \text{ kg}$ ), therefore, the values to enter are 50 percent of  $10 \text{ mV} = 5 \text{ mV}$  and 20 mA.

## 2.3 Digital Filtering

The instrument has a digital filter to reduce the effects of weight oscillation. Set the DIP switch indicated by FILTER.



**NOTE:** For an increased effect (weight more stable) increase the value of the response time.

| DIP SWITCH |     |     | Response time<br>[ms] | Display and serial port refresh<br>frequency<br>[Hz] |
|------------|-----|-----|-----------------------|--|
| 1          | 2   | 3   |                       |  |
| OFF        | OFF | OFF | 3                     | 300  |
| OFF        | OFF | ON  | 150                   | 100  |
| OFF        | ON  | OFF | 260                   | 50   |
| OFF        | ON  | ON  | 425                   | 25   |
| ON         | OFF | OFF | 850                   | 12.5 (default)                                       |
| ON         | OFF | ON  | 1700                  | 12.5   |
| ON         | ON  | OFF | 2500                  | 12.5   |
| ON         | ON  | ON  | 4000                  | 10   |

Table 2-1. Digital Filtering

## 3.0 RS-485 Serial Connection

The instrument transmits via RS-485 serial port, according to a continuous one way protocol or a querying protocol (MODBUS RTU). The division value will be between 0 and 200000 for load cell signal values between 0 and 10 mV.

For protocol setting, see [Section 2.0](#).

### 3.1 Continuous One Way Transmission Protocol

The instrument transmits the number of divisions according to a continuous protocol via the following string:

xxxxxxCRLF

where: **xxxxxx** = 6 division characters (48 – 57 ASCII).

**CR** = 1 carriage return character (13 ASCII).

**LF** = 1 new line character (10 ASCII).

### 3.2 Modbus-RTU Protocol

The MODBUS-RTU protocol enables to manage the reading and writing of the registers listed here below according to the specifications contained in the reference document for this standard Modicon PI-MBUS-300.

The numerical data listed below are expressed in hexadecimal notation if preceded by 0x.

#### Modbus-RTU Data Format

The data received and transmitted via the MODBUS-RTU protocol has the following format:

- 1 start bit
- 8 data bits, least significant bit sent first
- Parity none
- 1 stop bit

Of the controls available in the MODBUS-RTU protocol, only the READ HOLDING REGISTER control may be used (**code 0x03**).

The interrogation frequency is linked with the preset communication rate (the instrument will stand by for at least 3 bytes before beginning to calculate a possible response).

| QUERY   |          |             |              |         |
|---------|----------|-------------|--------------|---------|
| Address | Function | Add. Reg. 1 | No. register | 2 bytes |
| A       | 0x03     | 0x0000      | 0x0002       | CRC     |

Tot. bytes = 8

| RESPONSE |          |           |           |            |         |
|----------|----------|-----------|-----------|------------|---------|
| Address  | Function | No. bytes | Register1 | Register 2 | 2 bytes |
| A        | 0x03     | 0x04      | 0x0064    | 0x00C8     | CRC     |

Tot. bytes =  $3+2*\text{No. registers}+2$

where:

- No. of registers = number of Modbus registers to be read, starting from register 1 address;
- No. of bytes = number of following data bytes;

In the event of a string received correctly but not executable, the slave responds with an EXCEPTIONAL RESPONSE. The FUNCTION field is transmitted with the msb at 1.

| EXCEPTIONAL RESPONSE |               |      |         |
|----------------------|---------------|------|---------|
| Address              | Function      | Code | 2 bytes |
| A                    | Func + 0 x 80 |      | CRC     |

| CODE | DESCRIPTION  |
|------|--|
| 1    | ILLEGAL FUNCTION (Function not valid or not supported)             |
| 2    | ILLEGAL DATA ADDRESS (The specified data address is not available) |
| 3    | ILLEGAL DATA VALUE (The data received have no valid value)         |

The communication strings are controlled by CRC (Cyclical Redundancy Check).

In case of a communication error the slave will not respond with any string. The master must allow for a time-out before response reception and if no response is received, it infers that a communication error has occurred.

## Registers and Values

The instrument ModBus registers may only be read.

H - L: high half and low half - respectively, making up the DOUBLE WORD value.

| REGISTER | DESCRIPTION     |
|----------|-----------------|
| 40007    | Status Register |
| 40008    | H Divisions     |
| 40009    | L Divisions     |

| Status Register (40007) |                                  |
|-------------------------|----------------------------------|
| Bit 0                   | Cell Error (ERCEL)               |
| Bit 1                   | AD Convertor Malfunction (ER AD) |
| Bit 2                   | Off scale analog output (ER OL)  |
| Bit 3                   |                                  |
| Bit 7                   | Division negative sign           |
| Bit 11                  | Weight stability                 |
| Bit 12                  |                                  |

## H&L DIVISIONS (40008-40009)

For additional examples regarding the generation of correct control characters (CRC16) refer to the manual **Modicon PI-MBUS-30**.

## 3.3 Alarms

| Display | Description  |
|---------|--|
| ErCEL   | Load cell is not connected or is incorrectly connected; the load cell signal exceeds 39 mV; the analog output generates the lowest possible value.                           |
| Er OL   | The calculated analog signal is outside the allowed generating range:  |
| Er Ad   | The conversion electronics is malfunctioning, the analog output generates the lowest possible value; check load cell connections, if necessary contact technical assistance. |

Table 3-1. Alarms

**ANALOG OUTPUT VALUE UNDER ALARM CONDITIONS**

| <b>ANALOG OUTPUT TYPE</b> | <b>Minimum</b> | <b>Maximum</b> |
|---------------------------|----------------|----------------|
| 0-10 V                    | -1.000         | 11.000         |
| 0-5 V                     | -1.000         | 5.500          |
| -10-10 V                  | -11.000        | 11.000         |
| -5-5 V                    | -5.500         | 5.500          |
| 0-20 mA                   | 0.000          | 24.000         |
| 4-20 mA                   | 0.000          | 24.000         |

## 4.0 Reserved for the Installer

---

### 4.1 Restoring Factory Values

1. Turn off the instrument and set the selector switch to ZERO.
2. While holding down the control knob, turn the instrument back on until the following is displayed:  
CANC  
NO
3. Release the control knob and set the selector switch to NORMAL.
4. Rotate the control knob to display YES.
5. Confirm by pressing the control knob. The instrument restarts and all parameters will be restored to factory values.

### 4.2 Calibration and RS-485 Port Setting Access Limitation

1. Turn on the instrument and set the selector switch to NORMAL.
2. Hold down the control knob for five seconds until the following is displayed:  
Block  
No
3. By working the control knob it is possible to select:
  - **No:** access allowed;
  - **Yes:** access denied for unauthorized staff; if the selector switch is set to ZERO or FS CAL the display will read BLOCK.
4. Confirm by holding down the control knob for at least three seconds.
5. Release it to shift to the next parameter. The display will show the address set for the RS485 serial connection protocol:  
Address  
0
6. By working the control knob it is possible to select:
  - 0: continuous division transmission according to a frequency proportional to the set baud rate (30 Hz to 300 Hz with baud rate equal to 38400 bps);
  - 1-99: querying Modbus RTU slave protocol.
7. Confirm by holding down the control knob for at least three seconds.

8. Release it to shift to the next parameter. The display will show the rate setting for RS-485 serial connection:  
    Baud  
    9600
9. By working the control knob the transmission rate can be adjusted (2400, 4800, 9600, 19200, 38400, 115200. Default: 9600 bps).
10. Confirm by holding down the control knob for at least three seconds.
11. Release it to exit the settings menu and return to normal instrument operation.

## 5.0 Specifications

### Power

|                    |                        |
|--------------------|------------------------|
| Power Supply       | 12 - 24 VDC $\pm 10\%$ |
| Consumption (VDC)  | 3W                     |
| No. of Load Cells  | max 8 (350 ohm)        |
| Excitation Voltage | 5 VDC/120mA            |

### Analog Specifications

|  |  |
|--|--|
| Analog Output 16 Bit - 65535 Divisions | Current (max 300 ohms)<br>0-20 mA; 4-20 mA                           |
|  | Voltage (min 10 k ohm)<br>0-10 V; 0-5 V; $\pm 10$ V $\pm 5$ V        |
| Linearity                              | <0.01% F.S.  |
| Analog Output Linearity                | <0.01% F.S.  |
| Thermal Drift                          | <0.0005 % F.S./ $^{\circ}$ C   |
| Analog Output Thermal Drift            | <0.003 % F.S./ $^{\circ}$ C  |
| A/D Converter                          | 24 bit (16,000,000)  |
| Analog Signal Input Range              | $\pm 39$ mV  |
| Analog Signal Sensitivity              | 0.3 $\mu$ V/graduation minimum<br>1.0 $\mu$ V/graduation recommended |
| Max Sensitivity Of Usable Load Cells   | $\pm 7$ mV/V   |
| Max Conversions Per Second             | 300 conversions/second   |

### Serial Communications

|                      |  |
|----------------------|--|
| Serial Ports         | RS-485   |
| RS-485 Max Divisions | $\pm 200000$ ( $\pm 10$ mV with sens. 2 mV/V)<br>$\pm 300000$ ( $\pm 15$ mV with sens. 3 mV/V) |
| Baud Rate            | 2400, 4800, 9600, 19200, 38400, 115200   |

### Digital Specifications

|                     |               |
|---------------------|---------------|
| Digital Filter      | 0.003 - 4 sec |
| Readings Per Second | 10 - 300 Hz   |

### Environmental

|                           |                                     |
|---------------------------|-------------------------------------|
| Humidity (Non Condensing) | 85 percent                          |
| Storage Temperature       | - 30 $^{\circ}$ C + 80 $^{\circ}$ C |
| Operating Temperature     | - 20 $^{\circ}$ C + 60 $^{\circ}$ C |

### Certifications and Approvals







© Rice Lake Weighing Systems    Content subject to change without notice.

230 W. Coleman St. • Rice Lake, WI 54868 • USA    USA: 800-472-6703 • International: +1-715-234-9171

May 29, 2025

[www.ricelake.com](http://www.ricelake.com)

PN 159585 Rev C