## **INDICATORS** 920i<sup>®</sup> Panel Mount Indicator/Controller CPU Board Connections

## Part Number/Price

Ref#	Part#	Description	Price
3	15601	Ground wire, 6" with no. 8 eye connector	Consult
8	16861	High voltage warning label	Consult
21	71106	Enclosure, panel mount	Consult
24	71462	Fuses F1 and F2 (115VAC and 230VAC North American models), 3.15 A Time-Lag TR5	Consult
	72339	Fuses F1 and F2 (230 VAC European model), 3.15 A Time-Lag TR5	Consult
25	69144	Faceplate gasket	Consult
30	71430	Power supply cable assembly, to CPU board	Consult

The LED backlight display can be used with green CPU board Rev N or older by replacing the power supply cable. Universal 186464 (AC) 186464 (DC); Deep universal 186278 (AC) 187603 (DC); Panel 186278 (AC) 187603 (DC); Wall 186760 (AC) 188345 (DC); Two-slot expansion for wall 188716 (AC) 189724 (DC); Two-slot expansion panel for deep universal 188717 (AC) 189725 (DC); Six-slot expansion for wall 188774 (AC). (See Diagram 920i-H)

25 29 30 24 FUSES F1 & F2 8 -Ĵ n Ĵ 0 1 1940 C З 1 21 FROM LCD DISPLAY FROM SWITCH MEMBRANE

920i-H



