

Bench Scale Columns

Part Number/Price

Part #	Description	Price
112044	12 in column for IQ plus® 210, CW-90, CW-90X, 480/482 Legend Series, 380/380X Synergy Series, 680/682 Synergy Series	Consult
112045	18 in column for IQ plus® 210, CW-90, CW-90X, 480/482 Legend Series, 380/380X Synergy Series, 680/682 Synergy Series	Consult
196363	12 in column for 882IS/882IS Plus with battery	Consult
196364	18 in column for 882IS/882IS Plus with battery	Consult
197482	12 in column for 882IS/882IS Plus with power supply (Note: Power supply does not mount to column)	Consult
197484	18 in column for 882IS/882IS Plus with power supply (Note: Power supply does not mount to column)	Consult
64576	Attachment bracket for IQ plus® 210, CW-90, CW-90X, 480/482 Legend Series, 380/380X Synergy Series, 680/682 Synergy Series	Consult
216970	12 in column for 381 Synergy Indicator	Consult
216971	18 in column for 381 Synergy Indicator	Consult

Available for the BenchMark SL, BenchMark SL/HE, BenchMark Mild Steel, BenchMark Stainless Steel, BenchMark HE, BenchMark HE-X, CW-80B, CW-90B and CW90-XB



CW-90B with 380 indicator and 12 in column



Base with 882IS/882IS Plus indicator with battery and 12 in column



Attachment bracket with 680 Indicator



Base with 381 Synergy indicator and 12 in column