Installation Manual

The 4 channel board is used in many Rice Lake Weighing systems products and is FM approved. Use this document when replacing the board in existing product.



WARNING: Some procedures described in this manual require work inside the product. These procedures are to be performed by qualified service personnel only.




Figure 1. 4 Channel Board

Installation

To replace the board in existing product, follow these steps:

- 1. Open the product and locate the current 4 channel board.
- 2. Note the wiring configuration of the current board.
- 3. Remove the wiring from the board.
- 4. Loosen mounting screws and remove the board from the product.
- 5. Install the new board and secure with mounting hardware.
- Reinstall the wiring as noted in Step 2.
- 7. Close the product.

Refer to the product manual for additional information.



Manuals are available from Rice Lake Weighing Systems at www.ricelake.com/manuals Warranty information is available at www.ricelake.com/warranties

Special Conditions of Use

- Clean the product enclosure with a damp cloth only Electrostatic Charging Hazard.
- This equipment was examined and approved for connection to a single Indicator only.



August 26, 2025 PN 91909 Rev D



© Rice Lake Weighing Systems Content subject to change without notice.

230 W. Coleman St. • Rice Lake, WI 54868 • USA USA: 800-472-6703 • International: +1-715-234-9171