

Front Panel Overlay Film Removal

Product: Front panel overlay

Issue: Difficulty removing fingerprints from display overlay

Solution: Remove the protective film from the back of the front panel overlay before installation



Manuals are available from Rice Lake Weighing Systems at www.ricelake.com/manuals

Warranty information is available at www.ricelake.com/warranties

Perform the following instructions to remove the protective film from the back of the overlay:

1. Place the overlay on a flat surface with the protective film facing up.
2. Gently peel up a corner of the film.
3. Pull the corner until the protective film is removed.




Figure 1. Overlay Film Removal



© Rice Lake Weighing Systems Content subject to change without notice.

230 W. Coleman St. • Rice Lake, WI 54868 • USA USA: 800-472-6703 • International: +1-715-234-9171