

Ishida SLP-5 Lite and Uni-3 Korean Setup

These instructions are to configure the Ishida Uni-3 and SLP-5 Lite to print Korean characters. The Korean characters must be sent from SLP-5 Lite – they cannot be programmed at the scale.

Uni-3

From firmware version C1937U and all of C2271x, the Uni-3 supports Korean characters (Hangul). The Language setting in the Uni-3 must be set to "Korean" to print and display Korean characters. All menus, etc. remain in English.

Note: Only the Uni-3L2 models display Korean characters.

KEY IN ITEM No. 0.000 0.000 0.00 0.00	Enter 6000 , press Mode
<B00 SETUP> <B00 SETUP>	Enter 495344 , press PLU
<B00 SETUP> <B00 SETUP>	Enter 26 , press Down Arrow
B26 COUNTRY B26 COUNTRY	Press Enter
*LANGUAGE → 1: ENGLISH B26-01-02 LANGUAGE 1	Enter 16 , press Enter
*LANGUAGE → 16: KOREAN B26-01-02 LANGUAGE 16	After the long beep press Mode
REBOOT 19004-0000	The scale must be shut off for this setting change to take effect.

SLP-5 Lite

From version 2.20c it is possible to send Korean characters to the Uni-3 scale. These are the steps to enable Korean characters.

1. Install SLP-5 Lite as usual. Do not configure the scales or database until after the Korean setup file has been loaded.
2. Do not use the default Korean setup file installed with SLP-5 Lite. The file will not work. Instead download the updated setup file from the SLP-5 Lite software page on the [Rice Lake web](#) site. Login is required.
3. Install the new setup file as follows.
 - a. Open the SLP-5 Lite Setup Utility.
 - b. Select the **Configuration** menu.
 - c. Select **Load Setup**.
 - d. Navigate to and select the new setup file: **Update_Lite_USAKorean.set**.
 - e. Enter the scale(s) and database as needed.
 - f. Close the Setup Utility.
4. The following Korean (KS C 5601) fonts are now available:
 - 15: Super Small (Korean)
 - 16: Small (Korean)
 - 17: Medium (Korean)
 - 18: Large (Korean)

Ishida SLP-5 Lite and Uni-3 Korean Setup

Notes

1. Loading the new Korean setup file returns SLP-5 Lite to default configuration settings. If any scale(s), database, PLU Fields, etc. had been set they will be lost and must be re-entered.
2. Each line of the PLU description should consist of either Korean or English. Do not mix the characters on one line.



© Rice Lake Weighing Systems Specifications subject to change without notice.
Rice Lake Weighing Systems is an ISO 9001 registered company.

230 W. Coleman St. • Rice Lake, WI 54868 • USA
U.S. 800-472-6703 • Canada/Mexico 800-321-6703 • International 715-234-9171 • Europe +31 (0)26 472 1319

www.ricelake.com/retail

www.ricelake.mx

www.ricelake.eu

www.ricelake.co.in