



DecliHand

800-472-6703 www.ricelake.com



# The handy DeckHand® weighs and rolls anywhere

Move the DeckHand to any part of a facility and be instantly ready to weigh accurately. The platform is designed to weigh perfectly on all corners. Off-center product loading will not affect weighing accuracy.

DeckHand wheels only touch the floor when the unit is tilted back for movement allowing the weighing platform to remain stable on uneven floors.

Partner this scale with one of Rice Lake's battery-operated indicators like the 380 Synergy Series.

All models on this page are shown with optional indicators.

## Mild Steel with aluminum environmentally sealed load cells

Size (W x L x H)	Capacity
31 x 41 x 4.5 in (787 x 1041 x 114 mm)	500 lb (250 kg)
31 x 41 x 4.5 in (787 x 1041 x 114 mm)	1000 lb (500 kg)
31 x 41 x 4.5 in (787 x 1041 x 114 mm)	2000 lb (1000 kg)

## Stainless Steel with aluminum environmentally sealed load cells

Size (W x L x H)	Capacity
31 x 41 x 4.5 in (787 x 1041 x 114 mm)	500 lb (250 kg)
31 x 41 x 4.5 in (787 x 1041 x 114 mm)	1000 lb (500 kg)
31 x 41 x 4.5 in (787 x 1041 x 114 mm)	2000 lb (1000 kg)

# Installation Options Add Versatility...

- Indicator floor stand
- Digital weight indicators
- Anchor plates
- Access ramps

All installation options are available in mild or stainless steel.



ons



#### **STANDARD FEATURES**

- Mild or stainless steel wheeled frame, base and mast
- Diamond tread top plate, mild or stainless steel
- Large rubber wheels (not rated for IS) simplify movement on uneven floors
- Two IP67 aluminum load cells
- Standard indicator mount with integral handles for the 480/480 Plus, 482/482
  Plus, 880/880 Plus and 680 Synergy

#### **OPTIONS/ACCESSORIES**

- Clam shell for additional load cell protection
- Ramp

#### APPROVALS



#### WARRANTY

- Weldment: Five-year
- Load cells: Two-year
- All other components: One-year





HEADQUARTERS 230 West Coleman Street Rice Lake, Wisconsin 54868 - USA Tel: (715) 234 9171 | Fax: (715) 234 6967 www.ricelake.com