

Ishida SLP-5 Lite and Uni-3 Chinese BIG5 Setup

These instructions are to configure the Ishida Uni-3 and SLP-5 Lite to print Chinese characters. The Chinese characters must be sent from SLP-5 Lite – they cannot be programmed at the scale.

Uni-3

From firmware version C1937U and all of C2271x, the Uni-3 supports Chinese BIG5 characters, also known as Traditional. The Language setting in the Uni-3 must be set to "Formosan" to print and display Chinese characters. All menus, etc. remain in English.

Note: Only the Uni-3L2 models display Chinese characters.

KEY IN ITEM No. 0.000 0.000 0.00 0.00	Enter 6000 , press Mode
<B00 SETUP> <B00 SETUP>	Enter 495344 , press PLU
<B00 SETUP> <B00 SETUP>	Enter 26 , press Down Arrow
B26 COUNTRY B26 COUNTRY	Press Enter
*LANGUAGE → 1: ENGLISH B26-01-02 LANGUAGE 1	Enter 16 , press Enter
*LANGUAGE → 15: FORMOSAN B26-01-02 LANGUAGE 15	After the long beep press Mode
REBOOT 19004-0000	The scale must be shut off for this setting change to take effect.

SLP-5 Lite

From version 2.20c it is possible to send Chinese characters to the Uni-3 scale. These are the steps to enable Chinese characters.

1. Install SLP-5 Lite as usual. Do not configure the scales or database until after the Chinese setup file has been loaded.
2. Do not use the default Chinese setup file installed with SLP-5 Lite. The file will not work. Instead download the updated setup file from the SLP-5 Lite software page on the [Rice Lake web](#) site. Login is required.
3. Install the new setup file as follows.
 - a. Open the SLP-5 Lite Setup Utility.
 - b. Select the **Configuration** menu.
 - c. Select **Load Setup**.
 - d. Navigate to and select the new setup file: **Update_Lite_USAChinese.set**.
 - e. Enter the scale(s) and database as needed.
 - f. Close the Setup Utility.
4. The following Chinese BIG5 fonts are now available:
 - 16x16 SLP-5 size Small [Ingredients]
 - 24x24 SLP-5 size Medium [Messages]
 - 32x32 SLP-5 size Large [Item Name]
 - 48x48 SLP-5 size Large [Item Name]
 - 64x64 SLP-5 size Large [Item Name]

Ishida SLP-5 Lite and Uni-3 Chinese BIG5 Setup

Notes

1. Loading the new Chinese setup file returns SLP-5 Lite to default configuration settings. If any scale(s), database, PLU Fields, etc. had been set they will be lost and must be re-entered.
2. Each line of the PLU description should consist of either Chinese or English. Do not mix the characters on one line.



© Rice Lake Weighing Systems Specifications subject to change without notice.
Rice Lake Weighing Systems is an ISO 9001 registered company.

230 W. Coleman St. • Rice Lake, WI 54868 • USA
U.S. 800-472-6703 • Canada/Mexico 800-321-6703 • International 715-234-9171 • Europe +31 (0)26 472 1319

www.ricelake.com/retail

www.ricelake.mx

www.ricelake.eu

www.ricelake.co.in