

## Star NP-3511 and NP-2511 DIP Switch Settings

From section 4.1.1 of the NP-2511 and NP-3511 Product Specification manual.

### 4.1.1 DIP switch

A single DIP switch is mounted on the control board module – it is accessible through a cutout on the bottom of the printer.

SW No.	Function	ON	OFF	Factory setting
DS1-1	Transmit Setting	See Figure 1		Off
DS1-2				Off
DS1-3				Off
DS1-4	Serial Transmit Speed	See Figure 2		Off
DS1-5				Off
DS1-6	Serial Flow Control	XON/XOFF	RTS/CTS	Off
DS1-7	Autocutter	No	Yes	Off
DS1-8	Reserved	-	-	Off *

\* DS1-8 must be Off

Interface	Bit Length	Parity Setting	DS-1	DS-2	DS-3
USB	-	-	Off	Off	Off
Serial	8 Bit	Nil	On	Off	Off
		Odd	Off	On	Off
		Even	On	On	Off
	7 Bit	Nil	Off	Off	On
		Odd	On	Off	On
		Even	Off	On	On
Reserved	-	-	On	On	On

Figure 1

Serial Transmit Speed	DS1-4	DS1-5
115200	Off	Off
38400	On	Off
19200	Off	On
9600	On	On

Figure 2