



## Standard Features

- Foot adjustment holes for leveling scale from above
- Four ball-encapsulated feet
- Four IP66, alloy steel 10,000 lb load cells
- Top-access junction box
- Epoxy paint for added protection. Ramps are painted yellow and scale is painted black to easily distinguish live weighing surface.
- 20 ft SURVIVOR® EL147HE hostile environment load cell cable to connect scale to indicator. Cable can exit scale/ramp from any corner.
- Scale and wraparound ramps to access scale from all sides
- Ramps have integrated foot keeper plates to keep scale in check with ramps
- Holes in ramps to access internal anchor tabs from above. 16 anchor bolts at 3/4 in included.
- All surfaces diamond tread

## Specifications

### End Load Capacity:

100% full scale at 20,000 lb

### Cable Length:

20 ft (6.1 m) for connecting junction box to indicator

### Junction Box:

TuffSeal® JB4SS stainless steel, NEMA Type 4X junction box with signal trim card

### Welding:

Stitch

### Threaded Eyebolt:

Four holes (3/4-10 NC)

### Warranty (limited):

Weldment: Five years  
Load cells: Two years  
All other components: One year

## Part Number/Price

| Part # | Overall Size (W × L × H)  | Ramp Angle of Incline | Capacity  | Est. Weight | Price   |
|--------|---|-----------------------|-----------|-------------|---------|
| 194338 | Scale: 10 ft × 10 ft × 4 3/8 in<br>Ramps: (4) 3 ft × 10 ft × 4 3/8 in<br>Corners: (4) 3 ft × 4 ft 1 in × 4 3/8 in | 6.5°                  | 20,000 lb | 6,800 lb    | Consult |

## Dimensions

| RoughDeck PC |           |   |         |
|--------------|-----------|---|---------|
| A            | 120.00 in | C | 4.37 in |
| B            | 35.80 in  | D | 0.38 in |

Note: 1 in=25.4 mm

