Mettler Toledo[™] Bridgemaster[™] Truck Scale

Part Number/Price

Ref#	Part#	Description	Synonym	Price
1	22277	Lower plate assembly link pins center	10015600A	Consult
1	33915	Lower plate assembly with pins off center		Consult
2	22272	Link, unnotched	10011500B	Consult
3	22273	Link, notched	10011500A	Consult
4	22251	Retaining clips	10011700A	Consult
5	22274	Center screw	10011300A	Consult
6	22276	Upper plate assembly	10010600A	Consult
7	22269	Adaptor ring with 0-ring	10011400A	Consult
8	22268	Base plate and pin assembly	10011800A	Consult
9	22252	Skirt kit	10010400A	Consult
10	30302	Base plate		Consult

(See Diagram Toledo Bridgemaster-A)