


## Ishida WM-4000 Auto Wrapper Camera Access

Follow these steps to access the WM-4000 tray verification camera components.

### Notes:

1. If the camera controller P-1007A (157904) or the CMOS camera (157918) is replaced the camera must be recalibrated and the trays re-detected. Refer to the WM-4000 camera calibration instructions.
2. If the camera controller P-1007A is replaced firmware must be downloaded to the board. That is done from the Test Mode > Program Download > Detect Appl. Download from the CF-1 (Program CF). The message 1533 "A Problem Arose In The Tray Detector" will appear if the firmware is not downloaded.




**Remove the two interior covers indicated by the arrows**

## Ishida WM-4000 Auto Wrapper Camera Access




**Remove the front conveyor cover**




**Remove the lower conveyor cover**

## Ishida WM-4000 Auto Wrapper Camera Access



**Loosen two left side conveyor mounting bolts**



**Loosen two right side conveyor mounting bolts**

# Ishida WM-4000 Auto Wrapper Camera Access

Remove the conveyor assembly to access the camera components

