

Operator Card – 920i® Livestock Rate of Gain Quick Start

Refer to Operator's Manual (PN 173160) for detailed instructions

Manuals are available on our web site at

www.ricelake.com/manuals

The 920i can be used to weigh animals and store the weighments for download to a PC. Up to 500 animals with three weighments per ID may be stored (total of 1500 transactions). This program can be used with a 920i weighcenter or a stand-alone 920i.



Failure to heed may result in serious injury or death.

Do not allow minors/inexperienced people to operate.

Do not operate without all shields and guards in place.

Do not use for purposes other than weight taking.

Do not use any load bearing component that is worn beyond 5% of the original dimension.

Do not use this product if any components are cracked.


Do not exceed the rated load limit of the unit.

Do not make alterations or modifications to the unit.

Do not remove or obscure warning labels.

Keep body and loose clothing away from moving parts.

Weigh a Single Animal



1. Place an animal on the scale. **Enter/Scan Animal ID** displays.
2. Enter the animal ID number (up to 15 characters) or scan the animal's ear tag.
3. Press the **Record Weight** softkey.
 - Previously saved weights for that specific ID are displayed. The current weight replaces the oldest weight saved.
 - If there are no previous weights, a new record is added.
 - A ticket prints when the ID is entered and a stable weight is captured with ID#, gross weight and date/time on the print ticket.
4. Press the **End** softkey to return to the startup screen.

Print

Press the **Print Records** softkey to print only the three previously recorded weights. The current weight will not be printed or recorded.

To print the weight of only one animal, press  at any time between batches to print the gross weight, with the time/date, of only one animal.

Downloading Databases

1. Using a PC, copy the desired database file to a flash drive.
2. Connect the flash drive to the 920i USB connector.
3. Press **Setup Menu** softkey.
4. Press the **USB** softkey.
5. Press the **Upload/Download** softkey.
6. Select **Save All Databases** (*.db).
7. Press .
8. Press the **Exit** softkey to return to the **Setup Menu**.
9. Press **More=>** softkey.
10. Press **Exit** to return to weighing mode.

Uploading Databases

1. Using a PC, copy the desired database file to a flash drive.
 2. Connect the flash drive to the 920i USB connector.
 3. Press **Setup Menu** softkey.
 4. Press the **USB** softkey.
 5. Press the **Upload/Download** softkey.
 6. Select **Load All Databases** (*.db).
 7. Press .
 8. Press the **Exit** softkey to return to the **Setup Menu**.
 9. Press **More=>** softkey.
- Press **Exit** to return to weighing mode.

05/30/2018	11:06AM	Scale #
2379		Scale #
Gross		lb/kg
Animal Tag ID#	2379lb 11/24/15 01:12PM	
1234	2269lb 11/24/15 01:00PM	
	2340lb 11/24/15 12:30PM	
Select Action		
Record Weight	Print Records	End

Power up the indicator. It goes through the start up test and the start up screen displays.