


AutoLift HE

Pit Frame Concrete Details*



- 1 Length of pipe is determined on site
- 2 Use concrete of minimum yield strength 5,000 PSI or 6-bag mix
- 3 Slope pipe slightly for water drainage
- 4 Allow concrete 7 days to cure (wet concrete periodically during this time)
- 5 Tie pit in with existing floor with rebar if required
- 6 Ensure underside is supported with concrete or grout (plate is an integral part of frame)
- 7 Keep pocket free of concrete.
- 8 Coping must sit level in floor to allow proper operation of scale

Drawing Dimensions		
Scale Size	4 ft x 4 ft	5 ft x 5 ft
A	63.06	75.06
B	49.06	61.06
C	49.00	61.06
D	63.00	75.00
E (PN)	41936	41397
F	15.00	16.75

All dimensions are shown in inches. Drawing #S5158-Rev. B,
 * Drawings are for standard catalog part numbered scales.