

2. Attach a null modem adapter to the serial cable connector.




Figure 2

3. If needed, add a gender changer to the connector cable.




Figure 3

4. Test for connectivity. If connectivity test fails, consult a technician for repair.

NOTE: Use the null modem adapter until wiring can be corrected by a trained technician.



© Rice Lake Weighing Systems Specifications subject to change without notice.

230 W. Coleman St. • Rice Lake, WI 54868 • USA

U.S. 800-472-6703 • Canada/Mexico 800-321-6703 • International 715-234-9171 • Europe +31 (0)26 472 1319